



Diagnostic devices

Additions And Modifications In Software Version 65

Things to know – an overview

New

mega macs X

- High-voltage measurements available (requires additional hardware MT-HV)
- Low-voltage measurements available (requires additional hardware MT-HV, MT77 or MT56)The new MT-HV consists of an electronic unit with a firmly integrated high-voltage measuring technology and a module slot in which the well-known low-voltage measurement modules MT56 and MT77 can be inserted.NOTE: The MT-HV hardware will be available soon.

mega macs X, mega macs 77

- **Cyber Security Management (CSM):** for Cebas (Mercedes Benz) and SFD (Volkswagen Group)
- **OBD-Diagnostics:** Function OBFCM (OnBoardFuelConsumptionMeter) available under Generic – Beta status
- **Car History:** Measurements entries can be printed out

mega macs 56

- Connection of the mega macs X as DoIP VCI possible
- Vehicles which are partly capable for diagnostics or not at all are marked in a different color

mega macs BIKE

- Extension of the OBD adapter sets by BMI01, BSWM01, BVIP01

Revisions

mega macs 66, mega macs 56, mega macs PC, mega macs 42 SE

- Error in communication setup at actuator test menu of various models is removed
- Global fault deletion possible again (communication to vehicle no longer interrupted)

mega macs 66, mega macs 56, mega macs PC

- Components are not longer listed twice in the service schedule
- **Basic setting of Mercedes:** Indication troubles of tags/parameters in the basic setting is removed
- Tables in the Technical data menu correctly indicated again

mega macs 66, mega macs 56

- Trouble code texts no longer indicated twice
- Car History is reliably transferred again

mega macs 66, mega macs PC

- Troubles during depiction of flat rate units removed
- Number of entries in the Car History correctly indicated again



Diagnostic devices

mega macs PC

- Spontaneous internal fault during license update removed
- Fault during online connection on some PCs removed

mega macs 56

- Fault during Wi-Fi connection when printing out via PC (HGScom) removed

mega macs 42 SE

- Crash and undefined behavior upon selection of the menu **Reading trouble codes** removed
- Voltage value of vehicle correctly actualized and indicated in help dialog now

mega macs X, mega macs 77

- Troubleshooting in parameters summary request
- Continue in basic settings menu now and function can be completed properly now
- Continue in Codings menu now and function can be completed properly now
- OEM text at service reset is indicated now
- Missing ECUs at trouble code request through gateway (VAG) removed
- Abort button in parameters summary request works correctly now
- Various internal faults in CSM removed
- Region can be selected in the Settings menu now
- **Print a test page** function available for all printer settings now
- Search for a printer and printout function improved
- Summary request of kilometer/mileage reading improved
- Component suggestions in **Reading trouble codes** menu no longer indicated twice

mega macs X

- **MT-USB:** Connection troubles and missing settings removed
- Update errors of internal VCI removed

Modifications

mega macs X, mega macs 77

- **Cyber Security Management (CSM):** Usability of user administration optimized
- **Car History:** Double input of license number corrected

mega macs X

- Vehicle selection: DoIP warning note indicated longer
- Voltage indicator of vehicle battery with connected VCI permanently indicated

mega macs 77

- Vehicle selection: The diagnostic button is inactive for vehicles which can be diagnosed exclusively via DoIP or CAN-FD.



Diagnostic devices

mega macs 66, mega macs 56, mega macs PC, mega macs 42 SE

- **Cyber Security Management (CSM):** Causes for error message additionally indicated now
- **Cyber Security Management (CSM) with Cebas (Mercedes Benz):** Now the Daimler certificate is downloaded only if it is expired
- **Opel:** Speed at status change during parameter reading optimized

mega macs 66, mega macs 56, mega macs PC

- **Kilometer/mileage summary request:** Various procedures optimized

mega macs 66, mega macs 42SE

- Optimization of Bluetooth connection setup

mega macs 56, mega macs 42 SE

- LED blink code indicator for Bluetooth connection setup of VCI optimized

mega macs 56

- Update possible only with power supply connected

mega macs 42 SE

- **Cyber Security Management (CSM):** CSM user password can be reset also for deleted users now
- Bluetooth connection setup after VCI update optimized

mega macs PC

- Demo mode optimized and fault message handling adapted
- Links to wiring diagrams in the dialog **Component help** completed



Diagnostic devices

Vehicle Models with Cyber Security Management According to Manufacturer

This list merely gives a basic overview of the scope of our data additions.

Manufacturer

Alfa Romeo

- | Model [Giulia (952) ab 18-, Stelvio (949) ab 18-]

Audi

- | Model [A3 ab 20-, Q4 e-tron ab 21-]

Cupra

- | Model [Leon ab 20-, Formentor ab 20-, Born ab 21-]

Fiat

- | Model [500 (312) ab 20-, 500L (330) ab 17-, 500X (334) ab 18-, 500e (332), Doblo (152/263) ab 18-]

Jeep

- | Model [Renegade ab 19-, Compass (MP) ab 17-]

Mercedes

- | Model [E-Klasse (213 -Mod.20-) ab 20-, S-Klasse (223) ab 20-]

Seat

- | Model [Leon ab 20-]

Skoda

- | Model [Octavia ab 20-, Enyaq ab 21-]



Diagnostic devices

Volkswagen

Model	[Golf 8 ab 19-, Caddy ab 20-, ID.3 ab 20-, ID.4 ab 20-, Transp.T7 ab 21-]
-------	---



Diagnostic devices

Functions according to manufacturer

This list merely gives a basic overview of the scope of our data additions. A complete list with all the model additions for every manufacturer would be simply too extensive.

Extended and revised manufacturers

Audi

Trouble codes	(A4, 8W), (A5, F5), (Q3, F3), (Q7, 4M), (RS4, 8W), (RS5, F5), (S4, 8W), (S5, F5)
Parameters	(A4, 8W), (A5, F5), (Coupe, 8B), (Q3, F3), (Q7, 4M), (RS4, 8W), (RS5, F5), (S4, 8W), (S5, F5)
Actuators	(Coupe, 8B), (Q3, F3), (Q7, 4M)
Basic settings	<p>Initializing electric seats ((Q3, F3))</p> <p>Initializing the adaptive cruise control ((Q3, F3))</p> <p>Activating/deactivating the filling mode of electronic damper control ((RS7, 4G), (RS5, 8T), (RS6, 4G), (RS4, 8K), (RS5, 8F))</p> <p>Standardizing the loading space cover ((Q7, 4M), (A4, 8W), (S4, 8W), (A5, F5), (S5, F5), (RS5, F5), (RS4, 8W), (Q8, 4M), (e-tron, GE))</p> <p>Regenerating the soot particulate filter ((Q3, F3))</p> <p>Resetting engine adaptation values ((A1, 8X), (A3, 8P), (A5, 8T), (A5, 8F))</p> <p>Initializing the ESC sensors ((A3, 8Y), (S3, 8Y), (Q3, F3))</p> <p>Reset learned values of injectors. ((Q3, F3))</p> <p>Initialize 4WD clutch oil pump ((Q3, F3))</p> <p>Adapting the electronic damper control ((A4, 8K), (A5, 8F), (A5, 8T), (S5, 8T), (A7, 4G), (S4, 8K), (A6, 4G), (Q5, 8R), (Q3, 8U), (S7, 4G), (S6, 4G), (RS Q3, 8U), (RS5, 8T), (S5, 8F), (RS4, 8K), (RS5, 8F), (Q3, F3))</p> <p>Initializing the intake air control flap ((S5, 8T), (A7, 4G), (A8, 4H), (S4, 8K), (A6, 4G), (A4, 8K), (A5, 8F), (A5, 8T), (Q5, 8R), (S5, 8F), (Q7, 4M))</p> <p>Bleeding the fuel system ((A6, 4B), (A4, 8H), (A6, 4G), (A7, 4G), (Q3, F3))</p> <p>Burning off aux. heater/independent car heater ((Q3, F3))</p> <p>Changing and checking DCT fluid ((A4, 8K))</p> <p>Initializing the boost pressure regulator ((A5, 8T), (A5, 8F), (Q3, F3))</p> <p>Initializing the seat belt tensioner ECU ((Q3, F3))</p> <p>Standardizing the liftgate ((Q7, 4M), (A4, 8W), (S4, 8W), (Q2, GA), (A5, F5), (S5, F5), (Q5, FY), (RS5, F5), (RS4, 8W), (A8, 4N), (A6, 4A), (A7, 4K), (Q3, F3), (Q8, 4M), (S6, 4A), (S7, 4K), (RS Q3, F3), (e-tron, GE), (A3, 8Y), (S3, 8Y), (Q4 e-tron, FZ), (e-tron GT, FW), (RS6, 4A), (RS7, 4K), (S8, 4N))</p> <p>Initializing the fuel pump ((A3, 8P), (A6, 4F), (A4, 8E), (A4, 8H), (TT, 8J))</p> <p>Initialize actuator of coolant temperature control ((A5, 8T), (A5, 8F))</p> <p>Adapting the soot particulate filter ((Q3, F3))</p>



Diagnostic devices

- Learning the throttle valve ((A6, 4F), (Q3, F3))
- Learning the steering-angle sensor ((Q3, F3))
- Initializing the tilt/slide sunroof ((Q3, F3))
- Filling fuel lines of parking heater/auxiliary heater ((Q3, F3))
- Configuring the head-up display ((A4, 8W))
- Adapting the fuel burning heater remote control ((Q3, F3))
- Initializing the brake-pressure sensor ((A3, 8Y), (S3, 8Y), (Q3, F3))
- Performing transmission adaptations ((A7, 4G), (A6, 4G), (Q5, 8R), (S7, 4G), (S6, 4G), (RS7, 4G), (RS6, 4G), (A4, 8W), (S4, 8W), (A5, F5), (S5, F5), (Q5, FY), (RS5, F5), (RS4, 8W), (A6, 4A), (A7, 4K), (S6, 4A), (S7, 4K), (Q3, F3), (RS6, 4A), (RS7, 4K))
- Test of lambda control short trip ((A4, 8H))
- Resetting learned values of DEF injection system ((A3, 8V), (Q3, 8U), (Q2, GA), (Q3, F3))
- Performing the initial run-in of the air conditioning compressor ((Q7, 4M), (Q8, 4M))
- Check lambda ageing bank 1 before catalyst ((A4, 8H))
- Resetting the refrigerant loss counter ((Q7, 4M))
- Retracting parking brake ((A3, 8Y), (S3, 8Y), (Q4 e-tron, FZ), (Q3, F3))
- Reducing fuel high pressure ((Q3, F3))
- Test of secondary air valve bank 1 ((A4, 8H))
- Initializing the alternator ((Q3, F3))
- Resetting gearbox learning values ((A4, 8E), (A4, 8H))
- Activating the retrofitted parking heater ((Q3, F3))
- Test of lambda status probe 1 + 2 ((A4, 8H))
- TESTING LAMBDA-CONVERSION BANK 1 ((A4, 8H))
- Adapting the cabin fragrance system ((Q7, 4M))
- Configuring the lane change assist ((Q3, F3))
- Initializing the A/C flap actuators ((Q7, 4M), (Q8, 4M), (Q3, F3))
- Resetting timing chain adaptation values ((A5, 8T), (A5, 8F))
- Resetting the impact mode ((Q7, 4M), (A4, 8W), (S4, 8W), (A5, F5), (S5, F5), (Q5, FY), (RS5, F5), (RS4, 8W), (A8, 4N), (A6, 4A), (A7, 4K), (Q8, 4M), (Q3, F3), (S6, 4A), (S7, 4K), (A3, 8Y), (S3, 8Y), (RS6, 4A), (RS7, 4K), (S8, 4N))
- Initializing the neutral position sensor ((Q3, F3))
- Checking oxygen sensor (bank 2) before catalyst ((A4, 8H))
- Calibrating the parking brake ((Q3, F3))
- Initializing the clutch pedal position ((Q3, F3))
- Adapting the radiator shutter ((Q3, F3))
- Calibrating the parking brake ((A3, 8Y), (S3, 8Y))
- Adjusting the headlights ((Q7, 4M), (Q8, 4M), (Q3, F3))
- Adapting oil pressure for engine run-in ((A8, 4N), (A6, 4A), (A7, 4K), (Q7, 4M), (Q8, 4M))
- Bleeding the cooling system ((A5, 8T), (A5, 8F), (Q3, F3))



Diagnostic devices

Calibrating the camera ECU ((Q7, 4M), (Q2, GA), (A1, GB), (Q3, F3), (Q8, 4M), (RS Q3, F3), (A3, 8Y), (S3, 8Y), (Q4 e-tron, FZ))

De-energizing the 48 V system ((Q3, F3))

Filling/bleeding the pneumatic suspension system ((Q7, 4M), (Q5, FY), (A8, 4N), (A6, 4A), (A7, 4K), (Q8, 4M), (S6, 4A), (S7, 4K), (e-tron, GE), (RS6, 4A), (RS7, 4K), (S8, 4N))

Putting the 48 V system back into operation ((Q3, F3))

Extending parking brake ((A3, 8Y), (S3, 8Y), (Q4 e-tron, FZ), (Q3, F3))

Unlocking aux. heater/independent car heater ((Q3, F3))

Initializing the active steering ((A4, 8K), (A5, 8F), (A5, 8T), (S5, 8T), (A8, 4H), (A7, 4G), (S4, 8K), (A6, 4G), (Q5, 8R), (S7, 4G), (S6, 4G), (RS7, 4G), (RS5, 8T), (S5, 8F), (RS6, 4G), (S8, 4H), (RS4, 8K), (RS5, 8F))

Activating the roller test stand mode ((A3, 8Y), (S3, 8Y))

Codings

Coding the trailer hitch ((Q3, F3))

General ECU replacement ((Q3, F3))

Coding the radio remote control ((A4, 8H), (S4, 8H), (A4, 8E), (RS4, 8E))

Expert mode ECU coding ((Q3, F3))

Coding the rain/light sensor ((Q3, F3))

Registering the battery ((A3, 8Y), (S3, 8Y), (Q3, F3))

Deactivating/activating the transport mode ((A3, 8Y), (S3, 8Y), (Q3, F3))

Coding the ABS ECU ((A3, 8P), (S3, 8P), (RS3, 8P))

Coding the language version of instrument cluster ((Q3, F3))

Adapting the trailer hitch to advanced driver assistance systems ((Q3, F3))

Adjust parking assistance volume ((Q3, F3))

De/activating the trailer hitch ((A3, 8Y), (S3, 8Y), (Q3, F3))

Coding the gateway installation list ((Q3, F3))

Coding the parking assist ((A4, 8K), (A5, 8F), (A5, 8T), (S5, 8T), (A1, 8X), (S4, 8K), (Q5, 8R), (Q3, 8U), (S1, 8X), (RS Q3, 8U), (RS5, 8T), (S5, 8F), (RS4, 8K), (RS5, 8F))

Service resets

(Q3, F3)

BMW

Trouble codes

(1 Ser., 1C), (2 Ser., F44), (2 Ser., F46), (3 Ser., G20), (3 Ser., G21), (4 Ser., G22), (4 Ser., G23), (4 Ser., G82), (5 Ser., G30), (5 Ser., G31), (6 Ser., G32), (7 Ser., G11), (7 Ser., G12), (8 Ser., G14), (8 Ser., G15), (8 Ser., G16), (i8, I12), (iX, I20), (iX3, G08), (X1, F48), (X2, F39), (X3, G01), (X4, G02), (X5, F95), (X5, G05), (X6, G06), (X7, G07), (Z4, G29)

Parameters

(1 Ser., 1C), (1 Ser., F40), (2 Ser., F44), (2 Ser., F46), (3 Ser., G20), (3 Ser., G21), (4 Ser., G22), (4 Ser., G23), (4 Ser., G82), (5 Ser., G30), (5 Ser., G31), (6 Ser., G32), (7 Ser., G11), (7 Ser., G12), (8 Ser., F91), (8 Ser., F92), (8 Ser., F93), (8 Ser., G14), (8 Ser., G15), (8 Ser., G16), (i8, I12), (iX3, G08), (X1, F48), (X2, F39), (X3, G01), (X4, G02), (X5, F95), (X5, G05), (X6, G06), (X7, G07), (Z4, G29)



Diagnostic devices

Actuators	(1 Ser., 1C), (1 Ser., F40), (2 Ser., F44), (2 Ser., F46), (3 Ser., G20), (3 Ser., G21), (3 Ser., G80), (4 Ser., G22), (4 Ser., G23), (4 Ser., G82), (5 Ser., F90), (5 Ser., G30), (5 Ser., G31), (6 Ser., G32), (7 Ser., G11), (7 Ser., G12), (8 Ser., F91), (8 Ser., F92), (8 Ser., F93), (8 Ser., G14), (8 Ser., G15), (8 Ser., G16), (i8, I12), (iX3, G08), (X1, F48), (X2, F39), (X3, G01), (X4, G02), (X5, F95), (X5, G05), (X6, G06), (X7, G07), (Z4, G29)
Basic settings	<p>Adapting the longitudinal acceleration sensor ((1 Ser., 1C))</p> <p>Resetting adaptation values of the EGR cooling system ((1 Ser., F40), (3 Ser., G20), (5 Ser., G31), (2 Ser., F44), (3 Ser., G21))</p> <p>Resetting reference values ((X3, G01), (2 Ser., F46), (X2, F39), (X4, G02), (4 Ser., G82), (6 Ser., G32), (i8, I12), (X1, F48))</p> <p>Taking the active steering into operation ((1 Ser., 1C))</p> <p>Resetting the operating time of brake booster vacuum pump ((i8, I12))</p> <p>Initializing the air suspension ((X3, G01), (X5, G05), (7 Ser., G12), (7 Ser., G11), (5 Ser., G30), (5 Ser., G31), (X4, G02), (3 Ser., G20), (3 Ser., G21), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (6 Ser., G32))</p> <p>Adjusting the starting torque ((1 Ser., F40), (2 Ser., F46))</p> <p>Learning the power windows ((X3, G01), (X5, G05), (8 Ser., G16), (X2, F39), (7 Ser., G12), (1 Ser., 1C), (3 Ser., G20), (3 Ser., G21), (5 Ser., G30), (5 Ser., G31), (7 Ser., G11), (X4, G02), (X6, G06), (Z4, G29), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (6 Ser., G32), (8 Ser., G14), (i8, I12), (X1, F48))</p> <p>Deactivating the service mode ((8 Ser., G16), (3 Ser., G20), (3 Ser., G21), (5 Ser., G30), (X3, G01), (X4, G02), (X5, G05), (4 Ser., G23), (4 Ser., G22), (5 Ser., G31), (6 Ser., G32), (7 Ser., G11), (8 Ser., G14), (8 Ser., G15), (X7, G07), (7 Ser., G12))</p> <p>Initializing the rain sensor ((X3, G01), (X5, G05), (8 Ser., G16), (3 Ser., G20), (3 Ser., G21), (5 Ser., G30), (5 Ser., G31), (7 Ser., G11), (X4, G02), (X6, G06), (Z4, G29), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (6 Ser., G32), (8 Ser., G14), (8 Ser., G15), (X7, G07))</p> <p>Adapting the A/C compressor ((X3, G01), (X5, G05), (8 Ser., G16), (2 Ser., F46), (X2, F39), (7 Ser., G12), (7 Ser., G11), (2 Ser., F44), (3 Ser., G20), (3 Ser., G21), (5 Ser., G30), (5 Ser., G31), (X4, G02), (X6, G06), (Z4, G29), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (6 Ser., G32), (8 Ser., G14), (8 Ser., G15), (X1, F48))</p> <p>Standardizing the liftgate ((8 Ser., G14))</p> <p>Calibrating the night vision assist ((5 Ser., G30), (5 Ser., G31), (3 Ser., G20), (3 Ser., G21), (4 Ser., G23), (4 Ser., G22), (6 Ser., G32))</p> <p>Resetting fuel system adaptation values ((1 Ser., F40), (8 Ser., G16), (2 Ser., F46), (X6, G06), (X2, F39), (7 Ser., G12), (7 Ser., G11), (X3, G01), (2 Ser., F44), (3 Ser., G20), (3 Ser., G21), (5 Ser., G31), (X4, G02), (X5, G05), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (5 Ser., G30), (6 Ser., G32), (8 Ser., G14), (8 Ser., G15), (X7, G07))</p> <p>Learning the steering-angle sensor ((2 Ser., F46))</p> <p>Filling/bleeding the SCR passive system ((X3, G01), (7 Ser., G12), (7 Ser., G11), (5 Ser., G30), (5 Ser., G31), (X4, G02), (2 Ser., F46), (3 Ser., G20), (3 Ser., G21), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (6 Ser., G32))</p> <p>Initializing the electronic stability control sensors ((X3, G01), (8 Ser., G16), (2 Ser., F46), (7 Ser., G12), (7 Ser., G11), (5 Ser., G30), (5 Ser., G31), (X4, G02), (3 Ser., G20), (3 Ser., G21), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (6 Ser., G32), (8 Ser., G14), (8 Ser., G15), (i8, I12), (X1, F48))</p>



Diagnostic devices

Regenerating the soot particulate filter ((1 Ser., F40), (1 Ser., 1C), (3 Ser., G20), (5 Ser., G31), (X3, G01), (X4, G02), (X5, G05), (2 Ser., F44), (2 Ser., F46), (3 Ser., G21), (5 Ser., G30), (6 Ser., G32), (7 Ser., G11), (X7, G07), (7 Ser., G12))

Resetting the transport mode of ride height leveling / ride height leveling ECU ((8 Ser., G16), (8 Ser., G15))

Initialize classification resistance of transfer case ((3 Ser., E90), (3 Ser., E91), (3 Ser., E92), (5 Ser., E61))

Initializing the rain/light sensor ((2 Ser., F46), (X2, F39), (1 Ser., 1C), (2 Ser., F44), (i8, I12), (X1, F48))

Taking the steering into operation ((2 Ser., F44))

Initializing the gear sensor ((3 Ser., F34), (2 Ser., F46), (X2, F39), (3 Ser., G20), (3 Ser., G21), (2 Ser., F44), (X1, F48))

Bleeding the fuel system ((1 Ser., F40), (X6, G06), (3 Ser., G20), (5 Ser., G31), (X3, G01), (X4, G02), (X5, G05), (2 Ser., F44), (3 Ser., G21), (5 Ser., G30), (6 Ser., G32), (7 Ser., G11), (X7, G07), (7 Ser., G12))

Bleeding the ABS/ESC system ((2 Ser., F46), (1 Ser., 1C))

Resetting the DME adaptation values ((X2, F39), (X1, F48))

Unlocking aux. heater/independent car heater ((X3, G01), (X5, G05), (8 Ser., G16), (7 Ser., G12), (7 Ser., G11), (1 Ser., 1C), (3 Ser., G20), (3 Ser., G21), (5 Ser., G30), (5 Ser., G31), (X4, G02), (X6, G06), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (6 Ser., G32), (8 Ser., G15))

Bleeding the ABS/ESC system ((X2, F39), (8 Ser., G14))

Deactivating the service mode of SCR ECU ((X6, G06))

Adapting the variable camshaft timing ((1 Ser., F40), (8 Ser., G16), (2 Ser., F46), (X2, F39), (7 Ser., G12), (7 Ser., G11), (X3, G01), (2 Ser., F44), (3 Ser., G20), (3 Ser., G21), (X4, G02), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (5 Ser., G30), (5 Ser., G31), (6 Ser., G32), (8 Ser., G14), (8 Ser., G15), (X1, F48), (X5, G05), (X7, G07))

Resetting learned values of fuel pressure regulator ((5 Ser., F10), (1 Ser., 1C))

Bleeding the fuel system ((1 Ser., 1C), (2 Ser., F46))

Reset fuel pump learning values ((1 Ser., 1C))

Resetting transfer case adaptation values ((X6, G06), (X7, G07))

Replacing components of DEF injection system ((2 Ser., F45), (2 Ser., F46), (X1, F48), (5 Ser., G31), (5 Ser., G30), (X3, G01), (X2, F39), (6 Ser., G32), (X4, G02), (8 Ser., G15), (X5, G05), (3 Ser., G20), (8 Ser., G14), (X7, G07), (1 Ser., F40), (3 Ser., G21), (8 Ser., G16), (X6, G06), (2 Ser., F44), (4 Ser., G22), (4 Ser., G23))

Resetting the body control module ((1 Ser., 1C))

Performing the internal tank pressure sensor synchronization ((i3, I01), (X3, G01), (X5, G05), (3 Ser., G20), (3 Ser., G21), (4 Ser., G23), (4 Ser., G22), (5 Ser., G31), (i8, I12))

Deactivating the transport mode ((X5, G05), (7 Ser., G12), (7 Ser., G11), (5 Ser., G30), (5 Ser., G31), (3 Ser., G20), (3 Ser., G21), (4 Ser., G23), (4 Ser., G22), (6 Ser., G32), (8 Ser., G14), (X7, G07))

Initializing the exhaust gas flap ((3 Ser., F31), (3 Ser., F30), (3 Ser., F34), (X5, G05), (X7, G07), (1 Ser., F40), (X2, F39), (2 Ser., F44), (3 Ser., G20), (3 Ser., G21), (5 Ser., G30), (5 Ser., G31))

Resetting engine adaptation values ((3 Ser., G20), (3 Ser., G21), (X1, F48))



Diagnostic devices

Initializing the turn signal front ((X3, G01), (2 Ser., F46), (X2, F39), (7 Ser., G12), (7 Ser., G11), (5 Ser., G30), (5 Ser., G31), (X4, G02), (3 Ser., G20), (3 Ser., G21), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (6 Ser., G32), (i8, I12), (X1, F48))

De-standardizing the tilt/slide sunroof ECU ((1 Ser., 1C))

Adapting the electronic damper control ((2 Ser., F46), (X2, F39), (X1, F48))

Unlocking the electric auxiliary heater ((X3, G01), (X5, G05), (8 Ser., G16), (7 Ser., G12), (7 Ser., G11), (2 Ser., F44), (3 Ser., G20), (3 Ser., G21), (5 Ser., G30), (5 Ser., G31), (X4, G02), (X6, G06), (Z4, G29), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (6 Ser., G32), (8 Ser., G14), (8 Ser., G15))

Resetting the start inhibitor of DEF injection system ((X6, G06))

De/activating the parking brake service mode ((Z4, G29), (X5, G05), (1 Ser., F40), (7 Ser., G12), (7 Ser., G11), (iX, I20), (2 Ser., F44), (3 Ser., G20), (3 Ser., G21), (X6, G06), (8 Ser., G14), (X7, G07))

Reset learning values ((X1, F48))

Initializing the glow plugs ((1 Ser., F40), (3 Ser., G20), (2 Ser., F44), (2 Ser., F46), (3 Ser., G21))

Activating the assembly position of the exhaust gas flap actuator ((3 Ser., F31), (3 Ser., F30), (3 Ser., F34), (X5, G05), (X7, G07), (1 Ser., F40), (8 Ser., G16), (X2, F39), (7 Ser., G12), (2 Ser., F44), (3 Ser., G20), (3 Ser., G21), (5 Ser., G30), (7 Ser., G11), (4 Ser., G23), (4 Ser., G22), (5 Ser., G31), (6 Ser., G32), (8 Ser., G14), (8 Ser., G15))

Initializing the angular offset between the crankshaft and camshaft ((1 Ser., F40), (3 Ser., G20), (5 Ser., G31), (X3, G01), (X4, G02), (X5, G05), (2 Ser., F44), (2 Ser., F46), (3 Ser., G21), (5 Ser., G30), (6 Ser., G32), (7 Ser., G11), (X7, G07), (7 Ser., G12))

Clearing the list of stored Bluetooth devices ((1 Ser., 1C))

Performing the initial run-in of the air conditioning compressor ((i8, I12))

Configuring the lane change assist ((X1, F48))

Initializing the ride height sensor ((2 Ser., F46), (X2, F39), (i8, I12), (X1, F48))

Initializing the tilt/slide sunroof manually ((1 Ser., 1C))

Initializing the SCR system ((6 Ser., G32))

Calibrating the tire pressure monitoring system manually ((1 Ser., 1C))

Standardizing the liftgate ((X3, G01), (X5, G05), (8 Ser., G16), (2 Ser., F46), (X2, F39), (7 Ser., G12), (7 Ser., G11), (3 Ser., G20), (3 Ser., G21), (5 Ser., G30), (5 Ser., G31), (X4, G02), (X6, G06), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (6 Ser., G32), (8 Ser., G15), (X1, F48), (X7, G07))

Learning the power windows ((5 Ser., F10), (2 Ser., F46), (1 Ser., 1C))

Reset fuel pump learning values ((X5, F15))

Replacing the brake fluid ((X5, G05), (8 Ser., G16), (X6, G06), (8 Ser., G14), (8 Ser., G15), (X7, G07))

Resetting learned values of swirl flap actuators ((1 Ser., 1C))

Bleeding the cooling system ((X4, F26), (1 Ser., F40), (2 Ser., F46), (X6, G06), (3 Ser., G20), (5 Ser., G31), (X3, G01), (X4, G02), (X5, G05), (2 Ser., F44), (3 Ser., G21), (5 Ser., G30), (6 Ser., G32), (7 Ser., G11), (X1, F48), (X7, G07), (7 Ser., G12))

Adapting ETC components ((1 Ser., 1C))



Diagnostic devices

Replacing the particle filter ((1 Ser., F40), (X6, G06), (1 Ser., 1C), (3 Ser., G20), (5 Ser., G31), (X3, G01), (X4, G02), (X5, G05), (2 Ser., F44), (2 Ser., F46), (3 Ser., G21), (5 Ser., G30), (6 Ser., G32), (7 Ser., G11), (X7, G07), (7 Ser., G12))

De-energizing the 48 V system ((X5, G05), (8 Ser., G16), (7 Ser., G12), (7 Ser., G11), (X3, G01), (3 Ser., G20), (3 Ser., G21), (5 Ser., G30), (5 Ser., G31), (X4, G02), (X6, G06), (Z4, G29), (4 Ser., G82), (6 Ser., G32), (8 Ser., G14), (8 Ser., G15), (X7, G07))

Filling/bleeding the pneumatic suspension system ((X3, G01), (X5, G05), (8 Ser., G16), (7 Ser., G12), (7 Ser., G11), (5 Ser., G30), (5 Ser., G31), (X4, G02), (3 Ser., G20), (3 Ser., G21), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (6 Ser., G32), (8 Ser., G14), (8 Ser., G15), (X7, G07))

Adapting the N position sensor ((1 Ser., 1C))

Initialize acceleration sensor ((1 Ser., F40), (2 Ser., F44))

Initializing the neutral position sensor ((2 Ser., F46), (X2, F39), (X1, F48))

Resetting the immobilizer ((1 Ser., 1C))

Restarting the transmission ECU ((1 Ser., 1C))

Replacing the lean NOx catalyst ((X6, G06), (5 Ser., G31), (X3, G01), (X4, G02), (X5, G05), (3 Ser., G21), (5 Ser., G30), (6 Ser., G32), (X7, G07))

Reactivating the ECU output after short circuit ((1 Ser., 1C))

Calibrating the parking brake ((5 Ser., F10))

Aiming the headlights for targeted lighting ((X1, F48))

Resetting the ECU ((X3, G01), (X5, G05), (8 Ser., G16), (2 Ser., F46), (X2, F39), (7 Ser., G12), (7 Ser., G11), (1 Ser., 1C), (3 Ser., G20), (3 Ser., G21), (5 Ser., G30), (5 Ser., G31), (X4, G02), (Z4, G29), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (6 Ser., G32), (8 Ser., G14), (8 Ser., G15), (X1, F48), (X7, G07))

Self-adaptation of A/C system ((i8, I12))

Reset exhaust-gas aftertreatment learning values ((1 Ser., F40), (X6, G06), (3 Ser., G20), (5 Ser., G31), (X3, G01), (X4, G02), (X5, G05), (2 Ser., F44), (2 Ser., F46), (3 Ser., G21), (5 Ser., G30), (6 Ser., G32), (7 Ser., G11), (X7, G07), (7 Ser., G12))

Gearbox bleeding ((2 Ser., F46), (X2, F39), (X1, F48))

Resetting long-term adaptation values of diesel exhaust fluid dosing module ((5 Ser., G31), (X3, G01), (X4, G02), (X5, G05), (3 Ser., G21), (5 Ser., G30), (6 Ser., G32), (X7, G07))

Calibrating the front camera ((5 Ser., F10), (2 Ser., F46), (iX, I20), (2 Ser., F44), (i8, I12), (X1, F48), (X7, G07))

Resetting the mixture adjustment ((8 Ser., G16), (2 Ser., F46), (7 Ser., G11), (X3, G01), (X4, G02), (4 Ser., G82), (5 Ser., G30), (5 Ser., G31), (6 Ser., G32), (8 Ser., G14), (8 Ser., G15), (X5, G05), (X7, G07))

Initializing the air distribution flaps ((X3, G01), (2 Ser., F46), (X2, F39), (7 Ser., G12), (7 Ser., G11), (5 Ser., G30), (5 Ser., G31), (X4, G02), (3 Ser., G20), (3 Ser., G21), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (6 Ser., G32), (X1, F48))

Resetting learned values of throttle valve actuator ((2 Ser., F45), (2 Ser., F46), (1 Ser., F40), (8 Ser., G16), (X2, F39), (7 Ser., G11), (X3, G01), (2 Ser., F44), (3 Ser., G20), (3 Ser., G21), (X4, G02), (Z4, G29), (4 Ser., G82), (5 Ser., G30), (5 Ser., G31), (6 Ser., G32), (8 Ser., G14), (8 Ser., G15), (X5, G05), (X7, G07))

Initializing the tilt/slide sunroof ((2 Ser., F46), (2 Ser., F44), (i8, I12), (X1, F48))



Diagnostic devices

Changing automatic transmission fluid ((X3, G01), (7 Ser., G12), (7 Ser., G11), (5 Ser., G30), (5 Ser., G31), (X4, G02), (3 Ser., G20), (3 Ser., G21), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (6 Ser., G32))

Configuring the head-up display ((X2, F39), (X1, F48))

Resetting the footwell module ECU ((1 Ser., 1C))

Adapt shifting speed regulation ((2 Ser., F46), (X2, F39), (3 Ser., G20), (3 Ser., G21), (X1, F48))

Resetting gearbox learning values ((X2, F39), (X1, F48))

Activating the axle alignment mode for self-steering rear axle ((8 Ser., G16), (7 Ser., G12), (7 Ser., G11), (5 Ser., G30), (5 Ser., G31), (3 Ser., G20), (3 Ser., G21), (4 Ser., G23), (4 Ser., G22), (8 Ser., G14), (8 Ser., G15))

Moving the air distribution flaps to service position ((X3, G01), (X5, G05), (8 Ser., G16), (7 Ser., G12), (7 Ser., G11), (2 Ser., F44), (3 Ser., G20), (3 Ser., G21), (5 Ser., G30), (5 Ser., G31), (X4, G02), (X6, G06), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (6 Ser., G32), (8 Ser., G14), (8 Ser., G15), (X7, G07))

Resetting the valve stroke adaptation initialization values ((1 Ser., F40), (8 Ser., G16), (2 Ser., F46), (X2, F39), (7 Ser., G11), (X3, G01), (2 Ser., F44), (3 Ser., G20), (3 Ser., G21), (X4, G02), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (5 Ser., G30), (5 Ser., G31), (6 Ser., G32), (8 Ser., G14), (8 Ser., G15), (X5, G05), (X7, G07))

Initializing the A/C flap actuators ((i8, I12))

Resetting gearbox learning values ((5 Ser., F10), (X5, G05), (8 Ser., G16), (3 Ser., G20), (3 Ser., G21), (X6, G06), (8 Ser., G14), (8 Ser., G15), (i8, I12), (X1, F48), (X7, G07))

Initialize minimum quantity deviation of the injectors ((5 Ser., G31), (5 Ser., G30), (1 Ser., F40), (2 Ser., F44), (X3, G01))

Initialize acceleration sensor ((2 Ser., F46), (3 Ser., G20), (3 Ser., G21), (X1, F48))

Resetting the quantity mean value adaptation ((X5, F15), (2 Ser., F46), (X2, F39), (1 Ser., 1C), (3 Ser., G20), (3 Ser., G21), (X1, F48))

Bleeding the brake system ((X3, G01), (X5, G05), (X7, G07), (1 Ser., F40), (8 Ser., G16), (X6, G06), (7 Ser., G12), (7 Ser., G11), (2 Ser., F44), (8 Ser., F92), (5 Ser., G30), (5 Ser., G31), (X4, G02), (3 Ser., G20), (3 Ser., G21), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (6 Ser., G32), (8 Ser., G15), (i8, I12), (iX3, G08), (X1, F48))

Configuring the lane change assist ((5 Ser., G31), (5 Ser., G30), (X3, G01), (5 Ser., F90), (X4, G02), (8 Ser., G15), (X5, G05), (8 Ser., G14), (X7, G07), (8 Ser., G16), (8 Ser., F91), (2 Ser., F44), (7 Ser., G12), (7 Ser., G11), (8 Ser., F92), (8 Ser., F93), (X6, G06), (3 Ser., G20), (3 Ser., G80), (3 Ser., G21), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (6 Ser., G32))

Actuating the assembly position of the EGR valve ((X5, F15), (1 Ser., F40), (X6, G06), (3 Ser., G20), (5 Ser., G31), (X3, G01), (X4, G02), (X5, G05), (2 Ser., F44), (2 Ser., F46), (3 Ser., G21), (5 Ser., G30), (6 Ser., G32), (7 Ser., G11), (X7, G07), (7 Ser., G12))

Initializing the variable valve lift ((1 Ser., F40), (8 Ser., G16), (2 Ser., F46), (X2, F39), (7 Ser., G12), (7 Ser., G11), (X3, G01), (2 Ser., F44), (3 Ser., G20), (3 Ser., G21), (X4, G02), (Z4, G29), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (5 Ser., G30), (5 Ser., G31), (6 Ser., G32), (8 Ser., G14), (8 Ser., G15), (X1, F48), (X5, G05), (X7, G07))

EMF workshop mode ((X1, F48))

De/activating the parking brake service mode ((X3, G01), (8 Ser., G16), (2 Ser., F46), (X2, F39), (5 Ser., G30), (5 Ser., G31), (X4, G02), (3 Ser., G20), (3 Ser., G21), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (6 Ser., G32), (8 Ser., G15), (i8, I12), (X1, F48))

Readdressing air distribution flaps ((2 Ser., F46), (X2, F39), (X1, F48))



Diagnostic devices

Resetting mass airflow sensor adaptation values ((X5, F15), (5 Ser., F10), (1 Ser., 1C))

Interchanged brake pipe check ((X3, G01), (8 Ser., G16), (2 Ser., F46), (X2, F39), (7 Ser., G12), (7 Ser., G11), (5 Ser., G30), (5 Ser., G31), (X4, G02), (3 Ser., G20), (3 Ser., G21), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (6 Ser., G32), (8 Ser., G14), (8 Ser., G15), (X1, F48))

Moving the exhaust back pressure flap actuator to assembly position ((3 Ser., G20), (X3, G01), (3 Ser., G21), (5 Ser., G30), (6 Ser., G32))

Resetting learned values of the transmission ECU ((X3, G01), (2 Ser., F46), (7 Ser., G12), (7 Ser., G11), (1 Ser., 1C), (5 Ser., G30), (5 Ser., G31), (X4, G02), (3 Ser., G20), (3 Ser., G21), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (6 Ser., G32))

Adapting the headlight motor ((2 Ser., F46), (X2, F39), (X1, F48))

Initializing the lateral acceleration sensor ((1 Ser., 1C))

Unlocking aux. heater/independent car heater ((2 Ser., F46), (X2, F39), (8 Ser., G14), (X1, F48))

Initializing pre-programmed keys ((2 Ser., F46), (X1, F48))

Initializing ride height sensors ((3 Ser., G20), (3 Ser., G21))

Resetting the transport mode ((X1, F48))

Resetting starter learning values ((5 Ser., G31), (5 Ser., G30), (8 Ser., G15), (3 Ser., G20), (Z4, G29), (X5, G05), (8 Ser., G14), (1 Ser., F40), (3 Ser., G21), (8 Ser., G16), (2 Ser., F46), (X2, F39), (X6, G06))

Activating the roller test stand mode ((X1, F48))

Initializing the SCR system ((5 Ser., F10), (X3, G01), (7 Ser., G12), (7 Ser., G11), (5 Ser., G30), (X4, G02), (3 Ser., G20), (3 Ser., G21), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (5 Ser., G31))

Activating the fuel pump ((4 Ser., F82), (4 Ser., F83), (1 Ser., F40), (2 Ser., F46), (X6, G06), (X2, F39), (7 Ser., G12), (3 Ser., G20), (3 Ser., G21), (5 Ser., G31), (7 Ser., G11), (X3, G01), (X4, G02), (X5, G05), (2 Ser., F44), (4 Ser., G23), (4 Ser., G22), (5 Ser., G30), (6 Ser., G32), (X1, F48), (X7, G07))

Reset equipment variant ((2 Ser., F46), (X2, F39), (3 Ser., G20), (3 Ser., G21), (X1, F48))

Resetting learned values of the induction system ((3 Ser., G20), (1 Ser., F40), (3 Ser., G21), (X6, G06), (2 Ser., F44))

Resetting EGR valve learning values ((X5, F15), (5 Ser., F10), (1 Ser., 1C), (5 Ser., G31), (X3, G01), (2 Ser., F46), (5 Ser., G30), (6 Ser., G32), (7 Ser., G12))

Initializing the valve stroke adaptation ((5 Ser., G31), (5 Ser., G30), (1 Ser., F40), (X2, F39), (2 Ser., F44), (3 Ser., G20), (3 Ser., G21), (4 Ser., G23), (4 Ser., G22))

Resetting the mixture adjustment ((1 Ser., F40), (X2, F39), (7 Ser., G12), (2 Ser., F44), (3 Ser., G20), (3 Ser., G21), (7 Ser., G11), (4 Ser., G23), (4 Ser., G22), (5 Ser., G30), (5 Ser., G31), (6 Ser., G32))

Resetting the pulse-generator ring adaptation ((3 Ser., G20), (1 Ser., F40), (3 Ser., G21), (8 Ser., G16), (2 Ser., F46), (X2, F39), (7 Ser., G12), (7 Ser., G11), (X3, G01), (2 Ser., F44), (5 Ser., G31), (X4, G02), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (5 Ser., G30), (6 Ser., G32), (8 Ser., G14), (8 Ser., G15), (X5, G05), (X7, G07))

Resetting the EGS oil change ((1 Ser., 1C))

Resetting learned values upon VTG oil change ((5 Ser., E61))

Draining/filling the refrigerant circuit ((X5, G05), (8 Ser., G16), (7 Ser., G12), (7 Ser., G11), (2 Ser., F44), (3 Ser., G20), (3 Ser., G21), (X6, G06), (8 Ser., G14), (8 Ser., G15))

Resetting the overhead control panel ECU ((1 Ser., 1C))



Diagnostic devices

Initializing the sunroof actuator ((X1, F48))

Calibrating the steering-angle sensor ((X2, F39), (X1, F48))

Resetting the start inhibitor of DEF injection system ((5 Ser., G31), (X3, G01), (X4, G02), (X5, G05), (3 Ser., G21), (5 Ser., G30), (6 Ser., G32), (X7, G07))

Learning the steering-angle sensor ((1 Ser., 1C))

Initializing the tilt/slide sunroof ((X3, G01), (7 Ser., G12), (7 Ser., G11), (5 Ser., G30), (5 Ser., G31), (X4, G02), (3 Ser., G20), (3 Ser., G21), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (6 Ser., G32))

Resetting transfer case adaptation values ((3 Ser., E92), (3 Ser., E90), (3 Ser., E91), (3 Ser., E93), (5 Ser., E60), (5 Ser., E61), (X3, G01), (X5, G05), (8 Ser., G16), (2 Ser., F46), (X2, F39), (3 Ser., G20), (3 Ser., G21), (5 Ser., G30), (5 Ser., G31), (X4, G02), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (6 Ser., G32), (8 Ser., G14), (8 Ser., G15), (X1, F48))

Resetting learned values of the DEF injection system ((X3, G01), (7 Ser., G12), (7 Ser., G11), (5 Ser., G30), (X4, G02), (2 Ser., F46), (3 Ser., G20), (3 Ser., G21), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (5 Ser., G31), (6 Ser., G32))

Adjusting the boost control rod ((5 Ser., G31), (5 Ser., G30), (1 Ser., F40), (8 Ser., G16), (2 Ser., F46), (X2, F39), (7 Ser., G11), (X3, G01), (2 Ser., F44), (3 Ser., G20), (3 Ser., G21), (X4, G02), (Z4, G02), (Z4, G29), (4 Ser., G82), (6 Ser., G32), (8 Ser., G14), (8 Ser., G15), (i8, I12), (X1, F48), (X5, G05), (X7, G07))

Setting vehicle into sleep mode ((X3, G01), (X5, G05), (8 Ser., G16), (2 Ser., F46), (X2, F39), (7 Ser., G12), (7 Ser., G11), (3 Ser., G20), (3 Ser., G21), (5 Ser., G30), (5 Ser., G31), (X4, G02), (Z4, G29), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (6 Ser., G32), (8 Ser., G14), (8 Ser., G15), (i8, I12), (X1, F48), (X7, G07))

Initializing the brake-pressure sensor ((1 Ser., 1C))

Adapting the induction system ((5 Ser., G31), (X3, G01), (X4, G02), (X5, G05), (2 Ser., F46), (3 Ser., G21), (5 Ser., G30), (6 Ser., G32), (7 Ser., G11), (X7, G07), (7 Ser., G12))

Adapting the exhaust gas flap actuator ((5 Ser., G30))

Calibrating the radar sensor ((X3, G01), (X5, G05), (8 Ser., G16), (X2, F39), (7 Ser., G12), (7 Ser., G11), (2 Ser., F44), (3 Ser., G20), (3 Ser., G21), (5 Ser., G30), (5 Ser., G31), (X4, G02), (X6, G06), (Z4, G06), (Z4, G29), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (6 Ser., G32), (8 Ser., G14), (8 Ser., G15), (X1, F48), (X7, G07))

Resetting the swirl flap adaptation values ((X5, F15), (5 Ser., F10))

Calibrating the front camera ((X3, G01), (X5, G05), (8 Ser., G16), (X2, F39), (7 Ser., G12), (7 Ser., G11), (3 Ser., G20), (3 Ser., G21), (5 Ser., G30), (5 Ser., G31), (X4, G02), (X6, G06), (Z4, G29), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (6 Ser., G32), (8 Ser., G14), (8 Ser., G15), (X1, F48))

Learning the steering-angle sensor ((5 Ser., F10))

De-energizing the hybrid/electric vehicle ((i8, I12))

Taking the DEF tank system into operation ((2 Ser., F45), (2 Ser., F46), (X1, F48), (5 Ser., G31), (5 Ser., G30), (X3, G01), (X2, F39), (6 Ser., G32), (X4, G02), (8 Ser., G15), (X5, G05), (3 Ser., G20), (8 Ser., G14), (X7, G07), (1 Ser., F40), (3 Ser., G21), (8 Ser., G16), (X6, G06), (2 Ser., F44), (4 Ser., G22), (4 Ser., G23))

Resetting the error counter of the steering column locking ((1 Ser., 1C))

Calibrating the rearview camera/all-round vision camera ((X3, G01), (X5, G05), (8 Ser., G16), (2 Ser., F46), (X2, F39), (7 Ser., G12), (7 Ser., G11), (2 Ser., F44), (5 Ser., G30), (5 Ser., G31), (X4, G02), (X6, G06), (3 Ser., G20), (3 Ser., G21), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (6 Ser., G32), (8 Ser., G14), (8 Ser., G15), (i8, I12), (X1, F48), (X7, G07))



Diagnostic devices

Special bleeding ((X1, F48))

Resetting differential pressure sensor learning values ((2 Ser., F45), (2 Ser., F46), (X1, F48), (3 Ser., F34), (5 Ser., G31), (5 Ser., G30), (X2, F39), (3 Ser., G20), (X5, G05), (X7, G07), (1 Ser., F40), (3 Ser., G21), (X6, G06), (2 Ser., F44))

Codings

Coding injectors ((3 Ser., G20), (Z4, G29), (1 Ser., F40), (3 Ser., G21), (2 Ser., F46), (1 Ser., 1C), (2 Ser., F44), (5 Ser., G31), (X3, G01), (X4, G02), (X5, G05), (5 Ser., G30), (6 Ser., G32), (7 Ser., G11), (i8, I12), (X1, F48), (X7, G07), (7 Ser., G12))

Deactivating/activating the transport mode ((7 Ser., G12), (7 Ser., G11), (5 Ser., G30), (5 Ser., G31), (X4, G02), (3 Ser., G20), (3 Ser., G21), (4 Ser., G23), (4 Ser., G22))

Coding the idle rpm ((X3, G01), (8 Ser., G16), (2 Ser., F46), (X6, G06), (X2, F39), (7 Ser., G12), (7 Ser., G11), (1 Ser., 1C), (5 Ser., G31), (X4, G02), (X5, G05), (3 Ser., G20), (3 Ser., G21), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (5 Ser., G30), (6 Ser., G32), (8 Ser., G14), (8 Ser., G15), (i8, I12), (X1, F48), (X7, G07))

Coding the radio remote control ((1 Ser., 1C))

Registering the battery ((X3, G01), (X5, G05), (1 Ser., F40), (8 Ser., G16), (2 Ser., F46), (X2, F39), (7 Ser., G12), (7 Ser., G11), (1 Ser., 1C), (3 Ser., G20), (3 Ser., G21), (5 Ser., G30), (5 Ser., G31), (X4, G02), (X6, G06), (Z4, G29), (4 Ser., G23), (4 Ser., G22), (4 Ser., G82), (6 Ser., G32), (8 Ser., G14), (8 Ser., G15), (i8, I12), (X1, F48), (X7, G07))

Deactivating the transport mode ((X3, G01), (4 Ser., G82), (6 Ser., G32))

Service resets

(1 Ser., 1C), (2 Ser., F44), (2 Ser., F46), (3 Ser., G20), (3 Ser., G21), (4 Ser., G22), (4 Ser., G23), (4 Ser., G82), (5 Ser., G30), (5 Ser., G31), (6 Ser., G32), (7 Ser., G11), (7 Ser., G12), (8 Ser., G14), (8 Ser., G15), (8 Ser., G16), (i8, I12), (X1, F48), (X2, F39), (X3, G01), (X4, G02), (X5, G05), (X6, G06), (X7, G07), (Z4, G29)

Citroen

Trouble codes (Berlingo-III, 7), (Berlingo-IV, E), (C4, B), (C4 Picasso, U)

Parameters (Berlingo-III, 7), (Berlingo-IV, E), (C4, B)

Actuators (Berlingo-III, 7), (Berlingo-IV, E), (C4, B)

Basic settings Resetting battery monitoring data ((C5 Aircross, A))

Adapting the longitudinal acceleration sensor ((C4, B))

Initializing the rain/light sensor ((Berlingo-IV, E), (C4, B))

Draining the cooling system ((Berlingo-IV, E))

Adapting the clutch biting point ((C4, B))

Initializing the forward collision warning system ((Berlingo-IV, E))

Locking the airbag ECU ((Berlingo-IV, E))

Bleeding the oil pump ((C4, B))

Reactivating the emergency brake assistant ((SpaceTourer, V), (C3 Aircross, None), (Berlingo-IV, E), (C4 Cactus-II, 0), (C5 Aircross, A), (C4, B))

Adapting crankshaft sensor ((C5 Aircross, A), (C4, B))



Diagnostic devices

- Deactivating the torque limitation ((C5 Aircross, A))
- Cleaning/replacing the soot particulate filter ((C5 Aircross, A), (C4, B))
- Initializing the differential pressure sensor ((C5 Aircross, A), (C4, B))
- De-calibrating the longitudinal/lateral acceleration sensor ((Jumper-IV, Y (EU6)))
- Calibrating the steering-angle sensor ((Berlingo-IV, E))
- Self-adaptation of A/C system ((C4, B))
- Reconnecting the battery ((C4, B))
- Learning the turbocharger ((C5 Aircross, A))
- Learning the throttle valve ((C4, B))
- Resetting the counter of fragrance cartridge block ((C4, B))
- Reset learned values of injectors. ((C4, B))
- Resetting the clutch counter ((C5 Aircross, A))
- Resetting gearbox learning values ((C4, N), (C-Elysee, D))
- Replace brake parts ((Berlingo-IV, E), (C4, B))
- Unlocking the airbag ECU ((Berlingo-IV, E))
- Adapting the longitudinal acceleration sensor ((Berlingo-IV, E))
- Replacing engine parts ((C5 Aircross, A))
- Replace the battery. ((C4, B))
- Initializing the A/C flap actuators ((Berlingo-IV, E))
- Calibrating the radar sensor ((C4, B))
- Bleeding the brake system ((C4, B))
- Reducing fuel high pressure ((C4, B))
- Initializing the longitudinal/lateral acceleration sensor ((Jumper-IV, Y (EU6)))
- Initializing the fuel level ((Berlingo-IV, E), (C4, B))
- Calibrating the front camera ((C1, P), (Berlingo-IV, E))
- Initializing the alternator ((C4, B))
- Adapting the radiator shutter ((C5 Aircross, A), (C4, B))
- Bleeding the ABS/ESC system ((Berlingo-IV, E))
- Leaving the ECO mode ((Berlingo-IV, E), (C4, B))
- Bleeding the cooling system ((Berlingo-IV, E))
- Adapting the variable camshaft timing ((C4, B))
- Calibrating the camera ECU ((C4, B))
- Activating the start/stop function ((C5 Aircross, A), (C4, B))
- Filling the cooling system ((Berlingo-IV, E))
- Regenerating the soot particulate filter at standstill ((C5 Aircross, A), (C4, B))
- Replace the piston ((C4, B))



Diagnostic devices

Coding the keys ((Berlingo-IV, E), (C4, B))
Registering the battery ((Berlingo-IV, E))
Locking the airbag ECU ((C4, B))
Coding the remote control ((C4, B))
Deactivating/activating the transport mode ((C4, B))
Unlocking the airbag ECU ((C4, B))
Synchronisation of the remote control ((Berlingo-IV, E))
Coding injectors ((Berlingo-III, 7), (Jumper-IV, Y (EU6)))
Coding the alarm sound ((Berlingo-IV, E), (C4, B))

Service resets (Berlingo-IV, E), (C4, B), (Jumper-IV, Y (EU6))

Cupra

Trouble codes (Ateca, KH), (Born, K1), (Formentor, KM), (Leon, KL)
Parameters (Ateca, KH), (Born, K1), (Formentor, KM), (Leon, KL)
Actuators (Ateca, KH), (Born, K1), (Formentor, KM), (Leon, KL)
Basic settings Initializing electric seats ((Leon, KL), (Born, K1), (Formentor, KM))
Initializing the adaptive cruise control ((Born, K1), (Ateca, KH))
Filling fuel lines of parking heater/auxiliary heater ((Leon, KL), (Formentor, KM), (Ateca, KH))
Resetting the start inhibitor of DEF injection system ((Formentor, KM))
Regenerating the soot particulate filter ((Formentor, KM), (Leon, KL), (Ateca, KH))
Resetting engine adaptation values ((Formentor, KM), (Leon, KL), (Ateca, KH))
Initializing the ESC sensors ((Formentor, KM), (Ateca, KH))
Adapting the electronic damper control ((Born, K1), (Formentor, KM), (Leon, KL), (Ateca, KH))
Bleeding the fuel system ((Formentor, KM))
Burning off aux. heater/independent car heater ((Formentor, KM), (Leon, KL), (Ateca, KH))
Performing transmission adaptations ((Formentor, KM), (Leon, KL), (Ateca, KH))
Initializing the seat belt tensioner ECU ((Ateca, KH))
Initializing the tilt/slide sunroof ((Formentor, KM), (Leon, KL), (Ateca, KH))
Standardizing the liftgate ((Formentor, KM))
Initialize actuator of coolant temperature control ((Leon, KL), (Ateca, KH))
Adapting the soot particulate filter ((Formentor, KM), (Leon, KL), (Ateca, KH))
Learning the steering-angle sensor ((Born, K1), (Formentor, KM), (Leon, KL))
Learning the throttle valve ((Leon, KL), (Ateca, KH))



Diagnostic devices

Learning the steering-angle sensor ((Ateca, KH))
Performing engine adaptations ((Formentor, KM))
Initializing the brake-pressure sensor ((Formentor, KM), (Ateca, KH))
Initializing the boost pressure regulator ((Leon, KL), (Ateca, KH))
Initializing the adaptive cruise control ((Leon, KL), (Formentor, KM))
Performing the initial run-in of the air conditioning compressor ((Formentor, KM), (Leon, KL), (Ateca, KH))
Retracting parking brake ((Formentor, KM), (Born, K1), (Ateca, KH))
Initializing the clutch pedal position ((Ateca, KH))
Reducing fuel high pressure ((Leon, KL), (Ateca, KH))
Initializing the A/C flap actuators ((Born, K1), (Formentor, KM), (Leon, KL), (Ateca, KH))
Initializing the alternator ((Ateca, KH))
Activating the retrofitted parking heater ((Formentor, KM), (Leon, KL), (Ateca, KH))
Initializing the oxidation catalyst ((Formentor, KM))
Initialize 4WD clutch oil pump ((Ateca, KH))
Resetting timing chain adaptation values ((Leon, KL), (Ateca, KH))
Resetting the impact mode ((Ateca, KH))
Initializing the neutral position sensor ((Leon, KL), (Ateca, KH))
Resetting the diesel exhaust fluid level ((Formentor, KM))
Adjust headlight with/without dynamic light control (DLA) ((Ateca, KH))
Calibrating the parking brake ((Formentor, KM))
Adjusting the headlights ((Leon, KL), (Formentor, KM))
Adapting oil pressure for engine run-in ((Formentor, KM))
Bleeding the cooling system ((Formentor, KM), (Leon, KL), (Ateca, KH))
Calibrating the camera ECU ((Formentor, KM), (Born, K1), (Leon, KL), (Ateca, KH))
Adapting the fuel burning heater remote control ((Formentor, KM), (Leon, KL), (Ateca, KH))
Extending parking brake ((Formentor, KM), (Born, K1), (Ateca, KH))
Unlocking aux. heater/independent car heater ((Formentor, KM), (Leon, KL), (Ateca, KH))
Calibrating the parking brake ((Ateca, KH))
Activating the roller test stand mode ((Formentor, KM))

Codings

Adjust parking assistance volume ((Formentor, KM), (Leon, KL), (Ateca, KH))
General ECU replacement ((Ateca, KH))
Coding the language version ((Ateca, KH))
Registering the battery ((Formentor, KM), (Ateca, KH))
Expert mode ECU coding ((Ateca, KH))
Coding the rain/light sensor ((Born, K1), (Formentor, KM), (Leon, KL), (Ateca, KH))
Deactivating/activating the transport mode ((Formentor, KM), (Ateca, KH))



Diagnostic devices

Coding the trailer detection ((Born, K1), (Formentor, KM), (Leon, KL), (Ateca, KH))

Coding the steering-column module ((Ateca, KH))

Adapting the trailer hitch to advanced driver assistance systems ((Ateca, KH))

Coding injectors ((Formentor, KM))

De/activating the trailer hitch ((Formentor, KM), (Ateca, KH))

Coding the gateway installation list ((Ateca, KH))

| **Service resets** (Ateca, KH), (Born, K1), (Formentor, KM), (Leon, KL)

Dacia

| **Trouble codes** (Duster-III, HMMA), (Lodgy, SD), (Logan-II, SD), (Sandero-II, SD)

| **Parameters** (Duster-III, HMMA), (Lodgy, SD), (Logan-II, SD), (Sandero-II, SD)

| **Actuators** (Duster-III, HMMT), (Lodgy, SD), (Logan-II, SD), (Sandero-II, SD)

| **Basic settings** Learning the flywheel ((Duster-II, HSDA), (Duster-II, HSAU))
Resetting the mixture adjustment ((Duster-II, HSDA), (Duster-II, HSAU))
Calibrating the steering-angle sensor ((Logan-II, SD), (Logan-II,), (Sandero-II, SD))
Learning the steering-angle sensor ((Duster-III, HMMT), (Duster-III, HMMF), (Duster-III, HMM3))

Learning the throttle valve ((Dokker, 0SDTV), (Dokker, 0SD), (Lodgy, JSDC), (Lodgy, JSDM), (Dokker, 0SDCV), (Dokker, 0ES), (Dokker, 0ESNB), (Dokker, 0EVNB,0ESNB), (Lodgy, JSNB, JESNB), (Lodgy, JSNB))

Learning the steering-angle sensor ((Lodgy, SD))

Bleeding the ABS hydraulic unit ((Duster-III, HMMT), (Duster-III, HMMF), (Duster-III, HMM3), (Logan-II, SD), (Logan-II,), (Sandero-II, SD))

Resetting learned values of steering angle sensor ((Logan-II, SD), (Logan-II,), (Sandero-II, SD))

Initializing the boost pressure regulator ((Duster-II, HSDA), (Duster-II, HSAU))

| **Codings** Coding the tire size ((Lodgy, SD), (Logan-II, SD), (Logan-II,), (Sandero-II, SD))

Coding the language version ((Duster-III, HMMT), (Duster-III, HMMF), (Duster-III, HMM3), (Lodgy, SD), (Logan-II, SD), (Logan-II,), (Sandero-II, SD))

Airbag ECU locking/unlocking ((Duster-III, HMMT), (Duster-III, HMMF), (Duster-III, HMM3))

Unlocking the airbag ECU ((Lodgy, SD), (Logan-II, SD), (Logan-II,), (Sandero-II, SD))

Locking the airbag ECU ((Lodgy, SD), (Logan-II, SD), (Logan-II,), (Sandero-II, SD))

| **Service resets** (Lodgy, SD), (Logan-II, SD), (Sandero-II, SD)



Diagnostic devices

Fiat

- | **Trouble codes** (500L (330), 330), (Tipo (356), 356)
- | **Parameters** (500L (330), 330)
- | **Actuators**
- | **Basic settings**
- | **Codings**
- | **Service resets**

Ford

- | **Trouble codes** (C-Max 04, DXA), (Fiesta 08, JJH), (Fusion, JU2), (Mondeo 05, BA7)
- | **Parameters** (C-Max 04, DXA), (Fiesta 08, JJH), (Focus 06, HP), (Fusion, JU2), (Kuga 03, DFK), (Mondeo 05, BA7), (Mustang Mach-E, LSK), (Tourneo Connect 03, PJ2)
- | **Actuators** (Fusion, JU2)
- | **Basic settings**
 - Adapting the longitudinal acceleration sensor ((Mondeo 05, BA7))
 - Activating the tire pressure sensors ((Fiesta 08, JJH), (Mondeo 05, BA7), (Fiesta 08, JHH), (Fiesta 08, JGH), (C-Max 04, DXA))
 - Resetting engine adaptation values ((Fiesta 07, JA8), (Fiesta 08, JJH), (Mondeo 05, BA7), (Fiesta 08, JHH))
 - Resetting the intake manifold flap learning values ((Mondeo 05, BA7), (C-Max 04, DXA))
 - Resetting EGR valve learning values ((C-Max 04, DXA))
 - Adapting crankshaft sensor ((Transit 10, FED, FFD), (Transit 10, FAD, FBD), (Transit 10, FCD, FDD), (Transit 10, FCD), (Transit 10, FFD), (Transit 10, FED), (Transit 10, FDD), (Transit 10, SX), (Transit 10, 81), (Transit 10, SXS), (Transit 10, FCC))
 - Resetting radiator fan learning values ((C-Max 04, DXA))
 - Initialize tire pressure sensors ((Fiesta 08, JJH), (Mondeo 05, BA7), (Fiesta 08, JHH), (Fiesta 08, JGH), (C-Max 04, DXA))
 - Resetting the indicator light "Water in fuel" ((Mondeo 05, BA7))
 - Resetting oxygen sensor adaptation values ((Mondeo 05, BA7))
 - Initializing the fuel high-pressure sensor ((Mondeo 05, BA7), (C-Max 04, DXA))
 - Resetting the exhaust temperature values ((Mondeo 05, BA7))
 - Resetting the particulate filter learning values ((C-Max 04, DXA))
 - Resetting the fuel low pressure adaptation values ((Transit 10, FED, FFD), (Transit 10, FAD, FBD), (Transit 10, FCD, FDD), (Transit 10, FCD), (Transit 10, FFD), (Transit 10, FED), (Transit 10, FDD), (Transit 10, SX), (Transit 10, 81), (Transit 10, SXS), (Transit 10, FCC), (C-Max 04, DXA))



Diagnostic devices

- Teach-in battery sensor module ((Fiesta 08, JJH), (Mondeo 05, BA7), (Fiesta 08, JHH), (Fiesta 08, JGH), (C-Max 04, DXA))
- Correcting straight-running stability ((C-Max 04, DXA))
- Calibrating the steering wheel position sensor ((C-Max 04, DXA))
- Initializing the mass airflow sensor ((Mondeo 05, BA7))
- Calibrating the steering-angle sensor ((C-Max 04, DXA))
- Resetting learned values of the interface module ((Fiesta 08, JJH), (Fiesta 08, JHH), (Fiesta 08, JGH))
- Initializing the tilt/slide sunroof ((Mondeo 05, BA7), (C-Max 04, DXA))
- Resetting learned values of NOx sensor ((C-Max 04, DXA))
- Regenerating the soot particulate filter ((Mondeo 05, BA7), (C-Max 04, DXA))
- Resetting misfire and knock counter ((S-Max 02, WA6), (Galaxy 04, WA6))
- Initializing the brake-pressure sensor ((C-Max 04, DXA))
- Resetting exhaust-gas temperature sensor adaptation values of soot particulate filter ((Transit 10, FED, FFD), (Transit 10, FAD, FBD), (Transit 10, FCD, FDD), (Transit 10, FCD), (Transit 10, FFD), (Transit 10, FED), (Transit 10, FDD), (Transit 10, SX), (Transit 10, 81), (Transit 10, SXS), (Transit 10, FCC))
- Reset learned values of injectors. ((Transit 10, FED, FFD), (Transit 10, FAD, FBD), (Transit 10, FCD, FDD), (Transit 10, FCD), (Transit 10, FFD), (Transit 10, FED), (Transit 10, FDD), (Transit 10, SX), (Transit 10, 81), (Transit 10, SXS), (Transit 10, FCC), (Mondeo 05, BA7), (C-Max 04, DXA))
- Calibrating the lane departure warning system camera ((Fiesta 08, JJH), (Fiesta 08, JHH), (Fiesta 08, JGH), (C-Max 04, DXA))
- Resetting rail pressure ((C-Max 04, DXA))
- Resetting mass airflow sensor adaptation values ((C-Max 04, DXA))
- Resetting the turbocharger upon cleaning ((C-Max 04, DXA))
- Initializing the forward collision warning system ((Mondeo 05, BA7), (C-Max 04, DXA))
- Initializing the adaptive cruise control ((Fiesta 08, JJH), (Mondeo 05, BA7), (Fiesta 08, JHH), (Fiesta 08, JGH))
- Resetting ECM engine learning values ((C-Max 04, DXA))
- Initializing the lateral acceleration sensor ((C-Max 04, DXA))
- Cleaning the turbocharger ((Transit 10, FED, FFD), (Transit 10, FAD, FBD), (Transit 10, FCD, FDD), (Transit 10, FCD), (Transit 10, FFD), (Transit 10, FED), (Transit 10, FDD), (Transit 10, SX), (Transit 10, 81), (Transit 10, SXS), (Transit 10, FCC))
- Resetting differential pressure sensor learning values ((Mondeo 05, BA7), (C-Max 04, DXA))
- Resetting adaptation values of ABS ECU ((C-Max 04, DXA))
- De-energizing the vehicle ((Mustang Mach-E, LSK))
- Standardizing the liftgate ((Mondeo 05, BA7), (C-Max 04, DXA))
- Resetting EGR valve learning values ((Mondeo 05, BA7))
- Calibrating the front camera ((Mondeo 05, BA7))
- Adapting the radiator shutter ((C-Max 04, DXA))
- De/activating the parking brake service mode ((Mondeo 05, BA7))



Diagnostic devices

Learning the power windows ((C-Max 04, DXA))
Resetting the variable turbocharger adaptation values ((Mondeo 05, BA7), (C-Max 04, DXA))
Bleeding the ABS/ESC system ((C-Max 04, DXA))
Learning the power windows ((Mondeo 05, BA7))
Initializing the SCR system ((C-Max 04, DXA))
Adapting the longitudinal acceleration sensor ((C-Max 04, DXA))
Resetting differential pressure sensor learning values ((C-Max 04, DXA))
Resetting the soot particulate filter ((Mondeo 05, BA7))
Calibrating the parking brake ((Mondeo 05, BA7))

Codings Coding injectors ((Mondeo 05, BA7), (C-Max 04, DXA))

Service resets (C-Max 04, DXA), (Mondeo 05, BA7)

Honda

Trouble codes (Civic, FK), (CR-V, RE)

Parameters (Civic, FK), (CR-V, RE)

Actuators (CR-V, RE)

Basic settings Initializing lateral/longitudinal/rotation acceleration sensor ((CR-V, RE))
Resetting learned values of emergency brake assist ((Civic, FK))
Calibrating the camera ECU ((Civic, FK), (CR-V, RE))
Resetting battery discharging current values ((Civic, FK), (CR-V, RE))
Initializing the electronic stability control sensors ((Civic, FK))
Actuating the installation/removal position of the parking brake ((Civic, FK))
Learning the steering-angle sensor ((CR-V, RE))
Calibrating radar statically ((Civic, FK), (CR-V, RE))

Codings Coding the tire size ((CR-V, RE))

Service resets (CR-V, RE)

Hyundai

Trouble codes (Elantra, MD), (i30 / i30cw, GD), (i30 / i30cw, PD), (Matrix, FC), (Tucson, NX)

Parameters (Elantra, MD), (i20, PB), (i30 / i30cw, GD), (i30 / i30cw, PD), (Matrix, FC), (Tucson, NX)

Actuators (Elantra, MD), (i30 / i30cw, GD), (i30 / i30cw, PD), (Matrix, FC)



Diagnostic devices

Basic settings	Resetting transfer case adaptation values ((i30 / i30cw, PD)) Resetting engine adaptation values ((i30 / i30cw, PD)) Initializing the ABS/ESC system ((Elantra, MD)) Gearbox bleeding ((i30 / i30cw, PD)) Learning the throttle valve ((H350, EU(V)), (H350, EU(B)), (H350, EU)) Initializing the fuel high-pressure sensor ((Elantra, MD)) Initializing the differential pressure sensor ((H350, EU(V)), (H350, EU(B)), (H350, EU), (Elantra, MD)) Replacing the lambda probe ((Elantra, MD)) Resetting self-adaptation parameters ((i30 / i30cw, PD)) Initializing the mass airflow sensor ((H350, EU(V)), (H350, EU(B)), (H350, EU), (Elantra, MD)) Learning the turbocharger ((H350, EU(V)), (H350, EU(B)), (H350, EU)) Calibrating the steering-angle sensor ((i30 / i30cw, PD)) Learning the steering-angle sensor ((i30 / i30cw, PD)) Learning the steering-angle sensor ((Elantra, MD)) Adapting the longitudinal acceleration sensor ((i30 / i30cw, PD)) Regenerating the soot particulate filter ((Elantra, MD), (i30 / i30cw, PD)) Bleeding the ABS/ESC system ((i30 / i30cw, GD)) Calibrating radar statically ((i30 / i30cw, PD), (Kona, OS)) Initializing the high-pressure fuel pump ((H350, EU(V)), (H350, EU(B)), (H350, EU)) Resetting the ECU ((i30 / i30cw, PD)) Bleeding the brake system ((i30 / i30cw, PD)) Resetting the swirl flap adaptation values ((Elantra, MD)) Resetting EGR valve learning values ((Elantra, MD)) De/activating the parking brake service mode ((i30 / i30cw, PD)) Resetting throttle valve adaptation values ((Elantra, MD)) Replacing the particle filter ((H350, EU(V)), (H350, EU(B)), (H350, EU), (Elantra, MD)) Calibrating the camera ECU ((i30 / i30cw, PD)) Initializing the EGR valve ((H350, EU(V)), (H350, EU(B)), (H350, EU)) Bleeding the ABS hydraulic unit ((Elantra, MD), (Matrix, FC)) Learning the steering-angle sensor ((i30 / i30cw, PD))
Codings	Initializing the radar unit of distance warning system ((Tucson, TL), (Ioniq, AE HEV), (Ioniq, AE EV), (i30 / i30cw, PD), (Kona, OS), (Ioniq, AE)) Coding the remote control ((Elantra, MD)) Coding injectors ((Elantra, MD)) Coding the wheel valves ((i30 / i30cw, PD), (Elantra, MD))
Service resets	(i30 / i30cw, PD)



Diagnostic devices

Jeep

Trouble codes	(Cherokee,), (Cherokee, KL), (Commander, XK,XH), (Compass (MP), MP), (Grand Cherokee, EK,WK2), (Grand Cherokee, WK,WK2), (Patriot, PK)
Parameters	(Cherokee,), (Cherokee, KL), (Commander, XK,XH), (Compass (MP), MP), (Grand Cherokee, EK,WK2), (Grand Cherokee, WK,WK2), (Patriot, PK)
Actuators	(Cherokee,), (Cherokee, KL), (Commander, XK,XH), (Grand Cherokee, EK,WK2), (Grand Cherokee, WK,WK2), (Patriot, PK)
Basic settings	<p>Resetting learned values of diesel exhaust fluid pump ((Grand Cherokee, WK,WK2))</p> <p>Initializing the adaptive cruise control ((Compass (MP), MP))</p> <p>Initializing the soot particulate filter upon replacement ((Patriot, PK))</p> <p>Resetting the gearshift counter ((Cherokee, KL), (Cherokee,))</p> <p>Adjusting the headlights ((Grand Cherokee, WK,WK2), (Grand Cherokee, EK,WK2), (Grand Cherokee, Wk,WK2))</p> <p>Resetting engine adaptation values ((Compass (MP), MP))</p> <p>Initializing the ESC sensors ((Grand Cherokee, WK,WK2), (Grand Cherokee, EK,WK2), (Grand Cherokee, Wk,WK2))</p> <p>Resetting learned values of fuel quantity ((Cherokee, KL), (Cherokee,))</p> <p>Replacing the fuel pre-supply pump ((Patriot, PK))</p> <p>Cleaning the oil control valve ((Cherokee, KL), (Grand Cherokee, WK,WK2), (Grand Cherokee, Wk,WK2))</p> <p>Resetting learned values of NOx adsorption catalyst ((Grand Cherokee, WK,WK2))</p> <p>Reset learned values of injectors. ((Cherokee, KL), (Cherokee,))</p> <p>Gearbox bleeding ((Cherokee, KL), (Cherokee,))</p> <p>Resetting oxygen sensor adaptation values ((Grand Cherokee, WK,WK2))</p> <p>Initializing the yaw rate sensor ((Cherokee, KL), (Cherokee,))</p> <p>Replacing the lambda probe ((Cherokee, KL), (Cherokee,))</p> <p>ECU reset ((Cherokee, KL), (Cherokee,))</p> <p>Initializing minimum injection quantity ((Patriot, PK))</p> <p>Learning the lambda sensor ((Grand Cherokee, WK,WK2))</p> <p>Standardizing the liftgate ((Cherokee, KL), (Cherokee,))</p> <p>Emptying/filling the diesel exhaust fluid tank ((Grand Cherokee, WK,WK2))</p> <p>Learning the injection valve ((Compass (MP), MP))</p> <p>Initializing the boost pressure regulator ((Patriot, PK))</p> <p>Learning the throttle valve ((Cherokee, KL), (Grand Cherokee, WK,WK2), (Grand Cherokee, Wk,WK2))</p> <p>Replace the oxidation catalyst. ((Cherokee, KL), (Cherokee,))</p> <p>Learning the steering-angle sensor ((Cherokee, KL), (Cherokee,))</p> <p>Resetting the particulate filter learning values ((Grand Cherokee, WK,WK2))</p>



Diagnostic devices

- Reset learning values ((Cherokee, KL))
- Resetting learned values of the oxidation catalyst ((Grand Cherokee, WK,WK2))
- Regenerating the soot particulate filter ((Cherokee, KL), (Cherokee,), (Grand Cherokee, WK,WK2), (Patriot, PK))
- Initializing the brake-pressure sensor ((Grand Cherokee, WK,WK2), (Grand Cherokee, EK,WK2), (Grand Cherokee, Wk,WK2))
- Resetting adaptation values of the electrohydraulic valve control system ((Compass (MP), MP))
- Resetting gearbox learning values ((Cherokee, KL), (Cherokee,), (Grand Cherokee, WK,WK2), (Patriot, PK), (Grand Cherokee, EK,WK2), (Grand Cherokee, Wk,WK2))
- Resetting gearbox learning values ((Grand Cherokee, WK,WK2))
- Initializing the engine ECU ((Grand Cherokee, WK,WK2), (Grand Cherokee, Wk,WK2))
- Resetting learned values of emission-relevant components ((Cherokee, KL), (Cherokee,), (Grand Cherokee, WK,WK2))
- Initializing the crankshaft position sensor ((Cherokee, KL), (Grand Cherokee, WK,WK2), (Grand Cherokee, Wk,WK2))
- Solenoid valve test ((Cherokee, KL), (Cherokee,))
- Initializing the regeneration additive dosing module ((Grand Cherokee, WK,WK2))
- Replacing the regeneration additive container ((Grand Cherokee, WK,WK2))
- Resetting mass airflow sensor adaptation values ((Grand Cherokee, WK,WK2))
- Resetting transfer case adaptation values ((Grand Cherokee, WK,WK2), (Grand Cherokee, EK,WK2), (Grand Cherokee, Wk,WK2))
- Resetting differential pressure sensor learning values ((Grand Cherokee, WK,WK2))
- Initializing the A/C flap actuators ((Grand Cherokee, WK,WK2), (Grand Cherokee, EK,WK2), (Grand Cherokee, Wk,WK2))
- Initializing crankshaft/camshaft position ((Compass (MP), MP))
- Initializing the swirl flap ((Patriot, PK))
- Learning the throttle valve ((Grand Cherokee, WK,WK2))
- Resetting learned values of high beam assist ((Commander, XK,XH), (Grand Cherokee, WK,WK2), (Grand Cherokee, EK,WK2), (Grand Cherokee, Wk,WK2))
- Standardizing the liftgate ((Grand Cherokee, WK,WK2), (Grand Cherokee, EK,WK2), (Grand Cherokee, Wk,WK2))
- Resetting EGR valve learning values ((Patriot, PK))
- Calibrating the front camera ((Cherokee, KL), (Cherokee,), (Grand Cherokee, WK,WK2), (Grand Cherokee, EK,WK2), (Grand Cherokee, Wk,WK2))
- Resetting transfer case adaptation values ((Grand Cherokee, WK,WK2), (Grand Cherokee, EK,WK2), (Grand Cherokee, Wk,WK2))
- Resetting learned values of NOx sensor ((Grand Cherokee, WK,WK2))
- Bleeding the ABS/ESC system ((Commander, XK,XH), (Grand Cherokee, WK,WK2), (Grand Cherokee, EK,WK2), (Grand Cherokee, Wk,WK2))
- Readdressing air distribution flaps ((Cherokee, KL), (Cherokee,))
- De/activating the parking brake service mode ((Cherokee, KL), (Cherokee,))



Diagnostic devices

- Bleeding the cooling system ((Patriot, PK))
- Resetting mass airflow sensor adaptation values ((Cherokee, KL), (Cherokee,))
- Replacing the particle filter ((Cherokee, KL), (Cherokee,))
- Calibrating the camera ECU ((Compass (MP), MP))
- Regenerating the soot particulate filter during driving ((Grand Cherokee, WK,WK2))
- Calibrating the tire pressure monitoring system manually ((Grand Cherokee, WK,WK2), (Grand Cherokee, EK,WK2), (Grand Cherokee, Wk,WK2))
- Replacing the differential pressure sensor ((Cherokee, KL), (Cherokee,))
- Resetting headlight leveling adaptation values ((Cherokee, KL), (Cherokee,))
- Initializing the neutral position sensor ((Cherokee, KL), (Cherokee,))

Codings	Configuring the gateway ((Commander, XK,XH), (Grand Cherokee, WK,WK2), (Patriot, PK), (Grand Cherokee, EK,WK2), (Grand Cherokee, Wk,WK2)) Coding the language version ((Commander, XK,XH), (Grand Cherokee, WK,WK2), (Patriot, PK), (Grand Cherokee, EK,WK2), (Grand Cherokee, Wk,WK2)) Coding instrument cluster units ((Commander, XK,XH), (Grand Cherokee, WK,WK2), (Patriot, PK), (Grand Cherokee, EK,WK2), (Grand Cherokee, Wk,WK2)) Coding the tire pressure check ((Commander, XK,XH), (Cherokee, KL), (Cherokee,), (Grand Cherokee, WK,WK2), (Patriot, PK), (Grand Cherokee, EK,WK2), (Grand Cherokee, Wk,WK2)) Deactivating the transport mode ((Cherokee, KL), (Grand Cherokee, WK,WK2), (Grand Cherokee, WK), (Renegade, BU), (Renegade, BU,B1), (Compass (MP), MP), (Cherokee,), (Grand Cherokee, EK,WK2), (Grand Cherokee, Wk,WK2)) Coding the belt warning buzzer ((Compass (MP), MP)) Coding the country version ((Commander, XK,XH), (Grand Cherokee, WK,WK2), (Patriot, PK), (Grand Cherokee, EK,WK2), (Grand Cherokee, Wk,WK2)) Coding injectors ((Cherokee, KL), (Cherokee,), (Grand Cherokee, WK,WK2), (Patriot, PK))
Service resets	(Cherokee,), (Cherokee, KL), (Compass (MP), MP), (Grand Cherokee, EK,WK2), (Grand Cherokee, WK,WK2), (Patriot, PK)

Kia

Trouble codes	(Cee'd / Pro Cee'd, CD), (Cee'd / Pro Cee'd, ED), (Cee'd / Pro Cee'd, JD), (Picanto, JA), (Rio, YB), (Sorento, UM), (Sorento, XM), (Soul, PS), (Stinger, CK)
Parameters	(Cee'd / Pro Cee'd, CD), (Cee'd / Pro Cee'd, ED), (Cee'd / Pro Cee'd, JD), (Picanto, JA), (Rio, YB), (Sorento, XM), (Soul, PS), (Stinger, CK)
Actuators	(Cee'd / Pro Cee'd, CD), (Cee'd / Pro Cee'd, ED), (Cee'd / Pro Cee'd, JD), (Picanto, JA), (Rio, YB), (Sorento, XM), (Soul, PS), (Sportage, QL), (Stinger, CK)
Basic settings	Adapting the longitudinal acceleration sensor ((Cee'd / Pro Cee'd, CD)) Resetting engine adaptation values ((Picanto, TA), (Cee'd / Pro Cee'd, JD), (Cee'd / Pro Cee'd, CD), (Picanto, JA), (Rio, YB)) Resetting rail pressure ((Stinger, CK))



Diagnostic devices

- Initializing the brake-pressure sensor ((Picanto, JA))
- Learning the lambda sensor ((Stinger, CK))
- Bleeding the fuel system ((Cee'd / Pro Cee'd, CD))
- Gearbox bleeding ((Stinger, CK))
- Performing the special bleeding RL ((Cee'd / Pro Cee'd, ED))
- Performing the special bleeding FL ((Cee'd / Pro Cee'd, ED))
- Initializing the differential pressure sensor ((Stinger, CK))
- Adapting the longitudinal acceleration sensor ((Stinger, CK), (Picanto, JA), (Rio, YB))
- Calibrating the front camera ((Sorento, XM))
- Resetting gearbox learning values ((Stinger, CK))
- Initializing the swirl control valve ((Stinger, CK))
- Initializing the mass airflow sensor ((Stinger, CK))
- Initializing the ABS/ESC system ((Cee'd / Pro Cee'd, ED))
- Calibrating the steering-angle sensor ((Cee'd / Pro Cee'd, CD), (Stinger, CK), (Rio, YB))
- Learning the steering-angle sensor ((Cee'd / Pro Cee'd, CD))
- Learning the throttle valve ((Stinger, CK))
- De/activating the electric parking brake service mode ((Cee'd / Pro Cee'd, JD), (Cee'd / Pro Cee'd, CD))
- Reset learning values ((Cee'd / Pro Cee'd, ED))
- Regenerating the soot particulate filter ((Cee'd / Pro Cee'd, CD))
- Performing the special bleeding RR ((Cee'd / Pro Cee'd, ED))
- Resetting gearbox learning values ((Cee'd / Pro Cee'd, JD), (Cee'd / Pro Cee'd, ED), (Sorento, XM), (Picanto, JA))
- Bleeding the ABS/ESC system ((Sorento, XM), (Stinger, CK), (Picanto, JA), (Rio, YB))
- Calibrating radar statically ((Sorento, UM), (Rio, YB), (Picanto, JA), (Stonic, YB))
- Replacing engine parts ((Cee'd / Pro Cee'd, CD))
- Teach-in clutch system ((Cee'd / Pro Cee'd, JD), (Cee'd / Pro Cee'd, CD), (Rio, YB))
- Solenoid valve test ((Cee'd / Pro Cee'd, ED))
- Adapting the accelerator sensor ((Stinger, CK))
- Calibrating the lane departure warning system camera ((Cee'd / Pro Cee'd, JD))
- Activation/reset of tyre-pressure loss warning indicator ((Rio, YB))
- Resetting adaptation values of ABS ECU ((Stinger, CK), (Rio, YB))
- Bleeding the brake system ((Cee'd / Pro Cee'd, JD), (Cee'd / Pro Cee'd, CD))
- Performing the special bleeding FR ((Cee'd / Pro Cee'd, ED))
- Standardizing the liftgate ((Cee'd / Pro Cee'd, CD))
- Configuring the lane change assist ((Cee'd / Pro Cee'd, JD), (Cee'd / Pro Cee'd, CD))
- Resetting EGR valve learning values ((Stinger, CK))



Diagnostic devices

Resetting learned values of steering angle sensor ((Cee'd / Pro Cee'd, JD), (Cee'd / Pro Cee'd, ED))

Calibrate ASP ((Cee'd / Pro Cee'd, JD), (Sorento, XM), (Rio, YB))

Bleeding the ABS/ESC system ((Cee'd / Pro Cee'd, JD))

De/activating the parking brake service mode ((Stinger, CK))

Initializing the torque sensor ((Cee'd / Pro Cee'd, JD), (Sorento, XM))

Calibrating the cornering light ((Cee'd / Pro Cee'd, JD), (Sorento, XM))

Bleeding the cooling system ((Stinger, CK))

Resetting the tire pressure monitoring ((Picanto, JA))

Replacing the particle filter ((Stinger, CK))

Calibrating the camera ECU ((Soul, PS), (Stinger, CK), (Rio, YB))

Resetting self-adaptation parameters ((Stinger, CK))

Bleeding the ABS hydraulic unit ((Sorento, XM))

Learning the steering-angle sensor ((Stinger, CK), (Picanto, JA))

Codings

Coding the radio remote control ((Cee'd / Pro Cee'd, ED))

Coding the power steering ECU ((Cee'd / Pro Cee'd, CD))

Coding the tire size ((Picanto, JA), (Rio, YB))

Coding the wheel valves ((Cee'd / Pro Cee'd, JD), (Soul, PS), (Sorento, XM), (Stinger, CK))

Coding the power steering ((Cee'd / Pro Cee'd, CD))

Initializing the radar unit of distance warning system ((Niro, DE HEV), (Sorento, UM), (Sportage, QL), (Rio, YB), (Picanto, JA), (Stinger, CK), (Stonic, YB))

Service resets

(Cee'd / Pro Cee'd, CD), (Cee'd / Pro Cee'd, JD), (Picanto, JA), (Rio, YB), (Sorento, XM)

Lancia

Trouble codes

(Musa (350), 350), (Thesis (841), 841)

Parameters

(Musa (350), 350), (Thesis (841), 841)

Actuators

(Musa (350), 350), (Thesis (841), 841)

Basic settings

Initializing lateral/longitudinal/rotation acceleration sensor ((Thesis (841), 841))

Reducing system pressure in transmission ((Musa (350), 350))

Initializing the brake-pressure sensor ((Thesis (841), 841))

CFC self-adjustment band end/inspection ((Musa (350), 350))

CFC - new actuators ((Musa (350), 350))

Initializing the ABS/ESC system ((Thesis (841), 841))

Resetting differential pressure sensor learning values ((Thesis (841), 841))

Learning the steering-angle sensor ((Thesis (841), 841))



Diagnostic devices

Regenerating the soot particulate filter ((Musa (350), 350), (Thesis (841), 841))

Releasing the clutch self-adjustment ((Musa (350), 350))

Bleeding the clutch ((Musa (350), 350))

Calibrating the steering-angle sensor ((Musa (350), 350), (Thesis (841), 841))

Calculating the wear index ((Musa (350), 350))

Calibrating the parking brake ((Thesis (841), 841))

Codings

Coding injectors ((Musa (350), 350))

Registering the battery ((Thesis (841), 841))

Service resets

(Musa (350), 350), (Thesis (841), 841)

Land-Rover

Trouble codes

(Range Rover Evoque-I, L538), (Range Rover Velar, L560)*

Parameters

(Range Rover Evoque-I, L538)

Actuators

(Range Rover Evoque-I, L538)

Basic settings

Adapting the longitudinal acceleration sensor ((Range Rover Evoque-I, L538))

Replace the throttle valve actuator ((Range Rover Evoque-I, L538))

Initializing the yaw rate sensor ((Range Rover Evoque-I, L538))

Adjusting the headlights ((Range Rover Evoque-I, L538))

Initializing the sunroof actuator ((Range Rover Evoque-I, L538))

De/activating the parking brake service mode ((Range Rover Evoque-I, L538))

Learning the steering-angle sensor ((Range Rover Evoque-I, L538))

Initializing the A/C flap actuators ((Range Rover Evoque-I, L538))

Replacing the particle filter ((Discovery Sport (L55, L550))

Learning the power windows ((Range Rover Evoque-I, L538))

Initializing the lateral acceleration sensor ((Range Rover Evoque-I, L538))

Initializing the brake-pressure sensor ((Range Rover Evoque-I, L538))

Initializing the rain sensor ((Range Rover Evoque-I, L538))

Resetting the A/C compressor learning values ((Range Rover Evoque-I, L538))

Calibrating the front camera ((Range Rover Evoque-I, L538))

Resetting learned values of the battery monitoring ECU ((Range Rover Evoque-I, L538))

Performing the initial run-in of the air conditioning compressor ((Range Rover Evoque-I, L538))



Diagnostic devices

- | **Codings** Registering the battery ((Range Rover Evoque-I, L538))
- | **Service resets** (Range Rover Evoque-I, L538)

Lexus

- | **Trouble codes** (IS, AVE30), (IS, GSE3), (UX, KMA10)
- | **Parameters** (IS, AVE30), (IS, GSE3), (UX, KMA10)
- | **Actuators** (IS, AVE30), (IS, GSE3), (UX, KMA10)
- | **Basic settings**
 - Deactivating the electronic stability control ((IS, AVE30))
 - Initializing the yaw rate sensor ((IS, AVE30))
 - Adjusting the headlights ((IS, GSE3), (IS, AVE30), (UX, KMA10))
 - De/activating the parking brake service mode ((IS, AVE30), (UX, KMA10))
 - Initializing the air distribution flaps ((IS, GSE3), (IS, AVE30))
 - Calibrating front radar sensors ((IS, GSE3), (IS, AVE30))
 - Calibrating the radar sensor ((IS, GSE3), (IS, AVE30), (UX, KMA10))
 - Initializing the A/C flap actuators ((UX, KMA10))
 - Calibrating the camera ECU ((IS, GSE3), (IS, AVE30), (UX, KMA10))
 - Bleeding the brake system ((NX, AGZ10L), (NX, AGZ15L), (IS, AVE30))
 - Resetting adaptation values of ABS ECU ((IS, AVE30))
 - Configuring the lane change assist ((UX, KMA10))
 - Deactivating the electro-hydraulic brake ((IS, AVE30))
- | **Codings** Coding the wheel valves ((IS, GSE3), (IS, AVE30), (UX, KMA10))
- | **Service resets**

MAN

- | **Trouble codes**
- | **Parameters**
- | **Actuators**
- | **Basic settings** Bleeding the fuel system ((TGE, UZ), (TGE, UY))
- | **Codings**
- | **Service resets**



Diagnostic devices

Mazda

Trouble codes	(CX-7, ER), (Mazda 6, GJ,GL)
Parameters	(CX-7, ER), (Mazda 6, GJ,GL)
Actuators	(Mazda 6, GJ,GL)
Basic settings	Adapting the longitudinal acceleration sensor ((Mazda 6, GJ,GL)) Resetting oxygen sensor adaptation values ((Mazda 6, GJ,GL)) Resetting mass airflow sensor adaptation values ((Mazda 6, GJ,GL)) Initializing the yaw rate sensor ((CX-7, ER), (Mazda 6, GJ,GL)) Resetting adaptation values of the short-range radar ((Mazda 6, GJ,GL)) Learning the turbocharger ((Mazda 6, GJ,GL)) Resetting engine adaptation values ((Mazda 6, GJ,GL)) Learning the throttle valve ((Mazda 6, GJ,GL)) Learning the steering-angle sensor ((CX-7, ER)) Resetting the particulate filter learning values ((Mazda 6, GJ,GL)) Reset fuel pump learning values ((Mazda 6, GJ,GL)) Initializing the adaptive cruise control ((Mazda 6, GJ,GL)) Regenerating the soot particulate filter ((Mazda 6, GJ,GL)) Initializing the brake-pressure sensor ((Mazda 6, GJ,GL)) Calibrating the camera ECU ((Mazda 6, GJ,GL)) Initializing the lateral acceleration sensor ((CX-7, ER), (Mazda 6, GJ,GL)) Configuring the lane change assist ((Mazda 6, GJ,GL)) Resetting EGR valve learning values ((Mazda 6, GJ,GL)) Calibrating the camera ((Mazda 6, GJ,GL)) Reset learned values of injectors. ((Mazda 6, GJ,GL)) Resetting headlight leveling adaptation values ((Mazda 6, GJ,GL))
Codings	Coding injectors ((Mazda 6, GJ,GL)) Adjusting the engine oil monitoring function ((Mazda 6, GJ,GL))
Service resets	(Mazda 6, GJ,GL)



Diagnostic devices

Mercedes

Trouble codes

(A-Klasse, 177003), (B-Klasse, 247045), (C-Klasse, 205477), (C-Klasse, 205009), (Citan, 415601), (CLA-Klasse, 118384), (CLS-Klasse, 257321), (E-Klasse, 207373), (E-Klasse, 207425), (E-Klasse, 212072), (E-Klasse, 213054), (E-Klasse, 213066), (E-Klasse, 238342), (EQA, 243701), (EQB, 243708), (EQC, 293890,293891), (G-Klasse, 463277), (G-Klasse, 463306), (GL-Klasse, 166874), (GLA-Klasse, 247746), (GLB-Klasse, 247610), (GLC-Klasse, 253905), (GLE-Klasse, 166004), (GLE-Klasse, 167119), (GLE-Klasse, 292323,292324), (GLK-Klasse, 204990), (GLS-Klasse, 166824), (GLS-Klasse, 167921), (ML-Klasse, 166074), (S-Klasse, 222004,222104), (S-Klasse, 223030,223130)*, (SL-Klasse, 231474), (SLK/SLC-Klasse, 172466), (Sprinter, 906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,906733,906735), (Sprinter, 907621,907623), (Sprinter, 910621,910623), (V-Klasse, 447601,447603,447605), (V-Klasse, 448813), (V-Klasse, 639811,639813,639815)

Parameters

(A-Klasse, 177003), (B-Klasse, 247045), (C-Klasse, 205477), (C-Klasse, 205009), (Citan, 415601), (CLA-Klasse, 118384), (CLS-Klasse, 257348), (E-Klasse, 207426), (E-Klasse, 213054), (E-Klasse, 213066), (E-Klasse, 238342), (EQA, 243701), (EQB, 243708), (EQC, 293890,293891), (G-Klasse, 463277), (G-Klasse, 463306), (GLA-Klasse, 247746), (GLB-Klasse, 247610), (GLC-Klasse, 253905), (GLE-Klasse, 166073), (GLE-Klasse, 167119), (GLE-Klasse, 292323,292324), (GLK-Klasse, 204990), (GLS-Klasse, 167921), (SL-Klasse, 231474), (SLK/SLC-Klasse, 172466), (Sprinter, 906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,906733,906735), (Sprinter, 907621,907623), (Sprinter, 910621,910623), (V-Klasse, 447601,447603,447605), (V-Klasse, 448813), (V-Klasse, 639811,639813,639815)

Actuators

(A-Klasse, 177010), (B-Klasse, 247044), (Citan, 415601), (CLS-Klasse, 257348), (E-Klasse, 207426), (E-Klasse, 213227), (E-Klasse, 213066), (E-Klasse, 238342), (G-Klasse, 463306), (GLA-Klasse, 247784), (GLC-Klasse, 253905), (GLE-Klasse, 166073), (GLE-Klasse, 167323), (GLE-Klasse, 292323,292324), (GLK-Klasse, 204990), (SL-Klasse, 231474), (SLK/SLC-Klasse, 172466), (Sprinter, 906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,906733,906735), (Sprinter, 907621,907623), (Sprinter, 910621,910623), (V-Klasse, 447701,447703,447705), (V-Klasse, 639811,639813,639815)

Basic settings

Learning the power windows ((Sprinter, 910141,910143), (Sprinter, 910631,910633,910621,910623), (Sprinter, 910153,910155,910253,910255), (E-Klasse, 213068), (EQB, 243708), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse, 207403,207404), (E-Klasse, 207326), (B-Klasse, 247044), (B-Klasse, 247002), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (E-Klasse, 213268), (GLA-Klasse, 247784), (GLA-Klasse, 247751), (SLK/SLC-Klasse, 172466), (CLS-Klasse, 257348), (CLS-Klasse, 257358), (E-Klasse, 238483), (GLE-Klasse, 167323), (GLK-Klasse, 204990), (SLK/SLC-Klasse, 172435), (Sprinter, 907633,907635,907637), (Sprinter, 907731,907733,907735), (Sprinter, 907733,907735), (Sprinter, 907721,907723), (Sprinter, 907843), (Sprinter, 907643,907645,907647), (Sprinter, 907143,907145,907243,907245), (Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter, 907653,907655,907657), (Sprinter, 907153,907155,907253,907255), (Sprinter, 910143,910145,910243,910245), (Sprinter, 907133,907135,907233,907235), (Sprinter, 910133,910135,910233,910235), (Sprinter, 910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter, 910133,910135,910233), (V-Klasse, 447701,447703,447705), (V-Klasse, 447603,447605), (V-Klasse, 447703), (V-Klasse, 447703,447705), (B-Klasse, 247087), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 910131,910133,910135,910231,910233), (Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647), (Sprinter, 910633,910635,910637), (E-Klasse, 213053,213050), (E-Klasse, 213216), (GLE-Klasse, 166073), (SL-Klasse, 231474),



Diagnostic devices

(Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (B-Klasse, 247088), (B-Klasse, 247086), (E-Klasse, 213253), (GLA-Klasse, 247788), (GLA-Klasse, 247786), (V-Klasse, 447601, 447603, 447605), (B-Klasse, 247010))

Standardizing the loading space cover ((E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse, 207403,207404), (E-Klasse, 207326))

Initializing the oxidation catalyst upon engine ECU replacement ((Sprinter, 906131, 906133, 906135, 906231, 906233, 906235, 906631, 906633, 906635, 906637, 906731, 906733, 906735), (Sprinter, 906731, 906733, 906735), (Sprinter, 906153, 906155, 906253, 906255), (Sprinter, 906111, 906113, 906211, 906213), (Sprinter, 906), (Sprinter, 906735, 906737), (Sprinter, 906153, 906155, 906253, 906255, 906653, 906655, 906657), (Sprinter, 910621, 910623), (Sprinter, 910121, 910123), (Sprinter, 910631, 910633), (Sprinter, 910141, 910143, 910145, 910241, 910243), (Sprinter, 910643, 910641), (Sprinter, 910131, 910133, 910135, 910231, 910233), (Sprinter, 907621, 907623), (Sprinter, 907141, 907143, 907145, 907241, 907243), (Sprinter, 907153, 907155, 907253, 907255), (Sprinter, 907653, 907655, 907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731, 907733, 907735), (Sprinter, 910141, 910143), (Sprinter, 907141, 907143, 907241, 907243, 907145, 907245), (Sprinter, 907743, 90745, 907747), (Sprinter, 907), (Sprinter, 907131, 907133, 907135, 907231, 907233), (Sprinter, 907633, 907635, 907637), (Sprinter, 907133, 907135, 907233, 907235), (Sprinter, 907643, 907645, 907647), (Sprinter, 907143, 907145, 907243, 907245), (Sprinter, 907733, 907735), (Sprinter, 910631, 910633, 910621, 910623), (Sprinter, 907631, 907633, 907635, 907637), (Sprinter, 910040, 910141, 910143, 910145, 910641, 910643), (Sprinter, 910153, 910155, 910253, 910255), (Sprinter, 910631, 910633, 910635, 910637), (V-Klasse, 639811, 639813, 639815), (V-Klasse, 639711, 639713, 639811, 639813), (V-Klasse, 639701, 639703, 639705), (V-Klasse, 639601, 639603, 639605), (E-Klasse, 207426), (E-Klasse, 207401, 207402), (E-Klasse, 207403, 207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721, 907723), (Sprinter, 907843), (Sprinter, 907141, 907143), (Sprinter, 907143, 907145, 907243, 907245, 907141), (Sprinter, 907143, 907145, 907243, 907141, 907241), (Sprinter, 907855, 907857), (Sprinter, 910143, 910145, 910243, 910245), (Sprinter, 910133, 910135, 910233, 910235), (Sprinter, 910143, 910145, 910243, 910141, 910241), (Sprinter, 907133, 907135, 907233), (Sprinter, 910133, 910135, 910233), (V-Klasse, 447701, 447703, 447705), (Sprinter, 907641, 907643), (Sprinter, 907643, 907645), (Sprinter, 910641, 910643), (Sprinter, 910643, 910645), (Sprinter, 907131, 907133), (Sprinter, 910131, 910133), (Sprinter, 907631, 907633), (Sprinter, 907633, 907635, 907637), (Sprinter, 910633, 910635, 910631, 910637), (Sprinter, 907121, 907123), (Sprinter, 907123, 907221, 907223), (Sprinter, 910123, 910221, 910223), (Sprinter, 907221, 907223), (Sprinter, 910221, 910223), (Sprinter, 910643, 910645, 910647), (Sprinter, 910633, 910635, 910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter, 907643, 907641), (V-Klasse, 447601, 447603, 447605), (B-Klasse, 247010))

Initialize tire pressure sensors ((E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse, 207403,207404), (E-Klasse, 207326), (SLK/SLC-Klasse, 172466), (GLK-Klasse, 204990), (SLK/SLC-Klasse, 172435), (V-Klasse, 447701,447703,447705), (V-Klasse, 447603,447605), (V-Klasse, 447703), (V-Klasse, 447703,447705), (SL-Klasse, 231474), (V-Klasse, 447601,447603,447605))

Resetting Neck-Pro headrests ((GLK-Klasse, 204990))

Initializing the high-pressure EGR valve ((Sprinter, 906131, 906133, 906135, 906231, 906233, 906235, 906631, 906633, 906635, 906637, 906731, 906733, 906735), (Sprinter, 906731, 906733, 906735), (Sprinter, 906153, 906155, 906253, 906255), (Sprinter, 906131, 906133, 906135, 906231, 906233, 906235), (Sprinter, 906711, 906713), (Sprinter, 906611, 906613), (Sprinter, 906653, 906655, 906657), (Sprinter, 906631, 906633, 906635, 906637), (Sprinter, 906111, 906113, 906211, 906213), (Sprinter, 906),



Diagnostic devices

(Sprinter, 906735,906737), (Sprinter, 906153,906155,906253,906255,906653,906655,906657), (Sprinter, 910621,910623), (Sprinter, 910121,910123), (Sprinter, 910631,910633), (Sprinter, 910141,910143,910145,910241,910243), (Sprinter, 910643,910641), (Sprinter, 910131,910133,910135,910231,910233), (Sprinter, 907621,907623), (Sprinter, 907141,907143,907145,907241,907243), (Sprinter, 907153,907155,907253,907255), (Sprinter, 907653,907655,907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731,907733,907735), (Sprinter, 910141,910143), (Sprinter, 907141,907143,907241,907243,907145,907245), (Sprinter, 907743,90745,907747), (Sprinter, 907), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 907633,907635,907637), (Sprinter, 907133,907135,907233,907235), (Sprinter, 907643,907645,907647), (Sprinter, 907143,907145,907243,907245), (Sprinter, 907733,907735), (Sprinter, 910631,910633,910621,910623), (Sprinter, 907631,907633,907635,907637), (Sprinter, 910040,910141,910143,910143,910641,910643), (Sprinter, 910153,910155,910253,910255), (Sprinter, 910631,910633,910635,910637), (V-Klasse, 639811,639813,639815), (V-Klasse, 639711,639713,639811,639813), (V-Klasse, 639601,639603,639605), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse, 207403,207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721,907723), (Sprinter, 907843), (Sprinter, 907141,907143), (Sprinter, 907143,907145,907243,907245,907141), (Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter, 910143,910145,910243,910245), (Sprinter, 910133,910135,910233,910235), (Sprinter, 910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter, 910133,910135,910233), (V-Klasse, 447701,447703,447705), (Sprinter, 907641,907643), (Sprinter, 907643,907645), (Sprinter, 910641,910643), (Sprinter, 910643,910645), (Sprinter, 907131,907133), (Sprinter, 910131,910133), (Sprinter, 907631,907633), (Sprinter, 907633,907635,907631,907637), (Sprinter, 910633,910635,910631,910637), (Sprinter, 907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223), (Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647), (Sprinter, 910633,910635,910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter, 907643,907641), (V-Klasse, 447601,447603,447605), (B-Klasse, 247010))

Calibrate rearview camera ((E-Klasse, 213068), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (E-Klasse, 213268), (E-Klasse, 213053,213050), (E-Klasse, 213216), (E-Klasse, 213253))

Adapting the pressure-regulating valve ((Sprinter, 906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,906733,906735), (Sprinter, 906731,906733,906735), (Sprinter, 906153,906155,906253,906255), (Sprinter, 906131,906133,906135,906231,906233,906235), (Sprinter, 906711,906713), (Sprinter, 906611,906613), (Sprinter, 906653,906655,906657), (Sprinter, 906631,906633,906635,906637), (Sprinter, 906111,906113,906211,906213), (Sprinter, 906), (Sprinter, 906735,906737), (Sprinter, 906153,906155,906253,906255,906653,906655,906657), (Sprinter, 910621,910623), (Sprinter, 910121,910123), (Sprinter, 910631,910633), (Sprinter, 910141,910143,910145,910241,910243), (Sprinter, 910643,910641), (Sprinter, 910131,910133,910135,910231,910233), (Sprinter, 907621,907623), (Sprinter, 907141,907143,907145,907241,907243), (Sprinter, 907153,907155,907253,907255), (Sprinter, 907653,907655,907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731,907733,907735), (Sprinter, 910141,910143), (Sprinter, 907141,907143,907241,907243,907145,907245), (Sprinter, 907743,90745,907747), (Sprinter, 907), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 907633,907635,907637), (Sprinter, 907133,907135,907233,907235), (Sprinter, 907643,907645,907647), (Sprinter, 907143,907145,907243,907245), (Sprinter, 907733,907735), (Sprinter, 910631,910633,910621,910623), (Sprinter, 907631,907633,907635,907637), (Sprinter, 910040,910141,910143,910143,910641,910643), (Sprinter, 910153,910155,910253,910255), (Sprinter, 910631,910633,910635,910637), (V-Klasse, 639811,639813,639815), (V-Klasse, 639711,639713,639811,639813), (V-Klasse, 639701,639703,639705), (V-Klasse,



Diagnostic devices

639601, 639603, 639605), (E-Klasse, 207426), (E-Klasse, 207401, 207402), (E-Klasse, 207403, 207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721, 907723), (Sprinter, 907843), (Sprinter, 907141, 907143), (Sprinter, 907143, 907145, 907243, 907245, 907141), (Sprinter, 907143, 907145, 907243, 907141, 907241), (Sprinter, 907855, 907857), (Sprinter, 910143, 910145, 910243, 910245), (Sprinter, 910133, 910135, 910233, 910235), (Sprinter, 910143, 910145, 910243, 910141, 910241), (Sprinter, 907133, 907135, 907233), (Sprinter, 910133, 910135, 910233), (V-Klasse, 447701, 447703, 447705), (Sprinter, 907641, 907643), (Sprinter, 907643, 907645), (Sprinter, 910641, 910643), (Sprinter, 910643, 910645), (Sprinter, 907131, 907133), (Sprinter, 910131, 910133), (Sprinter, 907631, 907633), (Sprinter, 907633, 907635, 907631, 907637), (Sprinter, 910633, 910635, 910631, 910637), (Sprinter, 907121, 907123), (Sprinter, 907123, 907221, 907223), (Sprinter, 910123, 910221, 910223), (Sprinter, 907221, 907223), (Sprinter, 910221, 910223), (Sprinter, 910643, 910645, 910647), (Sprinter, 910633, 910635, 910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter, 907643, 907641), (V-Klasse, 447601, 447603, 447605), (B-Klasse, 247010))

Resetting the warning message of diesel exhaust fluid level ((Sprinter, 910141, 910143), (Sprinter, 910631, 910633, 910621, 910623), (Sprinter, 910153, 910155, 910253, 910255), (V-Klasse, 447701, 447703, 447705), (V-Klasse, 447815, 447811, 447813), (V-Klasse, 447711, 447713), (E-Klasse, 207426), (E-Klasse, 207401, 207402), (E-Klasse, 207403, 207404), (E-Klasse, 207326), (B-Klasse, 247002), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907633, 907635, 907637), (Sprinter, 907731, 907733, 907735), (Sprinter, 907733, 907735), (Sprinter, 907721, 907723), (Sprinter, 907843), (Sprinter, 907643, 907645, 907647), (Sprinter, 907143, 907145, 907243, 907245), (Sprinter, 907143, 907145, 907243, 907141, 907241), (Sprinter, 907855, 907857), (Sprinter, 907653, 907655, 907657), (Sprinter, 907153, 907155, 907253, 907255), (Sprinter, 910143, 910145, 910243, 910245), (Sprinter, 907133, 907135, 907233, 907235), (Sprinter, 910133, 910135, 910233, 910235), (Sprinter, 910143, 910145, 910243, 910141, 910241), (Sprinter, 907133, 907135, 907233), (Sprinter, 910133, 910135, 910233), (Sprinter, 907131, 907133, 907135, 907231, 907233), (Sprinter, 910131, 910133, 910135, 910231, 910233), (Sprinter, 907221, 907223), (Sprinter, 910221, 910223), (Sprinter, 910643, 910645, 910647), (Sprinter, 910633, 910635, 910637), (E-Klasse, 213216), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (V-Klasse, 447601, 447603, 447605), (B-Klasse, 247010))

Learning the steering-angle sensor ((SL-Klasse, 231474))

Resetting counter for synchronization loss of crankshaft/camshaft ((Sprinter, 906131, 906133, 906135, 906231, 906233, 906235, 906631, 906633, 906635, 906637, 906731, 906733, 906735), (Sprinter, 906731, 906733, 906735), (Sprinter, 906153, 906155, 906253, 906255), (Sprinter, 906131, 906133, 906135, 906231, 906233, 906235), (Sprinter, 906711, 906713), (Sprinter, 906611, 906613), (Sprinter, 906653, 906655, 906657), (Sprinter, 906631, 906633, 906635, 906637), (Sprinter, 906111, 906113, 906211, 906213), (Sprinter, 906), (Sprinter, 906735, 906737), (Sprinter, 906153, 906155, 906253, 906255), (Sprinter, 906653, 906655, 906657), (Sprinter, 910621, 910623), (Sprinter, 910121, 910123), (Sprinter, 910631, 910633), (Sprinter, 910141, 910143, 910145, 910241, 910243), (Sprinter, 910643, 910641), (Sprinter, 910131, 910133, 910135, 910231, 910233), (Sprinter, 907621, 907623), (Sprinter, 907141, 907143, 907145, 907241, 907243), (Sprinter, 907153, 907155, 907253, 907255), (Sprinter, 907653, 907655, 907657), (Sprinter, 910141, 910143, 907733, 907735), (Sprinter, 907141, 907143, 907145, 907241, 907243), (Sprinter, 907743, 907745, 907747), (Sprinter, 907), (Sprinter, 907131, 907133, 907135, 907231, 907233), (Sprinter, 907633, 907635, 907637), (Sprinter, 907133, 907135, 907233, 907235), (Sprinter, 907643, 907645, 907647), (Sprinter, 907143, 907145, 907243, 907245), (Sprinter, 907733, 907735), (Sprinter, 907141, 907143, 907241, 907243, 907245), (Sprinter, 907743, 907745, 907747), (Sprinter, 910631, 910633, 910621, 910623), (Sprinter, 907631, 907633, 907635, 907637), (Sprinter, 910040, 910141, 910143, 910143, 910641, 910643), (Sprinter, 910153, 910155, 910253, 910255), (Sprinter, 910631, 910633, 910635, 910637), (V-Klasse, 639811, 639813, 639815), (V-Klasse,



Diagnostic devices

639711, 639713, 639811, 639813), (V-Klasse, 639701, 639703, 639705), (V-Klasse, 639601, 639603, 639605), (E-Klasse, 207426), (E-Klasse, 207401, 207402), (E-Klasse, 207403, 207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721, 907723), (Sprinter, 907843), (Sprinter, 907141, 907143), (Sprinter, 907143, 907145, 907243, 907245, 907141), (Sprinter, 907143, 907145, 907243, 907141, 907241), (Sprinter, 907855, 907857), (Sprinter, 910143, 910145, 910243, 910245), (Sprinter, 910133, 910135, 910233, 910235), (Sprinter, 910143, 910145, 910243, 910141, 910241), (Sprinter, 907133, 907135, 907233), (Sprinter, 910133, 910135, 910233), (V-Klasse, 447701, 447703, 447705), (Sprinter, 907641, 907643), (Sprinter, 907643, 907645), (Sprinter, 907131, 907133), (Sprinter, 910131, 910133), (Sprinter, 907631, 907633), (Sprinter, 907633, 907635, 907631, 907637), (Sprinter, 910633, 910635, 910631, 910637), (Sprinter, 907121, 907123), (Sprinter, 907123, 907221, 907223), (Sprinter, 910123, 910221, 910223), (Sprinter, 907221, 907223), (Sprinter, 910221, 910223), (Sprinter, 910643, 910645, 910647), (Sprinter, 910633, 910635, 910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter, 907643, 907641), (V-Klasse, 447601, 447603, 447605), (B-Klasse, 247010))

Adjusting the headlights ((Sprinter, 910141, 910143), (Sprinter, 910631, 910633, 910621, 910623), (Sprinter, 910153, 910155, 910253, 910255), (E-Klasse, 213068), (E-Klasse, 207426), (E-Klasse, 207401, 207402), (E-Klasse, 207403, 207404), (E-Klasse, 207326), (B-Klasse, 247044), (B-Klasse, 247002), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (E-Klasse, 213268), (GLA-Klasse, 247784), (GLA-Klasse, 247751), (E-Klasse, 238483), (GLE-Klasse, 167323), (GLK-Klasse, 204990), (Sprinter, 907633, 907635, 907637), (Sprinter, 907731, 907733, 907735), (Sprinter, 907733, 907735), (Sprinter, 907721, 907723), (Sprinter, 907843), (Sprinter, 907643, 907645, 907647), (Sprinter, 907143, 907145, 907243, 907245), (Sprinter, 907143, 907145, 907243, 907141, 907241), (Sprinter, 907855, 907857), (Sprinter, 907653, 907655, 907657), (Sprinter, 907153, 907155, 907253, 907255), (Sprinter, 910143, 910145, 910243, 910245), (Sprinter, 907133, 907135, 907233, 907235), (Sprinter, 910133, 910135, 910233, 910235), (Sprinter, 910143, 910145, 910243, 910141, 910241), (Sprinter, 907133, 907135, 907233), (Sprinter, 910133, 910135, 910233), (B-Klasse, 247087), (Sprinter, 907131, 907133, 907135, 907231, 907233), (Sprinter, 910131, 910133, 910135, 910231, 910233), (Sprinter, 907221, 907223), (Sprinter, 910221, 910223), (Sprinter, 910643, 910645, 910647), (Sprinter, 910633, 910635, 910637), (E-Klasse, 213053, 213050), (E-Klasse, 213216), (GLE-Klasse, 166073), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (B-Klasse, 247088), (B-Klasse, 247086), (E-Klasse, 213253), (GLA-Klasse, 247788), (GLA-Klasse, 247786), (B-Klasse, 247010))

Resetting exhaust-gas temperature sensor adaptation values of soot particulate filter ((Sprinter, 906131, 906133, 906135, 906231, 906233, 906235, 906631, 906633, 906635, 906637, 906731, 906733, 906735), (Sprinter, 906731, 906733, 906735), (Sprinter, 906153, 906155, 906253, 906255), (Sprinter, 906131, 906133, 906135, 906231, 906233, 906235), (Sprinter, 906711, 906713), (Sprinter, 906611, 906613), (Sprinter, 906653, 906655, 906657), (Sprinter, 906631, 906633, 906635, 906637), (Sprinter, 906111, 906113, 906211, 906213), (Sprinter, 906153, 906155, 906253, 906255), (Sprinter, 906255, 906653, 906655, 906657), (Sprinter, 910621, 910623), (Sprinter, 910121, 910123), (Sprinter, 910631, 910633), (Sprinter, 910141, 910143, 910145, 910241, 910243), (Sprinter, 910643, 910641), (Sprinter, 910131, 910133, 910135, 910231, 910233), (Sprinter, 907621, 907623), (Sprinter, 907141, 907143, 907145, 907241, 907243), (Sprinter, 907153, 907155, 907253, 907255), (Sprinter, 907653, 907655, 907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731, 907733, 907735), (Sprinter, 910141, 910143), (Sprinter, 907141, 907143, 907241, 907243, 907145, 907245), (Sprinter, 907743, 90745, 907747), (Sprinter, 907), (Sprinter, 907131, 907133, 907135, 907231, 907233), (Sprinter, 907633, 907635, 907637), (Sprinter, 907133, 907135, 907233, 907235), (Sprinter, 907643, 907645, 907647), (Sprinter, 907143, 907145, 907243, 907245), (Sprinter, 907733, 907735), (Sprinter, 910631, 910633, 910621, 910623), (Sprinter, 907631, 907633, 907635, 907637), (Sprinter,



Diagnostic devices

910040, 910141, 910143, 910143, 910641, 910643), (Sprinter, 910153, 910155, 910253, 910255),
(Sprinter, 910631, 910633, 910635, 910637), (V-Klasse, 639811, 639813, 639815), (V-Klasse,
639711, 639713, 639811, 639813), (V-Klasse, 639701, 639703, 639705), (V-Klasse,
639601, 639603, 639605), (E-Klasse, 207426), (E-Klasse, 207401, 207402), (E-Klasse,
207403, 207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse,
213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721, 907723), (Sprinter,
907843), (Sprinter, 907141, 907143), (Sprinter, 907143, 907145, 907243, 907245, 907141),
(Sprinter, 907143, 907145, 907243, 907141, 907241), (Sprinter, 907855, 907857), (Sprinter,
910143, 910145, 910243, 910245), (Sprinter, 910133, 910135, 910233, 910235), (Sprinter,
910143, 910145, 910243, 910141, 910241), (Sprinter, 907133, 907135, 907233), (Sprinter,
910133, 910135, 910233), (V-Klasse, 447701, 447703, 447705), (Sprinter, 907641, 907643),
(Sprinter, 907643, 907645), (Sprinter, 910641, 910643), (Sprinter, 910643, 910645), (Sprinter,
907131, 907133), (Sprinter, 910131, 910133), (Sprinter, 907631, 907633), (Sprinter,
907633, 907635, 907631, 907637), (Sprinter, 910633, 910635, 910631, 910637), (Sprinter,
907121, 907123), (Sprinter, 907123, 907221, 907223), (Sprinter, 910123, 910221, 910223),
(Sprinter, 907221, 907223), (Sprinter, 910221, 910223), (Sprinter, 910643, 910645, 910647),
(Sprinter, 910633, 910635, 910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter,
907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter,
907643, 907641), (V-Klasse, 447601, 447603, 447605), (B-Klasse, 247010))

Initializing the gear sensor ((Sprinter,
906131, 906133, 906135, 906231, 906233, 906235, 906631, 906633, 906635, 906637, 906731, 9067
33, 906735), (Sprinter, 906731, 906733, 906735), (Sprinter, 906153, 906155, 906253, 906255),
(Sprinter, 906131, 906133, 906135, 906231, 906233, 906235), (Sprinter, 906711, 906713),
(Sprinter, 906611, 906613), (Sprinter, 906653, 906655, 906657), (Sprinter,
906631, 906633, 906635, 906637), (Sprinter, 906111, 906113, 906211, 906213), (Sprinter, 906),
(Sprinter, 906735, 906737), (Sprinter,
906153, 906155, 906253, 906255, 906653, 906655, 906657), (Sprinter, 910621, 910623),
(Sprinter, 910121, 910123), (Sprinter, 910631, 910633), (Sprinter,
910141, 910143, 910145, 910241, 910243), (Sprinter, 910643, 910641), (Sprinter,
910131, 910133, 910135, 910231, 910233), (Sprinter, 907621, 907623), (Sprinter,
907141, 907143, 907145, 907241, 907243), (Sprinter, 907153, 907155, 907253, 907255),
(Sprinter, 907653, 907655, 907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter,
907731, 907733, 907735), (Sprinter, 910141, 910143), (Sprinter,
907141, 907143, 907241, 907243, 907145, 907245), (Sprinter, 907743, 90745, 907747), (Sprinter,
907), (Sprinter, 907131, 907133, 907135, 907231, 907233), (Sprinter, 907633, 907635, 907637),
(Sprinter, 907133, 907135, 907233, 907235), (Sprinter, 907643, 907645, 907647), (Sprinter,
907143, 907145, 907243, 907245), (Sprinter, 907733, 907735), (Sprinter,
910631, 910633, 910621, 910623), (Sprinter, 907631, 907633, 907635, 907637), (Sprinter,
910040, 910141, 910143, 910143, 910641, 910643), (Sprinter, 910153, 910155, 910253, 910255),
(Sprinter, 910631, 910633, 910635, 910637), (V-Klasse, 639811, 639813, 639815), (V-Klasse,
639711, 639713, 639811, 639813), (V-Klasse, 639701, 639703, 639705), (V-Klasse,
639601, 639603, 639605), (V-Klasse, 447601, 447603, 447605), (V-Klasse,
447701, 447703, 447705), (V-Klasse, 447703), (V-Klasse, 447811, 447813, 447815), (V-Klasse,
447813, 447811, 447813), (V-Klasse, 447703, 447705), (V-Klasse,
447811, 447813, 447801, 447803), (V-Klasse, 447811, 447813, 447811), (V-Klasse,
447811, 447813, 447801, 447803), (V-Klasse, 447701, 447702, 447703, 447704, 447705), (V-
Klasse, 447811, 447812, 447813, 447814, 447815), (V-Klasse, 447703, 477813), (V-Klasse,
447701, 447703), (V-Klasse, 447), (E-Klasse, 207426), (E-Klasse, 207401, 207402), (E-Klasse,
207403, 207404), (E-Klasse, 207326), (V-Klasse, 447701, 447703, 447705,), (V-Klasse,
447811, 447813), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse,
213227), (GLE-Klasse, 167323), (Sprinter, 907721, 907723), (Sprinter, 907843), (Sprinter,
907141, 907143), (Sprinter, 907143, 907145, 907243, 907245, 907141), (Sprinter,
907143, 907145, 907243, 907141, 907241), (Sprinter, 907855, 907857), (Sprinter,
910143, 910145, 910243, 910245), (Sprinter, 910133, 910135, 910233, 910235), (Sprinter,
910143, 910145, 910243, 910141, 910241), (Sprinter, 907133, 907135, 907233), (Sprinter,
910133, 910135, 910233), (Sprinter, 907641, 907643), (Sprinter, 907643, 907645), (Sprinter,



Diagnostic devices

910641,910643), (Sprinter, 910643,910645), (Sprinter, 907131,907133), (Sprinter, 910131,910133), (Sprinter, 907631,907633), (Sprinter, 907633,907635,907631,907637), (Sprinter, 910633,910635,910631,910637), (Sprinter, 907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223), (Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647), (Sprinter, 910633,910635,910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (Sprinter, 907643,907641), (B-Klasse, 247010))

Resetting the impact mode ((Sprinter, 906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,906733,906735), (Sprinter, 906731,906733,906735), (Sprinter, 906153,906155,906253,906255), (Sprinter, 906131,906133,906135,906231,906233,906235), (Sprinter, 906711,906713), (Sprinter, 906611,906613), (Sprinter, 906653,906655,906657), (Sprinter, 906631,906633,906635,906637), (Sprinter, 906111,906113,906211,906213), (Sprinter, 906), (Sprinter, 906735,906737), (Sprinter, 906153,906155,906253,906255,906653,906655,906657), (Sprinter, 910621,910623), (Sprinter, 910121,910123), (Sprinter, 910631,910633), (Sprinter, 910141,910143,910145,910241,910243), (Sprinter, 910643,910641), (Sprinter, 910131,910133,910135,910231,910233), (Sprinter, 907621,907623), (Sprinter, 907141,907143,907145,907241,907243), (Sprinter, 907153,907155,907253,907255), (Sprinter, 907653,907655,907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731,907733,907735), (Sprinter, 910141,910143), (Sprinter, 907141,907143,907241,907243,907145,907245), (Sprinter, 907743,90745,907747), (Sprinter, 907), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 907633,907635,907637), (Sprinter, 907133,907135,907233,907235), (Sprinter, 907643,907645,907647), (Sprinter, 907143,907145,907243,907245), (Sprinter, 907733,907735), (Sprinter, 910631,910633,910621,910623), (Sprinter, 907631,907633,907635,907637), (Sprinter, 910040,910141,910143,910143,910641,910643), (Sprinter, 910153,910155,910253,910255), (Sprinter, 910631,910633,910635,910637), (V-Klasse, 639811,639813,639815), (V-Klasse, 639711,639713,639811,639813), (V-Klasse, 639701,639703,639705), (V-Klasse, 639601,639603,639605), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse, 207403,207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721,907723), (Sprinter, 907843), (Sprinter, 907141,907143), (Sprinter, 907143,907145,907243,907245,907141), (Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter, 910143,910145,910243,910245), (Sprinter, 910133,910135,910233,910235), (Sprinter, 910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter, 910133,910135,910233), (V-Klasse, 447701,447703,447705), (Sprinter, 907641,907643), (Sprinter, 907643,907645), (Sprinter, 907131,907133), (Sprinter, 910131,910133), (Sprinter, 907631,907633), (Sprinter, 907633,907635,907631,907637), (Sprinter, 910633,910635,910631,910637), (Sprinter, 907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223), (Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647), (Sprinter, 910633,910635,910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter, 907643,907641), (V-Klasse, 447601,447603,447605), (B-Klasse, 247010))

Resetting the counter for headlight cooling fan operating hours ((E-Klasse, 213068), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (E-Klasse, 213268), (E-Klasse, 238483), (E-Klasse, 213053,213050), (E-Klasse, 213216), (E-Klasse, 213253))

Resetting the variable turbocharger adaptation values ((Sprinter, 906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,906733,906735), (Sprinter, 906731,906733,906735), (Sprinter, 906153,906155,906253,906255), (Sprinter, 906131,906133,906135,906231,906233,906235), (Sprinter, 906711,906713), (Sprinter, 906611,906613), (Sprinter, 906653,906655,906657), (Sprinter, 906631,906633,906635,906637), (Sprinter, 906111,906113,906211,906213), (Sprinter, 906), (Sprinter, 906735,906737), (Sprinter,



Diagnostic devices

906153,906155,906253,906255,906653,906655,906657), (Sprinter, 910621,910623),
(Sprinter, 910121,910123), (Sprinter, 910631,910633), (Sprinter,
910141,910143,910145,910241,910243), (Sprinter, 910643,910641), (Sprinter,
910131,910133,910135,910231,910233), (Sprinter, 907621,907623), (Sprinter,
907141,907143,907145,907241,907243), (Sprinter, 907153,907155,907253,907255),
(Sprinter, 907653,907655,907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter,
907731,907733,907735), (Sprinter, 910141,910143), (Sprinter,
907141,907143,907241,907243,907145,907245), (Sprinter, 907743,90745,907747), (Sprinter,
907), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 907633,907635,907637),
(Sprinter, 907133,907135,907233,907235), (Sprinter, 907643,907645,907647), (Sprinter,
907143,907145,907243,907245), (Sprinter, 907733,907735), (Sprinter,
910631,910633,910621,910623), (Sprinter, 907631,907633,907635,907637), (Sprinter,
910040,910141,910143,910143,910641,910643), (Sprinter, 910153,910155,910253,910255),
(Sprinter, 910631,910633,910635,910637), (V-Klasse, 639811,639813,639815), (V-Klasse,
639711,639713,639811,639813), (V-Klasse, 639701,639703,639705), (V-Klasse,
639601,639603,639605), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse,
207403,207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse,
213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721,907723), (Sprinter,
907843), (Sprinter, 907141,907143), (Sprinter, 907143,907145,907243,907245,907141),
(Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter,
910143,910145,910243,910245), (Sprinter, 910133,910135,910233,910235), (Sprinter,
910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter,
910133,910135,910233), (V-Klasse, 447701,447703,447705), (Sprinter, 907641,907643),
(Sprinter, 907643,907645), (Sprinter, 910641,910643), (Sprinter, 910643,910645), (Sprinter,
907131,907133), (Sprinter, 910131,910133), (Sprinter, 907631,907633), (Sprinter,
907633,907635,907631,907637), (Sprinter, 910633,910635,910631,910637), (Sprinter,
907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223),
(Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647),
(Sprinter, 910633,910635,910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter,
907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter,
907643,907641), (V-Klasse, 447601,447603,447605), (B-Klasse, 247010))

Resetting adaptation values of front radar sensor ((E-Klasse, 213066), (E-Klasse, 213043),
(E-Klasse, 213045), (E-Klasse, 238342), (E-Klasse, 238314), (E-Klasse, 238348), (E-Klasse,
238334), (E-Klasse, 238343), (E-Klasse, 238365), (E-Klasse, 238366), (E-Klasse, 213143),
(E-Klasse, 213142), (E-Klasse, 213148), (E-Klasse, 238443), (E-Klasse, 238315), (E-Klasse,
238442), (E-Klasse, 238414), (E-Klasse, 238466), (E-Klasse, 238448), (E-Klasse, 238318),
(E-Klasse, 213023), (E-Klasse, 238418), (E-Klasse, 238361), (GLE-Klasse, 167119), (GLE-
Klasse, 167121), (GLE-Klasse, 167123), (GLE-Klasse, 167148), (GLE-Klasse, 167149), (GLE-
Klasse, 167159), (GLS-Klasse, 167921), (GLS-Klasse, 167923), (GLS-Klasse, 167959), (GLS-
Klasse, 167986), (E-Klasse, 213068), (GLE-Klasse, 167161), (E-Klasse, 213042), (E-Klasse,
213004), (E-Klasse, 213242), (E-Klasse, 213204), (E-Klasse, 213245), (E-Klasse, 213031),
(E-Klasse, 213033), (E-Klasse, 213264), (E-Klasse, 213271), (E-Klasse, 213266), (E-Klasse,
213064), (E-Klasse, 213071), (E-Klasse, 213005), (E-Klasse, 213040), (E-Klasse, 213013),
(E-Klasse, 213050), (E-Klasse, 213048), (E-Klasse, 213217), (E-Klasse, 213237), (E-Klasse,
213234), (E-Klasse, 213213), (E-Klasse, 213205), (E-Klasse, 213233), (E-Klasse, 213243),
(E-Klasse, 213034), (E-Klasse, 213049), (E-Klasse, 213089), (E-Klasse, 213088), (E-Klasse,
213104), (E-Klasse, 213140), (E-Klasse, 213288), (E-Klasse, 213289), (E-Klasse, 238434),
(E-Klasse, 213008), (E-Klasse, 213208), (E-Klasse, 238415), (E-Klasse, 238385), (CLS-
Klasse, 257321), (CLS-Klasse, 257323), (CLS-Klasse, 257359), (E-Klasse, 238485), (E-
Klasse, 213061), (CLS-Klasse, 257361), (E-Klasse, 213012), (E-Klasse, 213016), (E-Klasse,
213053), (E-Klasse, 213022), (E-Klasse, 213220), (E-Klasse, 213085), (CLS-Klasse, 257350),
(CLS-Klasse, 257320), (E-Klasse, 238420), (E-Klasse, 238423), (E-Klasse, 238461), (CLS-
Klasse, 257318), (CLS-Klasse, 257351), (E-Klasse, 213080), (E-Klasse, 213087), (E-Klasse,
213083), (E-Klasse, 238480), (E-Klasse, 238487), (E-Klasse, 238483), (E-Klasse, 238380),
(E-Klasse, 238387), (E-Klasse, 238383), (E-Klasse, 213280), (E-Klasse, 213287), (E-Klasse,
213283), (E-Klasse, 213222), (E-Klasse, 213077), (E-Klasse, 213078), (E-Klasse, 213054),
(E-Klasse, 213011), (E-Klasse, 213), (E-Klasse, 213206), (E-Klasse, 213253), (E-Klasse,



Diagnostic devices

238468), (E-Klasse, 213212), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (E-Klasse, 213268), (E-Klasse, 213261), (E-Klasse, 213211), (E-Klasse, 238368), (CLS-Klasse, 257314), (CLS-Klasse, 257348), (CLS-Klasse, 257358), (E-Klasse, 238465), (E-Klasse, 238467), (E-Klasse, 238386), (E-Klasse, 238320), (E-Klasse, 238323), (E-Klasse, 238367), (E-Klasse, 213216), (GLE-Klasse, 167321), (GLE-Klasse, 167361), (GLE-Klasse, 167323), (E-Klasse, 213053, 213050), (E-Klasse, 213086), (E-Klasse, 238458), (E-Klasse, 238459), (E-Klasse, 238358), (E-Klasse, 238359), (GLE-Klasse, 167349))

Compressor run-in ((E-Klasse, 207426), (E-Klasse, 207401, 207402), (E-Klasse, 207403, 207404), (E-Klasse, 207326), (SLK/SLC-Klasse, 172466), (GLK-Klasse, 204990), (SLK/SLC-Klasse, 172435))

Calibrating the camera ECU ((Sprinter, 910141, 910143), (Sprinter, 910631, 910633, 910621, 910623), (Sprinter, 910153, 910155, 910253, 910255), (E-Klasse, 213068), (EQB, 243708), (E-Klasse, 207426), (E-Klasse, 207401, 207402), (E-Klasse, 207403, 207404), (E-Klasse, 207326), (B-Klasse, 247044), (B-Klasse, 247002), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (E-Klasse, 213268), (GLA-Klasse, 247784), (GLA-Klasse, 247751), (SLK/SLC-Klasse, 172466), (CLS-Klasse, 257348), (CLS-Klasse, 257358), (E-Klasse, 238483), (GLE-Klasse, 167323), (SLK/SLC-Klasse, 172435), (Sprinter, 907633, 907635, 907637), (Sprinter, 907731, 907733, 907735), (Sprinter, 907733, 907735), (Sprinter, 907721, 907723), (Sprinter, 907843), (Sprinter, 907643, 907645, 907647), (Sprinter, 907143, 907145, 907243, 907245), (Sprinter, 907143, 907145, 907243, 907241), (Sprinter, 907855, 907857), (Sprinter, 907653, 907655, 907657), (Sprinter, 907153, 907155, 907253, 907255), (Sprinter, 910143, 910145, 910243, 910245), (Sprinter, 907133, 907135, 907233, 907235), (Sprinter, 910133, 910135, 910233, 910235), (Sprinter, 910143, 910145, 910243, 910141, 910241), (Sprinter, 907133, 907135, 907233), (Sprinter, 910133, 910135, 910233), (V-Klasse, 447701, 447703, 447705), (V-Klasse, 447603, 447605), (V-Klasse, 447703), (V-Klasse, 447703, 447705), (B-Klasse, 247087), (Sprinter, 907131, 907133, 907135, 907231, 907233), (Sprinter, 910131, 910133, 910135, 910231, 910233), (Sprinter, 907221, 907223), (Sprinter, 910221, 910223), (Sprinter, 910643, 910645, 910647), (Sprinter, 910633, 910635, 910637), (E-Klasse, 213053, 213050), (E-Klasse, 213216), (GLE-Klasse, 166073), (SL-Klasse, 231474), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (B-Klasse, 247088), (B-Klasse, 247086), (E-Klasse, 213253), (GLA-Klasse, 247788), (GLA-Klasse, 247786), (V-Klasse, 447601, 447603, 447605), (B-Klasse, 247010))

Resetting adaptation values of radar sensor rear ((C-Klasse, 205009), (C-Klasse, 205066), (C-Klasse, 205040), (C-Klasse, 205036), (C-Klasse, 205042), (C-Klasse, 205007), (C-Klasse, 205012), (C-Klasse, 205006), (C-Klasse, 205045), (C-Klasse, 205002), (C-Klasse, 205204), (C-Klasse, 205240), (C-Klasse, 205044), (C-Klasse, 205236), (C-Klasse, 205037), (C-Klasse, 205004), (C-Klasse, 205003), (C-Klasse, 205008), (C-Klasse, 205048), (C-Klasse, 205247), (C-Klasse, 205207), (C-Klasse, 205287), (C-Klasse, 205087), (C-Klasse, 205208), (C-Klasse, 205209), (C-Klasse, 205266), (C-Klasse, 205237), (C-Klasse, 205212), (GLC-Klasse, 253905), (GLC-Klasse, 253946), (GLC-Klasse, 253909), (GLC-Klasse, 253949), (GLC-Klasse, 253954), (C-Klasse, 205342), (C-Klasse, 205304), (C-Klasse, 205345), (C-Klasse, 205308), (C-Klasse, 205348), (C-Klasse, 205043), (C-Klasse, 205005), (C-Klasse, 205064), (C-Klasse, 205264), (C-Klasse, 205205), (C-Klasse, 205243), (C-Klasse, 205448), (C-Klasse, 205464), (C-Klasse, 205466), (C-Klasse, 205405), (C-Klasse, 205443), (C-Klasse, 205408), (C-Klasse, 205445), (C-Klasse, 205404), (C-Klasse, 205440), (C-Klasse, 205442), (C-Klasse, 205340), (C-Klasse, 205343), (C-Klasse, 205305), (C-Klasse, 205309), (C-Klasse, 205366), (C-Klasse, 205364), (GLC-Klasse, 253964), (GLC-Klasse, 253303, 253305), (GLC-Klasse, 253309), (GLC-Klasse, 253301), (GLC-Klasse, 253325), (GLC-Klasse, 253346), (GLC-Klasse, 253349), (GLC-Klasse, 253364), (GLC-Klasse, 253354), (GLC-Klasse, 253904), (GLC-Klasse, 253901), (E-Klasse, 213066), (E-Klasse, 213043), (C-Klasse, 205242), (C-Klasse, 205245), (E-Klasse, 213045), (E-Klasse, 238342), (E-Klasse, 238314), (E-Klasse, 238348), (E-Klasse, 238334), (E-Klasse, 238343), (E-Klasse, 238365), (E-Klasse, 238366), (E-Klasse, 213143), (E-Klasse, 213142), (E-Klasse, 213148), (E-Klasse, 238443), (E-Klasse, 238315), (E-Klasse, 238442), (E-Klasse, 238414), (E-Klasse, 238466), (E-Klasse, 238448), (C-Klasse, 205477), (C-Klasse, 205377), (C-Klasse, 205314), (C-Klasse, 205378), (E-Klasse, 238318), (Sprinter, 910621, 910623),



Diagnostic devices

(Sprinter, 910121,910123), (Sprinter, 910631,910633), (Sprinter, 910141,910143,910145,910241,910243), (Sprinter, 910643,910641), (Sprinter, 910131,910133,910135,910231,910233), (Sprinter, 907621,907623), (Sprinter, 907141,907143,907145,907241,907243), (Sprinter, 907153,907155,907253,907255), (Sprinter, 907653,907655,907657), (Sprinter, 910), (E-Klasse, 213023), (C-Klasse, 205383), (E-Klasse, 238418), (E-Klasse, 238361), (GLE-Klasse, 167119), (GLE-Klasse, 167121), (GLE-Klasse, 167123), (GLE-Klasse, 167148), (GLE-Klasse, 167149), (GLE-Klasse, 167159), (GLS-Klasse, 167921), (GLS-Klasse, 167923), (GLS-Klasse, 167959), (C-Klasse, 205483), (C-Klasse, 205418), (C-Klasse, 205283), (C-Klasse, 205318), (C-Klasse, 205213), (C-Klasse, 205019), (C-Klasse, 205018), (C-Klasse, 205013), (EQC, 293890,293891), (GLS-Klasse, 167986), (C-Klasse, 205075), (C-Klasse, 205076), (C-Klasse, 205476), (C-Klasse, 205376), (C-Klasse, 205276), (GLC-Klasse, 253323), (Sprinter, 907733), (Sprinter, 907731,907733,907735), (Sprinter, 910141,910143), (Sprinter, 907141,907143,907241,907243,907145,907245), (Sprinter, 907743,90745,907747), (Sprinter, 907), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 907633,907635,907637), (Sprinter, 907133,907135,907233,907235), (Sprinter, 907643,907645,907647), (Sprinter, 907143,907145,907243,907245), (Sprinter, 907733,907735), (Sprinter, 910631,910633,910621,910623), (C-Klasse, 205054), (GLC-Klasse, 253923), (Sprinter, 907631,907633,907635,907637), (Sprinter, 910040,910141,910143,910143,910641,910643), (Sprinter, 910153,910155,910253,910255), (E-Klasse, 213068), (GLE-Klasse, 167161), (GLB-Klasse, 247610), (GLB-Klasse, 247612), (GLB-Klasse, 247613), (GLB-Klasse, 247615), (GLB-Klasse, 247687), (GLB-Klasse, 247647), (GLB-Klasse, 247651), (GLB-Klasse, 247646), (GLA-Klasse, 247746), (GLA-Klasse, 247787), (GLA-Klasse, 247747), (GLA-Klasse, 247712), (GLA-Klasse, 247713), (GLA-Klasse, 247715), (GLA-Klasse, 247714), (GLA-Klasse, 247786), (GLA-Klasse, 247710), (C-Klasse, 205140), (C-Klasse, 205286), (Sprinter, 910631,910633,910635,910637), (EQA, 243701), (EQA, 243708), (EQB, 243708), (S-Klasse, 222004,222104), (S-Klasse, 222033,222133), (S-Klasse, 222032,222123,222132), (S-Klasse, 222165), (S-Klasse, 222057,222157), (S-Klasse, 222082), (S-Klasse, 222176), (S-Klasse, 222179), (S-Klasse, 222077,222177), (S-Klasse, 222133), (S-Klasse, 222085), (S-Klasse, 222178), (S-Klasse, 222067,222167), (S-Klasse, 222063,222163), (S-Klasse, 222185), (S-Klasse, 222032,222132), (C-Klasse, 205086), (C-Klasse, 205387), (C-Klasse, 205047), (S-Klasse, 222967), (S-Klasse, 222982), (C-Klasse, 205386), (E-Klasse, 213042), (S-Klasse, 222976), (E-Klasse, 213004), (S-Klasse, 222162), (C-Klasse, 205244), (C-Klasse, 205248), (E-Klasse, 213242), (E-Klasse, 213204), (E-Klasse, 213245), (C-Klasse, 205486), (C-Klasse, 205487), (E-Klasse, 213031), (E-Klasse, 213033), (E-Klasse, 213264), (E-Klasse, 213271), (E-Klasse, 213266), (E-Klasse, 213064), (E-Klasse, 213071), (E-Klasse, 213005), (C-Klasse, 205203), (E-Klasse, 213040), (E-Klasse, 213013), (E-Klasse, 213050), (E-Klasse, 213048), (E-Klasse, 213217), (E-Klasse, 213237), (E-Klasse, 213234), (E-Klasse, 213213), (E-Klasse, 213205), (E-Klasse, 213233), (E-Klasse, 213243), (E-Klasse, 213034), (E-Klasse, 213049), (E-Klasse, 213089), (E-Klasse, 213088), (E-Klasse, 213104), (E-Klasse, 213140), (E-Klasse, 213288), (E-Klasse, 213289), (GLC-Klasse, 253925), (S-Klasse, 222985), (S-Klasse, 222983), (S-Klasse, 222980), (S-Klasse, 222964), (S-Klasse, 222986), (E-Klasse, 238434), (S-Klasse, 222035,222135), (A-Klasse, 177003), (A-Klasse, 177087), (A-Klasse, 177046), (C-Klasse, 205078), (C-Klasse, 205077), (C-Klasse, 205014), (C-Klasse, 205214), (C-Klasse, 205278), (C-Klasse, 205414), (C-Klasse, 205478), (C-Klasse, 205277), (E-Klasse, 213008), (E-Klasse, 213208), (S-Klasse, 222021,222121), (S-Klasse, 222059), (S-Klasse, 222064), (S-Klasse, 222086,222186), (S-Klasse, 222188), (S-Klasse, 222020,222120), (S-Klasse, 222058), (S-Klasse, 222066), (S-Klasse, 222060,222160), (S-Klasse, 222083,222183), (S-Klasse, 222073), (S-Klasse, 222187), (S-Klasse, 222034,222134), (S-Klasse, 221179), (E-Klasse, 238415), (E-Klasse, 238385), (GLC-Klasse, 253388), (GLC-Klasse, 253988), (GLC-Klasse, 253989), (GLC-Klasse, 253389), (GLC-Klasse, 253943), (CLS-Klasse, 257321), (CLS-Klasse, 257323), (CLS-Klasse, 257359), (E-Klasse, 238485), (E-Klasse, 213061), (C-Klasse, 205000), (C-Klasse, 205001), (C-Klasse, 205011), (C-Klasse, 205015), (C-Klasse, 205083), (C-Klasse, 205200), (C-Klasse, 205201), (C-Klasse, 205211), (C-Klasse, 205215), (CLS-Klasse, 257361), (A-Klasse, 177082), (A-Klasse, 177084), (A-Klasse, 177044), (A-Klasse, 177045), (A-Klasse, 177047), (A-Klasse, 177012), (A-Klasse, 177014), (A-Klasse, 177147), (A-Klasse, 177051), (C-Klasse, 205401), (C-Klasse, 205411), (C-Klasse, 205415), (C-Klasse, 205301), (C-Klasse, 205311), (C-Klasse, 205218), (C-Klasse, 205219), (E-Klasse, 213012), (E-Klasse, 213016),



Diagnostic devices

(E-Klasse, 213053), (E-Klasse, 213022), (E-Klasse, 213220), (E-Klasse, 213085), (CLS-Klasse, 257350), (CLS-Klasse, 257320), (E-Klasse, 238420), (E-Klasse, 238423), (E-Klasse, 238461), (B-Klasse, 247045), (B-Klasse, 247047), (B-Klasse, 247082), (B-Klasse, 247084), (B-Klasse, 247003), (B-Klasse, 247087), (B-Klasse, 247012), (B-Klasse, 247014), (CLA-Klasse, 118384), (CLA-Klasse, 118303), (CLA-Klasse, 118312), (CLA-Klasse, 118314), (CLA-Klasse, 118344), (CLA-Klasse, 118345), (CLA-Klasse, 118346), (CLA-Klasse, 118347), (CLA-Klasse, 118351), (CLA-Klasse, 118353), (CLA-Klasse, 118387), (B-Klasse, 247015), (B-Klasse, 247013), (B-Klasse, 247046), (CLS-Klasse, 257318), (CLS-Klasse, 257351), (C-Klasse, 205084), (C-Klasse, 205284), (CLA-Klasse, 118651), (CLA-Klasse, 118684), (CLA-Klasse, 118603), (CLA-Klasse, 118687), (CLA-Klasse, 118612), (CLA-Klasse, 118644), (CLA-Klasse, 118614), (CLA-Klasse, 118646), (CLA-Klasse, 118647), (E-Klasse, 213080), (E-Klasse, 213087), (E-Klasse, 213083), (E-Klasse, 238480), (E-Klasse, 238487), (E-Klasse, 238483), (E-Klasse, 238380), (E-Klasse, 238387), (E-Klasse, 238383), (E-Klasse, 213280), (E-Klasse, 213287), (E-Klasse, 213283), (C-Klasse, 205319), (C-Klasse, 205315), (C-Klasse, 205275), (CLA-Klasse, 118354), (GLC-Klasse, 253380), (C-Klasse, 205384), (C-Klasse, 205484), (E-Klasse, 213222), (A-Klasse, 177086), (A-Klasse, 177186), (E-Klasse, 213077), (E-Klasse, 213078), (A-Klasse, 177013), (A-Klasse, 177015), (CLA-Klasse, 118613), (CLA-Klasse, 118615), (B-Klasse, 247086), (E-Klasse, 213054), (E-Klasse, 213011), (E-Klasse, 213), (E-Klasse, 213206), (E-Klasse, 213253), (G-Klasse, 463277), (A-Klasse, 177002), (E-Klasse, 238468), (CLA-Klasse, 118313), (CLA-Klasse, 118315), (CLA-Klasse, 118653), (CLA-Klasse, 118654), (B-Klasse, 247044), (B-Klasse, 247002), (E-Klasse, 213212), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (E-Klasse, 213268), (E-Klasse, 213261), (GLC-Klasse, 253981), (GLC-Klasse, 253980), (GLC-Klasse, 253315), (GLC-Klasse, 253915), (GLC-Klasse, 253353), (E-Klasse, 213211), (E-Klasse, 238368), (G-Klasse, 463234), (G-Klasse, 463348), (G-Klasse, 463274), (G-Klasse, 463276), (GLA-Klasse, 247784), (GLA-Klasse, 247751), (A-Klasse, 177102), (A-Klasse, 177184), (A-Klasse, 177103), (A-Klasse, 177187), (A-Klasse, 177112), (A-Klasse, 177113), (A-Klasse, 177144), (A-Klasse, 177145), (A-Klasse, 177114), (A-Klasse, 177115), (A-Klasse, 177146), (A-Klasse, 177151), (C-Klasse, 205080), (C-Klasse, 205049), (C-Klasse, 205053), (C-Klasse, 205480), (C-Klasse, 205449), (C-Klasse, 205380), (C-Klasse, 205349), (C-Klasse, 205280), (C-Klasse, 205253), (CLS-Klasse, 257314), (CLS-Klasse, 257348), (CLS-Klasse, 257358), (E-Klasse, 238465), (E-Klasse, 238467), (E-Klasse, 238386), (E-Klasse, 238320), (E-Klasse, 238323), (E-Klasse, 238367), (E-Klasse, 213216), (G-Klasse, 463349), (G-Klasse, 463350), (GLB-Klasse, 247614), (GLC-Klasse, 253942), (GLC-Klasse, 253913), (GLC-Klasse, 253916), (GLC-Klasse, 253914), (GLC-Klasse, 253948), (GLC-Klasse, 253953), (GLC-Klasse, 253984), (GLC-Klasse, 253342), (GLC-Klasse, 253343), (GLC-Klasse, 253313), (GLC-Klasse, 253316), (GLC-Klasse, 253381), (GLC-Klasse, 253384), (GLE-Klasse, 167321), (GLE-Klasse, 167361), (GLE-Klasse, 167323), (S-Klasse, 222104), (Sprinter, 907721, 907723), (Sprinter, 907843), (Sprinter, 907141, 907143), (Sprinter, 907143, 907145, 907243, 907245, 907141), (Sprinter, 907143, 907145, 907243, 907141, 907241), (Sprinter, 907855, 907857), (Sprinter, 910143, 910145, 910243, 910245), (Sprinter, 910133, 910135, 910233, 910235), (Sprinter, 910143, 910145, 910243, 910141, 910241), (Sprinter, 907133, 907135, 907233), (Sprinter, 910133, 910135, 910233), (Sprinter, 907641, 907643), (Sprinter, 907643, 907645), (Sprinter, 910641, 910643), (Sprinter, 910643, 910645), (Sprinter, 907131, 907133), (Sprinter, 910131, 910133), (Sprinter, 907631, 907633), (Sprinter, 907633, 907635, 907631, 907637), (Sprinter, 910633, 910635, 910631, 910637), (Sprinter, 907121, 907123), (Sprinter, 907123, 907221, 907223), (Sprinter, 910123, 910221, 910223), (Sprinter, 907221, 907223), (Sprinter, 910221, 910223), (Sprinter, 910643, 910645, 910647), (Sprinter, 910633, 910635, 910637), (E-Klasse, 213053, 213050), (E-Klasse, 213086), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177088), (A-Klasse, 177110), (A-Klasse, 177188), (B-Klasse, 247088), (C-Klasse, 205079), (CLA-Klasse, 118310), (CLA-Klasse, 118388), (CLA-Klasse, 118610), (E-Klasse, 238458), (E-Klasse, 238459), (E-Klasse, 238358), (E-Klasse, 238359), (Sprinter, 910.633), (GLA-Klasse, 247788), (GLB-Klasse, 247684), (GLB-Klasse, 247688), (GLC-Klasse, 253903), (GLC-Klasse, 253911), (GLC-Klasse, 253311), (GLE-Klasse, 167349), (Sprinter, 907643, 907641), (B-Klasse, 247010))



Diagnostic devices

Fill the DEF tank ((E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse, 207403,207404), (E-Klasse, 207326), (B-Klasse, 247002), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (E-Klasse, 213216), (A-Klasse, 177010), (A-Klasse, 177110), (B-Klasse, 247010))

Checking the transmission fluid level ((ML-Klasse, 166074), (S-Klasse, 217378), (S-Klasse, 217377), (S-Klasse, 217379), (GL-Klasse, 166874), (S-Klasse, 217385), (GLE-Klasse, 166004), (GLE-Klasse, 166062), (GLE-Klasse, 166024), (GLE-Klasse, 166056), (GLE-Klasse, 166064), (GLE-Klasse, 166073), (GLE-Klasse, 166063), (GLE-Klasse, 166074), (GLE-Klasse, 166075, 166875), (GLE-Klasse, 166006), (GLE-Klasse, 292323, 292324), (GLE-Klasse, 292356), (GLE-Klasse, 292364), (GLE-Klasse, 292373), (GLE-Klasse, 292374), (GLE-Klasse, 292375), (GLC-Klasse, 253905), (GLC-Klasse, 253946), (GLC-Klasse, 253909), (GLC-Klasse, 253949), (GLC-Klasse, 253954), (S-Klasse, 217478), (S-Klasse, 217479), (GLC-Klasse, 253964), (GLC-Klasse, 253303, 253305), (GLC-Klasse, 253309), (GLC-Klasse, 253301), (GLC-Klasse, 253325), (GLC-Klasse, 253346), (GLC-Klasse, 253349), (GLC-Klasse, 253364), (GLC-Klasse, 253354), (GLC-Klasse, 253904), (GLC-Klasse, 253901), (E-Klasse, 213066), (E-Klasse, 213043), (GLE-Klasse, 292362), (S-Klasse, 217482), (E-Klasse, 213045), (E-Klasse, 238342), (E-Klasse, 238314), (E-Klasse, 238348), (E-Klasse, 238334), (E-Klasse, 238343), (E-Klasse, 238365), (E-Klasse, 238366), (E-Klasse, 213143), (E-Klasse, 213142), (E-Klasse, 213148), (E-Klasse, 238443), (E-Klasse, 238315), (E-Klasse, 238442), (E-Klasse, 238414), (E-Klasse, 238466), (E-Klasse, 238448), (C-Klasse, 205477), (C-Klasse, 205377), (C-Klasse, 205314), (C-Klasse, 205378), (S-Klasse, 217383), (S-Klasse, 217387), (S-Klasse, 217386), (S-Klasse, 217388), (S-Klasse, 217483), (S-Klasse, 217487), (S-Klasse, 217488), (E-Klasse, 238318), (C-Klasse, 205064), (C-Klasse, 205464), (C-Klasse, 205364), (C-Klasse, 205264), (E-Klasse, 213023), (C-Klasse, 205448), (C-Klasse, 205383), (E-Klasse, 238418), (E-Klasse, 238361), (GLE-Klasse, 167119), (GLE-Klasse, 167121), (GLE-Klasse, 167123), (GLE-Klasse, 167148), (GLE-Klasse, 167149), (GLE-Klasse, 167159), (GLS-Klasse, 167921), (GLS-Klasse, 167923), (GLS-Klasse, 167959), (C-Klasse, 205483), (C-Klasse, 205418), (C-Klasse, 205340), (C-Klasse, 205440), (C-Klasse, 205283), (C-Klasse, 205318), (C-Klasse, 205466), (C-Klasse, 205066), (C-Klasse, 205240), (C-Klasse, 205044), (C-Klasse, 205213), (C-Klasse, 205019), (C-Klasse, 205266), (C-Klasse, 205040), (C-Klasse, 205018), (C-Klasse, 205013), (GLS-Klasse, 167986), (C-Klasse, 205075), (C-Klasse, 205076), (C-Klasse, 205476), (C-Klasse, 205376), (C-Klasse, 205276), (GLC-Klasse, 253323), (GLC-Klasse, 253923), (E-Klasse, 213068), (GLE-Klasse, 167161), (ML-Klasse, 166003, 166004), (ML-Klasse, 166024), (ML-Klasse, 166057), (ML-Klasse, 166073), (GL-Klasse, 166823, 166824), (GL-Klasse, 166873), (ML-Klasse, 166055), (ML-Klasse, 166056), (GLS-Klasse, 166824), (ML-Klasse, 166), (ML-Klasse, 166058), (G-Klasse, 463272), (G-Klasse, 463274), (GL-Klasse, 166856), (ML-Klasse, 166062), (S-Klasse, 217382), (GLS-Klasse, 166856), (GLS-Klasse, 166873), (GLS-Klasse, 166875), (S-Klasse, 217364), (E-Klasse, 213042), (E-Klasse, 213004), (G-Klasse, 463234, 463239), (G-Klasse, 463348), (G-Klasse, 463274, 463275), (GLE-Klasse, 166057), (E-Klasse, 213242), (E-Klasse, 213204), (E-Klasse, 213245), (E-Klasse, 213031), (E-Klasse, 213033), (G-Klasse, 463202), (G-Klasse, 463306), (G-Klasse, 463346), (E-Klasse, 213264), (E-Klasse, 213271), (E-Klasse, 213266), (E-Klasse, 213064), (E-Klasse, 213071), (E-Klasse, 213005), (E-Klasse, 213040), (E-Klasse, 213013), (E-Klasse, 213050), (E-Klasse, 213048), (E-Klasse, 213217), (E-Klasse, 213237), (E-Klasse, 213234), (E-Klasse, 213213), (E-Klasse, 213205), (E-Klasse, 213233), (E-Klasse, 213243), (E-Klasse, 213034), (E-Klasse, 213049), (E-Klasse, 213089), (E-Klasse, 213088), (E-Klasse, 213104), (E-Klasse, 213140), (E-Klasse, 213288), (E-Klasse, 213289), (GLC-Klasse, 253925), (E-Klasse, 207426), (E-Klasse, 207401, 207402), (E-Klasse, 207403, 207404), (E-Klasse, 207326), (E-Klasse, 238434), (C-Klasse, 205078), (C-Klasse, 205077), (C-Klasse, 205014), (C-Klasse, 205214), (C-Klasse, 205278), (C-Klasse, 205414), (C-Klasse, 205478), (C-Klasse, 205277), (E-Klasse, 213008), (E-Klasse, 213208), (E-Klasse, 238415), (E-Klasse, 238385), (GLC-Klasse, 253388), (GLC-Klasse, 253988), (GLC-Klasse, 253989), (GLC-Klasse, 253389), (GLC-Klasse, 253943), (CLS-Klasse, 257321), (CLS-Klasse, 257323), (CLS-Klasse, 257359), (E-Klasse, 238485), (G-Klasse, 463276), (E-Klasse, 213061), (C-Klasse, 205000), (C-Klasse, 205001), (C-Klasse, 205011), (C-Klasse, 205015), (C-Klasse, 205083), (C-Klasse, 205200), (C-Klasse, 205201), (C-Klasse, 205211), (C-Klasse, 205215), (CLS-Klasse, 257361), (C-Klasse, 205401), (C-Klasse, 205411), (C-Klasse, 205487), (C-Klasse, 205486), (C-Klasse, 205415), (C-Klasse,



Diagnostic devices

205301), (C-Klasse, 205311), (C-Klasse, 205386), (C-Klasse, 205387), (C-Klasse, 205244), (C-Klasse, 205287), (C-Klasse, 205286), (C-Klasse, 205218), (C-Klasse, 205219), (C-Klasse, 205086), (C-Klasse, 205087), (E-Klasse, 213012), (E-Klasse, 213016), (E-Klasse, 213053), (E-Klasse, 213022), (E-Klasse, 213220), (E-Klasse, 213085), (CLS-Klasse, 257350), (CLS-Klasse, 257320), (E-Klasse, 238420), (E-Klasse, 238423), (E-Klasse, 238461), (CLS-Klasse, 257318), (CLS-Klasse, 257351), (C-Klasse, 205084), (C-Klasse, 205284), (E-Klasse, 213080), (E-Klasse, 213087), (E-Klasse, 213083), (E-Klasse, 238480), (E-Klasse, 238487), (E-Klasse, 238483), (E-Klasse, 238380), (E-Klasse, 238387), (E-Klasse, 238383), (E-Klasse, 213280), (E-Klasse, 213287), (E-Klasse, 213283), (C-Klasse, 205319), (C-Klasse, 205315), (C-Klasse, 205275), (GLC-Klasse, 253380), (C-Klasse, 205384), (C-Klasse, 205484), (E-Klasse, 213222), (E-Klasse, 213077), (E-Klasse, 213078), (G-Klasse, 463277), (E-Klasse, 238468), (E-Klasse, 213212), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (E-Klasse, 213268), (E-Klasse, 213261), (GLC-Klasse, 253981), (GLC-Klasse, 253980), (GLC-Klasse, 253315), (GLC-Klasse, 253915), (GLC-Klasse, 253353), (E-Klasse, 238368), (G-Klasse, 463234), (C-Klasse, 205080), (C-Klasse, 205480), (C-Klasse, 205380), (C-Klasse, 205280), (CLS-Klasse, 257314), (CLS-Klasse, 257348), (CLS-Klasse, 257358), (E-Klasse, 238465), (E-Klasse, 238467), (E-Klasse, 238320), (E-Klasse, 238323), (E-Klasse, 238367), (E-Klasse, 213216), (G-Klasse, 463349), (G-Klasse, 463273), (GL-Klasse, 166824), (GL-Klasse, 166864), (GL-Klasse, 166872), (GL-Klasse, None), (GLC-Klasse, 253942), (GLC-Klasse, 253913), (GLC-Klasse, 253916), (GLC-Klasse, 253914), (GLC-Klasse, 253948), (GLC-Klasse, 253953), (GLC-Klasse, 253984), (GLC-Klasse, 253342), (GLC-Klasse, 253343), (GLC-Klasse, 253313), (GLC-Klasse, 253316), (GLC-Klasse, 253381), (GLC-Klasse, 253384), (GLE-Klasse, 166058), (GLE-Klasse, 167321), (GLE-Klasse, 167361), (GLE-Klasse, 167323), (GLE-Klasse, 292062), (GLK-Klasse, 204990), (S-Klasse, 217477), (E-Klasse, 213053, 213050), (E-Klasse, 213086), (GLE-Klasse, 292324), (C-Klasse, 205079), (E-Klasse, 238458), (E-Klasse, 238459), (E-Klasse, 238358), (E-Klasse, 238359), (GLC-Klasse, 253903), (GLC-Klasse, 253911), (GLC-Klasse, 253311), (GLE-Klasse, 167349))

Adapting the emergency brake assistant ((E-Klasse, 213068), (EQB, 243708), (E-Klasse, 207426), (E-Klasse, 207401, 207402), (E-Klasse, 207403, 207404), (E-Klasse, 207326), (B-Klasse, 247044), (B-Klasse, 247002), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (E-Klasse, 213268), (GLA-Klasse, 247784), (GLA-Klasse, 247751), (SLK/SLC-Klasse, 172466), (CLS-Klasse, 257348), (CLS-Klasse, 257358), (E-Klasse, 238483), (GLE-Klasse, 167323), (SLK/SLC-Klasse, 172435), (V-Klasse, 447701, 447703, 447705), (V-Klasse, 447603, 447605), (V-Klasse, 447703), (V-Klasse, 447703, 447705), (B-Klasse, 247087), (E-Klasse, 213053, 213050), (E-Klasse, 213216), (GLE-Klasse, 166073), (SL-Klasse, 231474), (A-Klasse, 177010), (A-Klasse, 177110), (B-Klasse, 247088), (B-Klasse, 247086), (GLA-Klasse, 247788), (GLA-Klasse, 247786), (V-Klasse, 447601, 447603, 447605), (B-Klasse, 247010))

Resetting learned values of the power window ((SLK/SLC-Klasse, 172466), (GLK-Klasse, 204990), (SLK/SLC-Klasse, 172435), (GLE-Klasse, 166073))

Initializing the fuel pressure sensor or the fuel rail ((Sprinter, 906131, 906133, 906135, 906231, 906233, 906235, 906631, 906633, 906635, 906637, 906731, 906733, 906735), (Sprinter, 906731, 906733, 906735), (Sprinter, 906153, 906155, 906253, 906255), (Sprinter, 906131, 906133, 906135, 906231, 906233, 906235), (Sprinter, 906711, 906713), (Sprinter, 906611, 906613), (Sprinter, 906653, 906655, 906657), (Sprinter, 906631, 906633, 906635, 906637), (Sprinter, 906111, 906113, 906211, 906213), (Sprinter, 906), (Sprinter, 906735, 906737), (Sprinter, 906153, 906155, 906253, 906255), (Sprinter, 906255, 906653, 906655, 906657), (Sprinter, 910621, 910623), (Sprinter, 910121, 910123), (Sprinter, 910631, 910633), (Sprinter, 910141, 910143, 910145, 910241, 910243), (Sprinter, 910643, 910641), (Sprinter, 910131, 910133, 910135, 910231, 910233), (Sprinter, 907621, 907623), (Sprinter, 907141, 907143, 907145, 907241, 907243), (Sprinter, 907153, 907155, 907253, 907255), (Sprinter, 907653, 907655, 907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731, 907733, 907735), (Sprinter, 910141, 910143), (Sprinter, 907141, 907143, 907241, 907243, 907145, 907245), (Sprinter, 907743, 90745, 907747), (Sprinter, 907), (Sprinter, 907131, 907133, 907135, 907231, 907233), (Sprinter, 907633, 907635, 907637),



Diagnostic devices

(Sprinter, 907133,907135,907233,907235), (Sprinter, 907643,907645,907647), (Sprinter, 907143,907145,907243,907245), (Sprinter, 907733,907735), (Sprinter, 910631,910633,910621,910623), (Sprinter, 907631,907633,907635,907637), (Sprinter, 910040,910141,910143,910143,910641,910643), (Sprinter, 910153,910155,910253,910255), (Sprinter, 910631,910633,910635,910637), (V-Klasse, 639811,639813,639815), (V-Klasse, 639711,639713,639811,639813), (V-Klasse, 639701,639703,639705), (V-Klasse, 639601,639603,639605), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse, 207403,207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721,907723), (Sprinter, 907843), (Sprinter, 907141,907143), (Sprinter, 907143,907145,907243,907245,907141), (Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter, 910143,910145,910243,910245), (Sprinter, 910133,910135,910233,910235), (Sprinter, 910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter, 910133,910135,910233), (V-Klasse, 447701,447703,447705), (Sprinter, 907641,907643), (Sprinter, 907643,907645), (Sprinter, 910641,910643), (Sprinter, 910643,910645), (Sprinter, 907131,907133), (Sprinter, 910131,910133), (Sprinter, 907631,907633), (Sprinter, 907633,907635,907631,907637), (Sprinter, 910633,910635,910631,910637), (Sprinter, 907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223), (Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647), (Sprinter, 910633,910635,910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter, 907643,907641), (V-Klasse, 447601,447603,447605), (B-Klasse, 247010))

Initializing the differential pressure sensor ((Sprinter, 906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,906733,906735), (Sprinter, 906731,906733,906735), (Sprinter, 906153,906155,906253,906255), (Sprinter, 906131,906133,906135,906231,906233,906235), (Sprinter, 906711,906713), (Sprinter, 906611,906613), (Sprinter, 906653,906655,906657), (Sprinter, 906631,906633,906635,906637), (Sprinter, 906111,906113,906211,906213), (Sprinter, 906), (Sprinter, 906735,906737), (Sprinter, 906153,906155,906253,906255,906653,906655,906657), (Sprinter, 910621,910623), (Sprinter, 910121,910123), (Sprinter, 910631,910633), (Sprinter, 910141,910143,910145,910241,910243), (Sprinter, 910643,910641), (Sprinter, 910131,910133,910135,910231,910233), (Sprinter, 907621,907623), (Sprinter, 907141,907143,907145,907241,907243), (Sprinter, 907153,907155,907253,907255), (Sprinter, 907653,907655,907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731,907733,907735), (Sprinter, 910141,910143), (Sprinter, 907141,907143,907241,907243,907145,907245), (Sprinter, 907743,90745,907747), (Sprinter, 907), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 907633,907635,907637), (Sprinter, 907133,907135,907233,907235), (Sprinter, 907643,907645,907647), (Sprinter, 907143,907145,907243,907245), (Sprinter, 907733,907735), (Sprinter, 910631,910633,910621,910623), (Sprinter, 907631,907633,907635,907637), (Sprinter, 910040,910141,910143,910143,910641,910643), (Sprinter, 910153,910155,910253,910255), (Sprinter, 910631,910633,910635,910637), (V-Klasse, 639811,639813,639815), (V-Klasse, 639711,639713,639811,639813), (V-Klasse, 639701,639703,639705), (V-Klasse, 639601,639603,639605), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse, 207403,207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721,907723), (Sprinter, 907843), (Sprinter, 907141,907143), (Sprinter, 907143,907145,907243,907245,907141), (Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter, 910143,910145,910243,910245), (Sprinter, 910133,910135,910233,910235), (Sprinter, 910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter, 910133,910135,910233), (V-Klasse, 447701,447703,447705), (Sprinter, 907641,907643), (Sprinter, 907643,907645), (Sprinter, 910641,910643), (Sprinter, 910643,910645), (Sprinter, 907131,907133), (Sprinter, 910131,910133), (Sprinter, 907631,907633), (Sprinter, 907633,907635,907631,907637), (Sprinter, 910633,910635,910631,910637), (Sprinter, 907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223), (Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647),



Diagnostic devices

(Sprinter, 910633, 910635, 910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter, 907643, 907641), (V-Klasse, 447601, 447603, 447605), (B-Klasse, 247010))

Resetting the fuel low pressure adaptation values ((Sprinter, 906131, 906133, 906135, 906231, 906233, 906235, 906631, 906633, 906635, 906637, 906731, 906733, 906735), (Sprinter, 906731, 906733, 906735), (Sprinter, 906153, 906155, 906253, 906255), (Sprinter, 906131, 906133, 906135, 906231, 906233, 906235), (Sprinter, 906711, 906713), (Sprinter, 906611, 906613), (Sprinter, 906653, 906655, 906657), (Sprinter, 906631, 906633, 906635, 906637), (Sprinter, 906111, 906113, 906211, 906213), (Sprinter, 906153, 906155, 906253, 906255, 906653, 906655, 906657), (Sprinter, 910621, 910623), (Sprinter, 910121, 910123), (Sprinter, 910631, 910633), (Sprinter, 910141, 910143, 910145, 910241, 910243), (Sprinter, 910643, 910641), (Sprinter, 910131, 910133, 910135, 910231, 910233), (Sprinter, 907621, 907623), (Sprinter, 907141, 907143, 907145, 907241, 907243), (Sprinter, 907153, 907155, 907253, 907255), (Sprinter, 907653, 907655, 907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731, 907733, 907735), (Sprinter, 910141, 910143), (Sprinter, 907141, 907143, 907241, 907243, 907245), (Sprinter, 907743, 90745, 907747), (Sprinter, 907), (Sprinter, 907131, 907133, 907135, 907231, 907233), (Sprinter, 907633, 907635, 907637), (Sprinter, 907133, 907135, 907233, 907235), (Sprinter, 907643, 907645, 907647), (Sprinter, 907143, 907145, 907243, 907245), (Sprinter, 907733, 907735), (Sprinter, 910631, 910633, 910621, 910623), (Sprinter, 907631, 907633, 907635, 907637), (Sprinter, 910040, 910141, 910143, 910145, 910641, 910643), (Sprinter, 910153, 910155, 910253, 910255), (Sprinter, 910631, 910633, 910635, 910637), (V-Klasse, 639811, 639813, 639815), (V-Klasse, 639711, 639713, 639811, 639813), (V-Klasse, 639701, 639703, 639705), (V-Klasse, 639601, 639603, 639605), (E-Klasse, 207426), (E-Klasse, 207401, 207402), (E-Klasse, 207403, 207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721, 907723), (Sprinter, 907843), (Sprinter, 907141, 907143), (Sprinter, 907143, 907145, 907243, 907245, 907141), (Sprinter, 907143, 907145, 907243, 907141, 907241), (Sprinter, 907855, 907857), (Sprinter, 910143, 910145, 910243, 910245), (Sprinter, 910133, 910135, 910233, 910235), (Sprinter, 910143, 910145, 910243, 910141, 910241), (Sprinter, 907133, 907135, 907233), (Sprinter, 910133, 910135, 910233), (V-Klasse, 447701, 447703, 447705), (Sprinter, 907641, 907643), (Sprinter, 907643, 907645), (Sprinter, 907131, 907133), (Sprinter, 910131, 910133), (Sprinter, 907631, 907633), (Sprinter, 907633, 907635, 907631, 907637), (Sprinter, 910633, 910635, 910637), (Sprinter, 907121, 907123), (Sprinter, 907123, 907221, 907223), (Sprinter, 910123, 910221, 910223), (Sprinter, 907221, 907223), (Sprinter, 910221, 910223), (Sprinter, 910643, 910645, 910647), (Sprinter, 910633, 910635, 910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643, 907641), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter, 907643, 907641), (V-Klasse, 447601, 447603, 447605), (B-Klasse, 247010))

Resetting the start inhibitor of DEF injection system ((Sprinter, 910621, 910623), (Sprinter, 910121, 910123), (Sprinter, 910631, 910633), (Sprinter, 910141, 910143, 910145, 910241, 910243), (Sprinter, 910643, 910641), (Sprinter, 910131, 910133, 910135, 910231, 910233), (Sprinter, 907621, 907623), (Sprinter, 907141, 907143, 907145, 907241, 907243), (Sprinter, 907153, 907155, 907253, 907255), (Sprinter, 907653, 907655, 907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731, 907733, 907735), (Sprinter, 910141, 910143), (Sprinter, 907141, 907143, 907241, 907243, 907245), (Sprinter, 907743, 90745, 907747), (Sprinter, 907), (Sprinter, 907131, 907133, 907135, 907231, 907233), (Sprinter, 907633, 907635, 907637), (Sprinter, 907133, 907135, 907233, 907235), (Sprinter, 907643, 907645, 907647), (Sprinter, 907143, 907145, 907243, 907245), (Sprinter, 907733, 907735), (Sprinter, 910631, 910633, 910621, 910623), (Sprinter, 907631, 907633, 907635, 907637), (Sprinter, 910040, 910141, 910143, 910145, 910641, 910643), (Sprinter, 910153, 910155, 910253, 910255), (Sprinter, 910631, 910633, 910635, 910637), (V-Klasse, 639811, 639813, 639815), (V-Klasse, 639711, 639713, 639811, 639813), (V-Klasse, 639701, 639703, 639705), (V-Klasse, 639601, 639603, 639605), (V-Klasse, 447601, 447603, 447605), (V-Klasse,



Diagnostic devices

447701, 447703, 447705), (V-Klasse, 447703), (V-Klasse, 447811, 447813, 447815), (V-Klasse, 447813, 447811, 447815), (V-Klasse, 447703, 447813), (V-Klasse, 447811, 447813, 447815, 447801, 447803), (V-Klasse, 447705, 447701, 447703), (V-Klasse, 447811, 4477813, 447801, 447803), (V-Klasse, 447815, 447813, 447811), (V-Klasse, 447811, 447813, 447801, 447803), (V-Klasse, 447701, 447702, 447703, 447704, 447705), (V-Klasse, 447811, 447812, 447813, 447814, 447815), (V-Klasse, 447703, 477813), (V-Klasse, 447711, 447713, 447701, 447703), (V-Klasse, 447815, 447811, 447813), (V-Klasse, 447711, 447713), (V-Klasse, 447701, 447703), (V-Klasse, 447), (E-Klasse, 207426), (E-Klasse, 207401, 207402), (E-Klasse, 207403, 207404), (E-Klasse, 207326), (V-Klasse, 447701, 447703, 447705), (V-Klasse, 447811, 447813), (Sprinter, 907721, 907723), (Sprinter, 907843), (Sprinter, 907141, 907143), (Sprinter, 907143, 907145, 907243, 907245, 907141), (Sprinter, 907143, 907145, 907243, 907141, 907241), (Sprinter, 907855, 907857), (Sprinter, 910143, 910145, 910243, 910245), (Sprinter, 910133, 910135, 910233, 910235), (Sprinter, 910143, 910145, 910243, 910141, 910241), (Sprinter, 907133, 907135, 907233), (Sprinter, 910133, 910135, 910233), (Sprinter, 907641, 907643), (Sprinter, 907643, 907645), (Sprinter, 910641, 910643), (Sprinter, 910643, 910645), (Sprinter, 907131, 907133), (Sprinter, 910131, 910133), (Sprinter, 907631, 907633), (Sprinter, 907633, 907635, 907631, 907637), (Sprinter, 910633, 910635, 910631, 910637), (Sprinter, 907121, 907123), (Sprinter, 907123, 907221, 907223), (Sprinter, 910123, 910221, 910223), (Sprinter, 907221, 907223), (Sprinter, 910221, 910223), (Sprinter, 910643, 910645, 910647), (Sprinter, 910633, 910635, 910637), (Sprinter, 910143), (Sprinter, 907643), (Sprinter, 907643, 907641))

Performing engine adaptations ((Sprinter, 906131, 906133, 906135, 906231, 906233, 906235, 906631, 906633, 906635, 906637, 906731, 906733, 906735), (Sprinter, 906731, 906733, 906735), (Sprinter, 906153, 906155, 906253, 906255), (Sprinter, 906131, 906133, 906135, 906231, 906233, 906235), (Sprinter, 906711, 906713), (Sprinter, 906611, 906613), (Sprinter, 906653, 906655, 906657), (Sprinter, 906631, 906633, 906635, 906637), (Sprinter, 906111, 906113, 906211, 906213), (Sprinter, 906735, 906737), (Sprinter, 906153, 906155, 906253, 906255, 906653, 906655, 906657), (V-Klasse, 639811, 639813, 639815), (V-Klasse, 639711, 639713, 639811, 639813), (V-Klasse, 639701, 639703, 639705), (V-Klasse, 639601, 639603, 639605), (Sprinter, 906))

Reset learning values ((GLK-Klasse, 204990))

Initializing the intelligent cruise control/emergency brake assistant ((E-Klasse, 213068), (EQB, 243708), (E-Klasse, 207426), (E-Klasse, 207401, 207402), (E-Klasse, 207403, 207404), (E-Klasse, 207326), (B-Klasse, 247044), (B-Klasse, 247002), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (E-Klasse, 213268), (GLA-Klasse, 247784), (GLA-Klasse, 247751), (SLK/SLC-Klasse, 172466), (CLS-Klasse, 257348), (CLS-Klasse, 257358), (E-Klasse, 238483), (GLE-Klasse, 167323), (SLK/SLC-Klasse, 172435), (V-Klasse, 447701, 447703, 447705), (V-Klasse, 447603, 447605), (V-Klasse, 447703), (V-Klasse, 447703, 447705), (B-Klasse, 247087), (E-Klasse, 213053, 213050), (E-Klasse, 213216), (GLE-Klasse, 166073), (SL-Klasse, 231474), (A-Klasse, 177010), (A-Klasse, 177110), (B-Klasse, 247088), (B-Klasse, 247086), (GLA-Klasse, 247788), (GLA-Klasse, 247786), (V-Klasse, 447601, 447603, 447605), (B-Klasse, 247010))

Initializing the panoramic roof ((GLK-Klasse, 204990))

Resetting the counter for xenon lamp operating hours ((E-Klasse, 207426), (E-Klasse, 207401, 207402), (E-Klasse, 207403, 207404), (E-Klasse, 207326), (SLK/SLC-Klasse, 172466), (GLK-Klasse, 204990), (SLK/SLC-Klasse, 172435), (GLE-Klasse, 166073))

Adapting the SCR catalyst upon replacement ((Sprinter, 906131, 906133, 906135, 906231, 906233, 906235, 906631, 906633, 906635, 906637, 906731, 906733, 906735), (Sprinter, 906731, 906733, 906735), (Sprinter, 906153, 906155, 906253, 906255, 906653, 906655, 906657), (Sprinter, 906711, 906713), (Sprinter, 906611, 906613), (Sprinter, 906653, 906655, 906657), (Sprinter, 906631, 906633, 906635, 906637), (Sprinter, 906111, 906113, 906211, 906213), (Sprinter, 906), (Sprinter, 906735, 906737), (Sprinter, 906153, 906155, 906253, 906255, 906653, 906655, 906657), (Sprinter, 910621, 910623), (Sprinter, 910121, 910123), (Sprinter, 910631, 910633), (Sprinter,



Diagnostic devices

910141, 910143, 910145, 910241, 910243), (Sprinter, 910643, 910641), (Sprinter, 910131, 910133, 910135, 910231, 910233), (Sprinter, 907621, 907623), (Sprinter, 907141, 907143, 907145, 907241, 907243), (Sprinter, 907153, 907155, 907253, 907255), (Sprinter, 907653, 907655, 907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731, 907733, 907735), (Sprinter, 910141, 910143), (Sprinter, 907141, 907143, 907241, 907243, 907145, 907245), (Sprinter, 907743, 90745, 907747), (Sprinter, 907), (Sprinter, 907131, 907133, 907135, 907231, 907233), (Sprinter, 907633, 907635, 907637), (Sprinter, 907133, 907135, 907233, 907235), (Sprinter, 907643, 907645, 907647), (Sprinter, 907143, 907145, 907243, 907245), (Sprinter, 907733, 907735), (Sprinter, 910631, 910633, 910621, 910623), (Sprinter, 907631, 907633, 907635, 907637), (Sprinter, 910040, 910141, 910143, 910145, 910641, 910643), (Sprinter, 910153, 910155, 910253, 910255), (Sprinter, 910631, 910633, 910635, 910637), (V-Klasse, 639811, 639813, 639815), (V-Klasse, 639711, 639713, 639811, 639813), (V-Klasse, 639701, 639703, 639705), (V-Klasse, 639601, 639603, 639605), (E-Klasse, 207426), (E-Klasse, 207401, 207402), (E-Klasse, 207403, 207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721, 907723), (Sprinter, 907843), (Sprinter, 907141, 907143), (Sprinter, 907143, 907145, 907243, 907245, 907141), (Sprinter, 907143, 907145, 907243, 907141, 907241), (Sprinter, 907855, 907857), (Sprinter, 910143, 910145, 910243, 910245), (Sprinter, 910133, 910135, 910233, 910235), (Sprinter, 910143, 910145, 910243, 910141, 910241), (Sprinter, 907133, 907135, 907233), (Sprinter, 910133, 910135, 910233), (V-Klasse, 447701, 447703, 447705), (Sprinter, 907641, 907643), (Sprinter, 907643, 907645), (Sprinter, 907131, 907133), (Sprinter, 910131, 910133), (Sprinter, 907631, 907633), (Sprinter, 907633, 907635, 907631, 907637), (Sprinter, 907121, 907123), (Sprinter, 907123, 907221, 907223), (Sprinter, 910123, 910221, 910223), (Sprinter, 907221, 907223), (Sprinter, 910221, 910223), (Sprinter, 910643, 910645, 910647), (Sprinter, 910633, 910635, 910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter, 907643, 907641), (V-Klasse, 447601, 447603, 447605), (B-Klasse, 247010))

Regenerating the soot particulate filter during driving ((Sprinter, 910621, 910623), (Sprinter, 910121, 910123), (Sprinter, 910631, 910633), (Sprinter, 910141, 910143, 910145, 910241, 910243), (Sprinter, 910643, 910641), (Sprinter, 910131, 910133, 910135, 910231, 910233), (Sprinter, 907621, 907623), (Sprinter, 907141, 907143, 907145, 907241, 907243), (Sprinter, 907153, 907155, 907253, 907255), (Sprinter, 907653, 907655, 907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731, 907733, 907735), (Sprinter, 910141, 910143), (Sprinter, 907141, 907143, 907241, 907243, 907145, 907245), (Sprinter, 907743, 90745, 907747), (Sprinter, 907), (Sprinter, 907131, 907133, 907135, 907231, 907233), (Sprinter, 907633, 907635, 907637), (Sprinter, 907133, 907135, 907233, 907235), (Sprinter, 907643, 907645, 907647), (Sprinter, 907143, 907145, 907243, 907245), (Sprinter, 907733, 907735), (Sprinter, 910631, 910633, 910621, 910623), (Sprinter, 907631, 907633, 907635, 907637), (Sprinter, 910040, 910141, 910143, 910145, 910641, 910643), (Sprinter, 910153, 910155, 910253, 910255), (Sprinter, 910631, 910633, 910635, 910637), (V-Klasse, 447601, 447603, 447605), (V-Klasse, 447701, 447703, 447705), (V-Klasse, 447811, 447813, 447815, 447801, 447803), (V-Klasse, 447705, 447701, 447703), (V-Klasse, 447811, 447813, 447801, 447803), (V-Klasse, 447815, 447813, 447811), (V-Klasse, 447811, 447813, 447815, 447801, 447803), (V-Klasse, 447701, 447702, 447703, 447704, 447705), (V-Klasse, 447811, 447812, 447813, 447814, 447815), (V-Klasse, 447703, 4477813), (V-Klasse, 447711, 447713, 447701, 447703), (V-Klasse, 447815, 447811, 447813), (V-Klasse, 447711, 447713), (V-Klasse, 447701, 447703), (V-Klasse, 447), (E-Klasse, 207426), (E-Klasse, 207401, 207402), (E-Klasse, 207403, 207404), (E-Klasse, 207326), (V-Klasse, 447701, 447703, 447705), (V-Klasse, 447811, 447813), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721, 907723), (Sprinter, 907843), (Sprinter, 907141, 907143), (Sprinter, 907143, 907145, 907243, 907245, 907141), (Sprinter, 907855, 907857), (Sprinter, 910143, 910145, 910243, 910245), (Sprinter,



Diagnostic devices

910133,910135,910233,910235), (Sprinter, 910143,910145,910243,910141,910241),
(Sprinter, 907133,907135,907233), (Sprinter, 910133,910135,910233), (Sprinter,
907641,907643), (Sprinter, 907643,907645), (Sprinter, 910641,910643), (Sprinter,
910643,910645), (Sprinter, 907131,907133), (Sprinter, 910131,910133), (Sprinter,
907631,907633), (Sprinter, 907633,907635,907631,907637), (Sprinter,
910633,910635,910631,910637), (Sprinter, 907121,907123), (Sprinter,
907123,907221,907223), (Sprinter, 910123,910221,910223), (Sprinter, 907221,907223),
(Sprinter, 910221,910223), (Sprinter, 910643,910645,910647), (Sprinter,
910633,910635,910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-
Klasse, 177010), (A-Klasse, 177110), (Sprinter, 907643,907641), (B-Klasse, 247010)

Initializing the parking brake ECU ((SLK/SLC-Klasse, 172466), (SLK/SLC-Klasse, 172435),
(GLE-Klasse, 166073))

Resetting the air-suspension compressor run-time ((E-Klasse, 207426), (E-Klasse,
207401,207402), (E-Klasse, 207403,207404), (E-Klasse, 207326), (GLE-Klasse, 166073))

Activation/reset of tyre-pressure loss warning indicator ((GLK-Klasse, 204990))

Initializing the A/C flap actuators ((E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse,
207403,207404), (E-Klasse, 207326), (GLK-Klasse, 204990))

Resetting learned values of steering angle sensor ((SLK/SLC-Klasse, 172466), (SLK/SLC-
Klasse, 172435))

Initializing the low pressure EGR valve ((Sprinter,
906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,9067
33,906735), (Sprinter, 906731,906733,906735), (Sprinter, 906153,906155,906253,906255),
(Sprinter, 906131,906133,906135,906231,906233,906235), (Sprinter, 906711,906713),
(Sprinter, 906611,906613), (Sprinter, 906653,906655,906657), (Sprinter,
906631,906633,906635,906637), (Sprinter, 906111,906113,906211,906213), (Sprinter, 906),
(Sprinter, 906735,906737), (Sprinter,
906153,906155,906253,906255,906653,906655,906657), (Sprinter, 910621,910623),
(Sprinter, 910121,910123), (Sprinter, 910631,910633), (Sprinter,
910141,910143,910145,910241,910243), (Sprinter, 910643,910641), (Sprinter,
910131,910133,910135,910231,910233), (Sprinter, 907621,907623), (Sprinter,
907141,907143,907145,907241,907243), (Sprinter, 907153,907155,907253,907255),
(Sprinter, 907653,907655,907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter,
907731,907733,907735), (Sprinter, 910141,910143), (Sprinter,
907141,907143,907241,907243,907145,907245), (Sprinter, 907743,90745,907747), (Sprinter,
907), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 907633,907635,907637),
(Sprinter, 907133,907135,907233,907235), (Sprinter, 907643,907645,907647), (Sprinter,
907143,907145,907243,907245), (Sprinter, 907733,907735), (Sprinter,
910631,910633,910621,910623), (Sprinter, 907631,907633,907635,907637), (Sprinter,
910040,910141,910143,910143,910641,910643), (Sprinter, 910153,910155,910253,910255),
(Sprinter, 910631,910633,910635,910637), (V-Klasse, 639811,639813,639815), (V-Klasse,
639711,639713,639811,639813), (V-Klasse, 639701,639703,639705), (V-Klasse,
639601,639603,639605), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse,
207403,207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse,
213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721,907723), (Sprinter,
907843), (Sprinter, 907141,907143), (Sprinter, 907143,907145,907243,907245,907141),
(Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter,
910143,910145,910243,910245), (Sprinter, 910133,910135,910233,910235), (Sprinter,
910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter,
910133,910135,910233), (V-Klasse, 447701,447703,447705), (Sprinter, 907641,907643),
(Sprinter, 907643,907645), (Sprinter, 910641,910643), (Sprinter, 910643,910645), (Sprinter,
907131,907133), (Sprinter, 910131,910133), (Sprinter, 907631,907633), (Sprinter,
907633,907635,907631,907637), (Sprinter, 910633,910635,910631,910637), (Sprinter,
907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223),
(Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647),



Diagnostic devices

(Sprinter, 910633, 910635, 910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter, 907643, 907641), (V-Klasse, 447601, 447603, 447605), (B-Klasse, 247010))

Initializing the clutch pedal position ((Sprinter, 906131, 906133, 906135, 906231, 906233, 906235, 906631, 906633, 906635, 906637, 906731, 906733, 906735), (Sprinter, 906731, 906733, 906735), (Sprinter, 906153, 906155, 906253, 906255), (Sprinter, 906131, 906133, 906135, 906231, 906233, 906235), (Sprinter, 906711, 906713), (Sprinter, 906611, 906613), (Sprinter, 906653, 906655, 906657), (Sprinter, 906631, 906633, 906635, 906637), (Sprinter, 906111, 906113, 906211, 906213), (Sprinter, 906, (Sprinter, 906735, 906737), (Sprinter, 906153, 906155, 906253, 906255, 906653, 906655, 906657), (Sprinter, 910621, 910623), (Sprinter, 910121, 910123), (Sprinter, 910631, 910633), (Sprinter, 910141, 910143, 910145, 910241, 910243), (Sprinter, 910643, 910641), (Sprinter, 910131, 910133, 910135, 910231, 910233), (Sprinter, 907621, 907623), (Sprinter, 907141, 907143, 907145, 907241, 907243), (Sprinter, 907153, 907155, 907253, 907255), (Sprinter, 907653, 907655, 907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731, 907733, 907735), (Sprinter, 910141, 910143), (Sprinter, 907141, 907143, 907241, 907243, 907145, 907245), (Sprinter, 907743, 90745, 907747), (Sprinter, 907), (Sprinter, 907131, 907133, 907135, 907231, 907233), (Sprinter, 907633, 907635, 907637), (Sprinter, 907133, 907135, 907233, 907235), (Sprinter, 907643, 907645, 907647), (Sprinter, 907143, 907145, 907243, 907245), (Sprinter, 907733, 907735), (Sprinter, 910631, 910633, 910621, 910623), (Sprinter, 907631, 907633, 907635, 907637), (Sprinter, 910040, 910141, 910143, 910145, 910641, 910643), (Sprinter, 910153, 910155, 910253, 910255), (Sprinter, 910631, 910633, 910635, 910637), (V-Klasse, 639811, 639813, 639815), (V-Klasse, 639711, 639713, 639811, 639813), (V-Klasse, 639601, 639603, 639605), (V-Klasse, 447601, 447603, 447605), (V-Klasse, 447701, 447703, 447705), (V-Klasse, 447703), (V-Klasse, 447811, 447813, 447815), (V-Klasse, 447813, 447815, 447817), (V-Klasse, 447811, 447813, 447801, 447803), (V-Klasse, 447815, 447813, 447811), (V-Klasse, 447811, 447813, 447801, 447803), (V-Klasse, 447701, 447702, 447703, 447704, 447705), (V-Klasse, 447811, 447812, 447813, 447814, 447815), (V-Klasse, 447703, 477813), (V-Klasse, 447701, 447703), (V-Klasse, 447811, 447812), (E-Klasse, 207426), (E-Klasse, 207401, 207402), (E-Klasse, 207403, 207404), (E-Klasse, 207326), (V-Klasse, 447701, 447703, 447705), (V-Klasse, 447811, 447813), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721, 907723), (Sprinter, 907843), (Sprinter, 907141, 907143), (Sprinter, 907143, 907145, 907243, 907245, 907141), (Sprinter, 907143, 907145, 907243, 907141, 907241), (Sprinter, 907855, 907857), (Sprinter, 910143, 910145, 910243, 910245), (Sprinter, 910133, 910135, 910233, 910235), (Sprinter, 910143, 910145, 910243, 910141, 910241), (Sprinter, 907133, 907135, 907233), (Sprinter, 910133, 910135, 910233), (Sprinter, 907641, 907643), (Sprinter, 907643, 907645), (Sprinter, 910641, 910643), (Sprinter, 910643, 910645), (Sprinter, 907131, 907133), (Sprinter, 910131, 910133), (Sprinter, 907631, 907633), (Sprinter, 907633, 907635, 907631, 907637), (Sprinter, 910633, 910635, 910631, 910637), (Sprinter, 907121, 907123), (Sprinter, 907123, 907221, 907223), (Sprinter, 910221, 910223), (Sprinter, 910643, 910645, 910647), (Sprinter, 910633, 910635, 910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (Sprinter, 907643, 907641), (B-Klasse, 247010))

Calibrating the zero fuel qty ((Sprinter, 906131, 906133, 906135, 906231, 906233, 906235, 906631, 906633, 906635, 906637, 906731, 906733, 906735), (Sprinter, 906731, 906733, 906735), (Sprinter, 906153, 906155, 906253, 906255), (Sprinter, 906131, 906133, 906135, 906231, 906233, 906235), (Sprinter, 906711, 906713), (Sprinter, 906611, 906613), (Sprinter, 906653, 906655, 906657), (Sprinter, 906631, 906633, 906635, 906637), (Sprinter, 906111, 906113, 906211, 906213), (Sprinter, 906, (Sprinter, 906735, 906737), (Sprinter, 906153, 906155, 906253, 906255, 906653, 906655, 906657), (Sprinter, 910621, 910623), (Sprinter, 910121, 910123), (Sprinter, 910631, 910633), (Sprinter,



Diagnostic devices

910141, 910143, 910145, 910241, 910243), (Sprinter, 910643, 910641), (Sprinter, 910131, 910133, 910135, 910231, 910233), (Sprinter, 907621, 907623), (Sprinter, 907141, 907143, 907145, 907241, 907243), (Sprinter, 907153, 907155, 907253, 907255), (Sprinter, 907653, 907655, 907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731, 907733, 907735), (Sprinter, 910141, 910143), (Sprinter, 907141, 907143, 907241, 907243, 907145, 907245), (Sprinter, 907743, 90745, 907747), (Sprinter, 907), (Sprinter, 907131, 907133, 907135, 907231, 907233), (Sprinter, 907633, 907635, 907637), (Sprinter, 907133, 907135, 907233, 907235), (Sprinter, 907643, 907645, 907647), (Sprinter, 907143, 907145, 907243, 907245), (Sprinter, 907733, 907735), (Sprinter, 910631, 910633, 910621, 910623), (Sprinter, 907631, 907633, 907635, 907637), (Sprinter, 910040, 910141, 910143, 910145, 910641, 910643), (Sprinter, 910153, 910155, 910253, 910255), (Sprinter, 910631, 910633, 910635, 910637), (V-Klasse, 639811, 639813, 639815), (V-Klasse, 639711, 639713, 639811, 639813), (V-Klasse, 639701, 639703, 639705), (V-Klasse, 639601, 639603, 639605), (E-Klasse, 207426), (E-Klasse, 207401, 207402), (E-Klasse, 207403, 207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721, 907723), (Sprinter, 907843), (Sprinter, 907141, 907143), (Sprinter, 907143, 907145, 907243, 907245, 907141), (Sprinter, 907143, 907145, 907243, 907141, 907241), (Sprinter, 907855, 907857), (Sprinter, 910143, 910145, 910243, 910245), (Sprinter, 910133, 910135, 910233, 910235), (Sprinter, 910143, 910145, 910243, 910141, 910241), (Sprinter, 907133, 907135, 907233), (Sprinter, 910133, 910135, 910233), (V-Klasse, 447701, 447703, 447705), (Sprinter, 907641, 907643), (Sprinter, 907643, 907645), (Sprinter, 910641, 910643), (Sprinter, 910643, 910645), (Sprinter, 907131, 907133), (Sprinter, 910131, 910133), (Sprinter, 907631, 907633), (Sprinter, 907633, 907635, 907631, 907637), (Sprinter, 910633, 910635, 910631, 910637), (Sprinter, 907121, 907123), (Sprinter, 907123, 907221, 907223), (Sprinter, 910123, 910221, 910223), (Sprinter, 907221, 907223), (Sprinter, 910221, 910223), (Sprinter, 910643, 910645, 910647), (Sprinter, 910633, 910635, 910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter, 907643, 907641), (V-Klasse, 447601, 447603, 447605), (B-Klasse, 247010))

Bringing the wind deflector of windshield in assembly position ((E-Klasse, 207426), (E-Klasse, 207401, 207402), (E-Klasse, 207403, 207404), (E-Klasse, 207326))

Initializing the sunroof actuator ((GLK-Klasse, 204990))

Initializing the EGR valve ((Sprinter, 906131, 906133, 906135, 906231, 906233, 906235, 906631, 906633, 906635, 906637, 906731, 906733, 906735), (Sprinter, 906731, 906733, 906735), (Sprinter, 906153, 906155, 906253, 906255), (Sprinter, 906131, 906133, 906135, 906231, 906233, 906235), (Sprinter, 906711, 906713), (Sprinter, 906611, 906613), (Sprinter, 906653, 906655, 906657), (Sprinter, 906631, 906633, 906635, 906637), (Sprinter, 906111, 906113, 906211, 906213), (Sprinter, 906), (Sprinter, 906735, 906737), (Sprinter, 906153, 906155, 906253, 906255, 906653, 906655, 906657), (Sprinter, 910621, 910623), (Sprinter, 910121, 910123), (Sprinter, 910631, 910633), (Sprinter, 910141, 910143, 910145, 910241, 910243), (Sprinter, 910643, 910641), (Sprinter, 910131, 910133, 910135, 910231, 910233), (Sprinter, 907621, 907623), (Sprinter, 907141, 907143, 907145, 907241, 907243), (Sprinter, 907153, 907155, 907253, 907255), (Sprinter, 907653, 907655, 907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731, 907733, 907735), (Sprinter, 910141, 910143), (Sprinter, 907141, 907143, 907241, 907243, 907145, 907245), (Sprinter, 907743, 90745, 907747), (Sprinter, 907), (Sprinter, 907131, 907133, 907135, 907231, 907233), (Sprinter, 907633, 907635, 907637), (Sprinter, 907133, 907135, 907233, 907235), (Sprinter, 907643, 907645, 907647), (Sprinter, 907143, 907145, 907243, 907245), (Sprinter, 907733, 907735), (Sprinter, 910631, 910633, 910621, 910623), (Sprinter, 907631, 907633, 907635, 907637), (Sprinter, 910040, 910141, 910143, 910145, 910641, 910643), (Sprinter, 910153, 910155, 910253, 910255), (Sprinter, 910631, 910633, 910635, 910637), (V-Klasse, 639811, 639813, 639815), (V-Klasse, 639711, 639713, 639811, 639813), (V-Klasse, 639701, 639703, 639705), (V-Klasse, 639601, 639603, 639605), (E-Klasse, 207426), (E-Klasse, 207401, 207402), (E-Klasse, 207403, 207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse,



Diagnostic devices

213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721,907723), (Sprinter, 907843), (Sprinter, 907141,907143), (Sprinter, 907143,907145,907243,907245,907141), (Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter, 910143,910145,910243,910245), (Sprinter, 910133,910135,910233,910235), (Sprinter, 910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter, 910133,910135,910233), (V-Klasse, 447701,447703,447705), (Sprinter, 907641,907643), (Sprinter, 907643,907645), (Sprinter, 910641,910643), (Sprinter, 910643,910645), (Sprinter, 907131,907133), (Sprinter, 910131,910133), (Sprinter, 907631,907633), (Sprinter, 907633,907635,907631,907637), (Sprinter, 910633,910635,910631,910637), (Sprinter, 907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223), (Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647), (Sprinter, 910633,910635,910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter, 907643,907641), (V-Klasse, 447601,447603,447605), (B-Klasse, 247010))

Initializing the diesel exhaust fluid injector ((Sprinter, 906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,906733,906735), (Sprinter, 906731,906733,906735), (Sprinter, 906153,906155,906253,906255), (Sprinter, 906131,906133,906135,906231,906233,906235), (Sprinter, 906711,906713), (Sprinter, 906611,906613), (Sprinter, 906653,906655,906657), (Sprinter, 906631,906633,906635,906637), (Sprinter, 906111,906113,906211,906213), (Sprinter, 906), (Sprinter, 906735,906737), (Sprinter, 906153,906155,906253,906255,906653,906655,906657), (Sprinter, 910621,910623), (Sprinter, 910121,910123), (Sprinter, 910631,910633), (Sprinter, 910141,910143,910145,910241,910243), (Sprinter, 910643,910641), (Sprinter, 910131,910133,910135,910231,910233), (Sprinter, 907621,907623), (Sprinter, 907141,907143,907145,907241,907243), (Sprinter, 907153,907155,907253,907255), (Sprinter, 907653,907655,907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731,907733,907735), (Sprinter, 910141,910143), (Sprinter, 907141,907143,907241,907243,907145,907245), (Sprinter, 907743,90745,907747), (Sprinter, 907), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 907633,907635,907637), (Sprinter, 907133,907135,907233,907235), (Sprinter, 907643,907645,907647), (Sprinter, 907143,907145,907243,907245), (Sprinter, 907733,907735), (Sprinter, 910631,910633,910621,910623), (Sprinter, 907631,907633,907635,907637), (Sprinter, 910040,910141,910143,910143,910641,910643), (Sprinter, 910153,910155,910253,910255), (Sprinter, 910631,910633,910635,910637), (V-Klasse, 639811,639813,639815), (V-Klasse, 639711,639713,639811,639813), (V-Klasse, 639701,639703,639705), (V-Klasse, 639601,639603,639605), (V-Klasse, 447601,447603,447605), (V-Klasse, 447701,447703,447705), (V-Klasse, 447703), (V-Klasse, 447811,447813,447815), (V-Klasse, 447703,447813), (V-Klasse, 447811,447813,447815,447801,447803), (V-Klasse, 447705,447701,447703), (V-Klasse, 447811,4477813,447801,447803), (V-Klasse, 447815,447813,447811), (V-Klasse, 447811,447813,447801,447803), (V-Klasse, 447701,447702,447703,447704,447705), (V-Klasse, 447811,447812,447813,447814,447815), (V-Klasse, 447703,477813), (V-Klasse, 447701,447703), (V-Klasse, 447811,447813,447815), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse, 207403,207404), (E-Klasse, 207326), (V-Klasse, 447701,447703,447705), (V-Klasse, 447811,447813), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721,907723), (Sprinter, 907843), (Sprinter, 907141,907143), (Sprinter, 907143,907145,907243,907245,907141), (Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter, 910143,910145,910243,910245), (Sprinter, 910133,910135,910233,910235), (Sprinter, 910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter, 910133,910135,910233), (Sprinter, 907641,907643), (Sprinter, 907643,907645), (Sprinter, 910641,910643), (Sprinter, 910643,910645), (Sprinter, 907131,907133), (Sprinter, 910131,910133), (Sprinter, 907631,907633), (Sprinter, 907633,907635,907631,907637), (Sprinter, 910633,910635,910631,910637), (Sprinter, 907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223), (Sprinter, 907221,907223),



Diagnostic devices

(Sprinter, 910221,910223), (Sprinter, 910643,910645,910647), (Sprinter, 910633,910635,910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (Sprinter, 907643,907641), (B-Klasse, 247010))

Regenerating the soot particulate filter at standstill ((Sprinter, 906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,906733,906735), (Sprinter, 906731,906733,906735), (Sprinter, 906153,906155,906253,906255), (Sprinter, 906131,906133,906135,906231,906233,906235), (Sprinter, 906711,906713), (Sprinter, 906611,906613), (Sprinter, 906653,906655,906657), (Sprinter, 906631,906633,906635,906637), (Sprinter, 906111,906113,906211,906213), (Sprinter, 906153,906155,906253,906255,906653,906655,906657), (Sprinter, 910621,910623), (Sprinter, 910121,910123), (Sprinter, 910631,910633), (Sprinter, 910141,910143,910145,910241,910243), (Sprinter, 910643,910641), (Sprinter, 910131,910133,910135,910231,910233), (Sprinter, 907621,907623), (Sprinter, 907141,907143,907145,907241,907243), (Sprinter, 907153,907155,907253,907255), (Sprinter, 907653,907655,907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731,907733,907735), (Sprinter, 910141,910143), (Sprinter, 907141,907143,907241,907243,907145,907245), (Sprinter, 907743,90745,907747), (Sprinter, 907), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 907633,907635,907637), (Sprinter, 907133,907135,907233,907235), (Sprinter, 907643,907645,907647), (Sprinter, 907143,907145,907243,907245), (Sprinter, 907733,907735), (Sprinter, 910631,910633,910621,910623), (Sprinter, 907631,907633,907635,907637), (Sprinter, 910040,910141,910143,910143,910641,910643), (Sprinter, 910153,910155,910253,910255), (Sprinter, 910631,910633,910635,910637), (V-Klasse, 639811,639813,639815), (V-Klasse, 639711,639713,639811,639813), (V-Klasse, 639701,639703,639705), (V-Klasse, 639601,639603,639605), (V-Klasse, 447601,447603,447605), (V-Klasse, 447701,447703,447705), (V-Klasse, 447703), (V-Klasse, 447811,447813,447815), (V-Klasse, 447813,447815,447815), (V-Klasse, 447811,447813,447815,447803), (V-Klasse, 447705,447701,447703), (V-Klasse, 447811,447813,447801,447803), (V-Klasse, 447815,447813,447811), (V-Klasse, 447811,447813,447801,447803), (V-Klasse, 447701,447702,447703,447704,447705), (V-Klasse, 447811,447812,447813,447814,447815), (V-Klasse, 447703,477813), (V-Klasse, 447701,447703), (V-Klasse, 447701,447703,447705), (V-Klasse, 447811,447813), (Sprinter, 907721,907723), (Sprinter, 907843), (Sprinter, 907141,907143), (Sprinter, 907143,907145,907243,907245,907141), (Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter, 910143,910145,910243,910245), (Sprinter, 910133,910135,910233,910235), (Sprinter, 910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter, 910133,910135,910233), (Sprinter, 907641,907643), (Sprinter, 907643,907645), (Sprinter, 910641,910643), (Sprinter, 910643,910645), (Sprinter, 907131,907133), (Sprinter, 910131,910133), (Sprinter, 907631,907633), (Sprinter, 907633,907635,907631,907637), (Sprinter, 910633,910635,910631,910637), (Sprinter, 907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223), (Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647), (Sprinter, 910633,910635,910637), (Sprinter, 910143), (Sprinter, 907643), (Sprinter, 907643,907641))

Initializing the adaptive cruise control ((E-Klasse, 213068), (EQB, 243708), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse, 207403,207404), (E-Klasse, 207326), (B-Klasse, 247044), (B-Klasse, 247002), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (E-Klasse, 213268), (GLA-Klasse, 247784), (GLA-Klasse, 247751), (SLK/SLC-Klasse, 172466), (CLS-Klasse, 257348), (CLS-Klasse, 257358), (E-Klasse, 238483), (GLE-Klasse, 167323), (SLK/SLC-Klasse, 172435), (V-Klasse, 447701,447703,447705), (V-Klasse, 447603,447605), (V-Klasse, 447703), (V-Klasse, 447703,447705), (B-Klasse, 247087), (E-Klasse, 213053,213050), (E-Klasse, 213216), (GLE-Klasse, 166073), (SL-Klasse, 231474), (A-Klasse, 177010), (A-Klasse, 177110), (B-Klasse, 247088), (B-Klasse, 247086), (E-Klasse, 213253), (GLA-Klasse, 247788), (GLA-Klasse, 247786), (V-Klasse, 447601,447603,447605), (B-Klasse, 247010))



Diagnostic devices

Initializing the neutral position sensor ((Sprinter, 906131, 906133, 906135, 906231, 906233, 906235, 906631, 906633, 906635, 906637, 906731, 906733, 906735), (Sprinter, 906731, 906733, 906735), (Sprinter, 906153, 906155, 906253, 906255), (Sprinter, 906131, 906133, 906135, 906231, 906233, 906235), (Sprinter, 906711, 906713), (Sprinter, 906611, 906613), (Sprinter, 906653, 906655, 906657), (Sprinter, 906631, 906633, 906635, 906637), (Sprinter, 906111, 906113, 906211, 906213), (Sprinter, 906153, 906155, 906253, 906255, 906653, 906655, 906657), (Sprinter, 906735, 906737), (Sprinter, 906153, 906155, 906253, 906255, 906653, 906655, 906657), (Sprinter, 910621, 910623), (Sprinter, 910121, 910123), (Sprinter, 910631, 910633), (Sprinter, 910141, 910143, 910145, 910241, 910243), (Sprinter, 910643, 910641), (Sprinter, 910131, 910133, 910135, 910231, 910233), (Sprinter, 907621, 907623), (Sprinter, 907141, 907143, 907145, 907241, 907243), (Sprinter, 907153, 907155, 907253, 907255), (Sprinter, 907653, 907655, 907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731, 907733, 907735), (Sprinter, 910141, 910143), (Sprinter, 907141, 907143, 907241, 907243, 907145, 907245), (Sprinter, 907743, 90745, 907747), (Sprinter, 907), (Sprinter, 907131, 907133, 907135, 907231, 907233), (Sprinter, 907633, 907635, 907637), (Sprinter, 907133, 907135, 907233, 907235), (Sprinter, 907643, 907645, 907647), (Sprinter, 907143, 907145, 907243, 907245), (Sprinter, 907733, 907735), (Sprinter, 910631, 910633, 910621, 910623), (Sprinter, 907631, 907633, 907635, 907637), (Sprinter, 910040, 910141, 910143, 910145, 910641, 910643), (Sprinter, 910153, 910155, 910253, 910255), (Sprinter, 910631, 910633, 910635, 910637), (V-Klasse, 639811, 639813, 639815), (V-Klasse, 639711, 639713, 639811, 639813), (V-Klasse, 639701, 639703, 639705), (V-Klasse, 639601, 639603, 639605), (E-Klasse, 207426), (E-Klasse, 207401, 207402), (E-Klasse, 207403, 207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721, 907723), (Sprinter, 907843), (Sprinter, 907141, 907143), (Sprinter, 907143, 907145, 907243, 907245, 907141), (Sprinter, 907143, 907145, 907243, 907141, 907241), (Sprinter, 907855, 907857), (Sprinter, 910143, 910145, 910243, 910245), (Sprinter, 910133, 910135, 910233, 910235), (Sprinter, 910143, 910145, 910243, 910141, 910241), (Sprinter, 907133, 907135, 907233), (Sprinter, 910133, 910135, 910233), (V-Klasse, 447701, 447703, 447705), (Sprinter, 907641, 907643), (Sprinter, 907643, 907645), (Sprinter, 907131, 907133), (Sprinter, 910131, 910133), (Sprinter, 907631, 907633), (Sprinter, 907633, 907635, 907631, 907637), (Sprinter, 910633, 910635, 910631, 910637), (Sprinter, 907121, 907123), (Sprinter, 907123, 907221, 907223), (Sprinter, 910123, 910221, 910223), (Sprinter, 907221, 907223), (Sprinter, 910221, 910223), (Sprinter, 910643, 910645, 910647), (Sprinter, 910633, 910635, 910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter, 907643, 907641), (V-Klasse, 447601, 447603, 447605), (B-Klasse, 247010))

Learning the intake port shut-off ((Sprinter, 906131, 906133, 906135, 906231, 906233, 906235, 906631, 906633, 906635, 906637, 906731, 906733, 906735), (Sprinter, 906731, 906733, 906735), (Sprinter, 906153, 906155, 906253, 906255), (Sprinter, 906131, 906133, 906135, 906231, 906233, 906235), (Sprinter, 906711, 906713), (Sprinter, 906611, 906613), (Sprinter, 906653, 906655, 906657), (Sprinter, 906631, 906633, 906635, 906637), (Sprinter, 906111, 906113, 906211, 906213), (Sprinter, 906, (Sprinter, 906735, 906737), (Sprinter, 906153, 906155, 906253, 906255, 906653, 906655, 906657), (Sprinter, 910621, 910623), (Sprinter, 910121, 910123), (Sprinter, 910631, 910633), (Sprinter, 910141, 910143, 910145, 910241, 910243), (Sprinter, 910643, 910641), (Sprinter, 910131, 910133, 910135, 910231, 910233), (Sprinter, 907621, 907623), (Sprinter, 907141, 907143, 907145, 907241, 907243), (Sprinter, 907153, 907155, 907253, 907255), (Sprinter, 907653, 907655, 907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731, 907733, 907735), (Sprinter, 910141, 910143), (Sprinter, 907141, 907143, 907241, 907243, 907145, 907245), (Sprinter, 907743, 90745, 907747), (Sprinter, 907), (Sprinter, 907131, 907133, 907135, 907231, 907233), (Sprinter, 907633, 907635, 907637), (Sprinter, 907133, 907135, 907233, 907235), (Sprinter, 907643, 907645, 907647), (Sprinter, 907143, 907145, 907243, 907245), (Sprinter, 907733, 907735), (Sprinter, 910631, 910633, 910621, 910623), (Sprinter, 907631, 907633, 907635, 907637), (Sprinter,



Diagnostic devices

910040, 910141, 910143, 910143, 910641, 910643), (Sprinter, 910153, 910155, 910253, 910255),
(Sprinter, 910631, 910633, 910635, 910637), (V-Klasse, 639811, 639813, 639815), (V-Klasse,
639711, 639713, 639811, 639813), (V-Klasse, 639701, 639703, 639705), (V-Klasse,
639601, 639603, 639605), (E-Klasse, 207426), (E-Klasse, 207401, 207402), (E-Klasse,
207403, 207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse,
213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721, 907723), (Sprinter,
907843), (Sprinter, 907141, 907143), (Sprinter, 907143, 907145, 907243, 907245, 907141),
(Sprinter, 907143, 907145, 907243, 907141, 907241), (Sprinter, 907855, 907857), (Sprinter,
910143, 910145, 910243, 910245), (Sprinter, 910133, 910135, 910233, 910235), (Sprinter,
910143, 910145, 910243, 910141, 910241), (Sprinter, 907133, 907135, 907233), (Sprinter,
910133, 910135, 910233), (V-Klasse, 447701, 447703, 447705), (Sprinter, 907641, 907643),
(Sprinter, 907643, 907645), (Sprinter, 910641, 910643), (Sprinter, 910643, 910645), (Sprinter,
907131, 907133), (Sprinter, 910131, 910133), (Sprinter, 907631, 907633), (Sprinter,
907633, 907635, 907631, 907637), (Sprinter, 910633, 910635, 910631, 910637), (Sprinter,
907121, 907123), (Sprinter, 907123, 907221, 907223), (Sprinter, 910123, 910221, 910223),
(Sprinter, 907221, 907223), (Sprinter, 910221, 910223), (Sprinter, 910643, 910645, 910647),
(Sprinter, 910633, 910635, 910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter,
907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter,
907643, 907641), (V-Klasse, 447601, 447603, 447605), (B-Klasse, 247010))

Initializing lateral/longitudinal/rotation acceleration sensor ((GLK-Klasse, 204990))

Resetting the diesel exhaust fluid level ((GLE-Klasse, 166073))

Initializing the steering angle sensor manually ((E-Klasse, 207426), (E-Klasse,
207401, 207402), (E-Klasse, 207403, 207404), (E-Klasse, 207326), (SLK/SLC-Klasse,
172466), (Citan, 415601), (Citan, 415603), (Citan, 415605), (GLK-Klasse, 204990), (SLK/SLC-
Klasse, 172435), (V-Klasse, 447701, 447703, 447705), (V-Klasse, 447603, 447605), (V-Klasse,
447703), (V-Klasse, 447703, 447705), (V-Klasse, 447601, 447603, 447605))

Reset exhaust-gas aftertreatment learning values ((Sprinter,
906131, 906133, 906135, 906231, 906233, 906235, 906631, 906633, 906635, 906637, 906731, 9067
33, 906735), (Sprinter, 906731, 906733, 906735), (Sprinter, 906153, 906155, 906253, 906255),
(Sprinter, 906131, 906133, 906135, 906231, 906233, 906235), (Sprinter, 906711, 906713),
(Sprinter, 906611, 906613), (Sprinter, 906653, 906655, 906657), (Sprinter,
906631, 906633, 906635, 906637), (Sprinter, 906111, 906113, 906211, 906213), (Sprinter, 906),
(Sprinter, 906735, 906737), (Sprinter,
906153, 906155, 906253, 906255, 906653, 906655, 906657), (Sprinter, 910621, 910623),
(Sprinter, 910121, 910123), (Sprinter, 910631, 910633), (Sprinter,
910141, 910143, 910145, 910241, 910243), (Sprinter, 910643, 910641), (Sprinter,
910131, 910133, 910135, 910231, 910233), (Sprinter, 907621, 907623), (Sprinter,
907141, 907143, 907145, 907241, 907243), (Sprinter, 907153, 907155, 907253, 907255),
(Sprinter, 907653, 907655, 907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter,
907731, 907733, 907735), (Sprinter, 910141, 910143), (Sprinter,
907141, 907143, 907241, 907243, 907145, 907245), (Sprinter, 907743, 90745, 907747), (Sprinter,
907), (Sprinter, 907131, 907133, 907135, 907231, 907233), (Sprinter, 907633, 907635, 907637),
(Sprinter, 907133, 907135, 907233, 907235), (Sprinter, 907643, 907645, 907647), (Sprinter,
907143, 907145, 907243, 907245), (Sprinter, 907733, 907735), (Sprinter,
910631, 910633, 910621, 910623), (Sprinter, 907631, 907633, 907635, 907637), (Sprinter,
910040, 910141, 910143, 910143, 910641, 910643), (Sprinter, 910153, 910155, 910253, 910255),
(Sprinter, 910631, 910633, 910635, 910637), (V-Klasse, 639811, 639813, 639815), (V-Klasse,
639711, 639713, 639811, 639813), (V-Klasse, 639701, 639703, 639705), (V-Klasse,
639601, 639603, 639605), (E-Klasse, 207426), (E-Klasse, 207401, 207402), (E-Klasse,
207403, 207404), (E-Klasse, 207326), (Sprinter, 907721, 907723), (Sprinter, 907843),
(Sprinter, 907141, 907143), (Sprinter, 907143, 907145, 907243, 907245, 907141), (Sprinter,
907143, 907145, 907243, 907141, 907241), (Sprinter, 907855, 907857), (Sprinter,
910143, 910145, 910243, 910245), (Sprinter, 910133, 910135, 910233, 910235), (Sprinter,
910143, 910145, 910243, 910141, 910241), (Sprinter, 907133, 907135, 907233), (Sprinter,
910133, 910135, 910233), (V-Klasse, 447701, 447703, 447705), (Sprinter, 907641, 907643),
(Sprinter, 907643, 907645), (Sprinter, 910641, 910643), (Sprinter, 910643, 910645), (Sprinter,



Diagnostic devices

907131,907133), (Sprinter, 910131,910133), (Sprinter, 907631,907633), (Sprinter, 907633,907635,907631,907637), (Sprinter, 910633,910635,910631,910637), (Sprinter, 907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223), (Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647), (Sprinter, 910633,910635,910637), (Sprinter, 910143), (Sprinter, 907643), (V-Klasse, 447703), (Sprinter, 907643,907641), (V-Klasse, 447601,447603,447605))

Initializing the soot particulate filter ((Sprinter, 906131, 906133, 906135, 906231, 906233, 906235, 906631, 906633, 906635, 906637, 906731, 906733, 906735), (Sprinter, 906731, 906733, 906735), (Sprinter, 906153, 906155, 906253, 906255), (Sprinter, 906131, 906133, 906135, 906231, 906233, 906235), (Sprinter, 906711, 906713), (Sprinter, 906611, 906613), (Sprinter, 906653, 906655, 906657), (Sprinter, 906631, 906633, 906635, 906637), (Sprinter, 906111, 906113, 906211, 906213), (Sprinter, 906), (Sprinter, 906735, 906737), (Sprinter, 906153, 906155, 906253, 906255, 906653, 906655, 906657), (Sprinter, 910621, 910623), (Sprinter, 910121, 910123), (Sprinter, 910631, 910633), (Sprinter, 910141, 910143, 910145, 910241, 910243), (Sprinter, 910643, 910641), (Sprinter, 910131, 910133, 910135, 910231, 910233), (Sprinter, 907621, 907623), (Sprinter, 907141, 907143, 907145, 907241, 907243), (Sprinter, 907153, 907155, 907253, 907255), (Sprinter, 907653, 907655, 907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731, 907733, 907735), (Sprinter, 910141, 910143), (Sprinter, 907141, 907143, 907241, 907243, 907145, 907245), (Sprinter, 907743, 90745, 907747), (Sprinter, 907), (Sprinter, 907131, 907133, 907135, 907231, 907233), (Sprinter, 907633, 907635, 907637), (Sprinter, 907133, 907135, 907233, 907235), (Sprinter, 907643, 907645, 907647), (Sprinter, 907143, 907145, 907243, 907245), (Sprinter, 907733, 907735), (Sprinter, 910631, 910633, 910621, 910623), (Sprinter, 907631, 907633, 907635, 907637), (Sprinter, 910040, 910141, 910143, 910145, 910641, 910643), (Sprinter, 910153, 910155, 910253, 910255), (Sprinter, 910631, 910633, 910635, 910637), (V-Klasse, 639811, 639813, 639815), (V-Klasse, 639711, 639713, 639811, 639813), (V-Klasse, 639701, 639703, 639705), (V-Klasse, 639601, 639603, 639605), (V-Klasse, 447601, 447603, 447605), (V-Klasse, 447701, 447703, 447705), (V-Klasse, 447703), (V-Klasse, 447811, 447813, 447815), (V-Klasse, 447703, 447813), (V-Klasse, 447811, 447813, 447815, 447801, 447803), (V-Klasse, 447705, 447701, 447703), (V-Klasse, 447811, 447813, 447801, 447803), (V-Klasse, 447815, 447813, 447811), (V-Klasse, 447811, 447813, 447801, 447803), (V-Klasse, 447701, 447702, 447703, 447704, 447705), (V-Klasse, 447811, 447812, 447813, 447814, 447815), (V-Klasse, 447703, 477813), (V-Klasse, 447701, 447703), (V-Klasse, 447701, 447703), (V-Klasse, 207426), (E-Klasse, 207401, 207402), (E-Klasse, 207403, 207404), (E-Klasse, 207326), (V-Klasse, 447701, 447703, 447705), (V-Klasse, 447811, 447813), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721, 907723), (Sprinter, 907843), (Sprinter, 907141, 907143), (Sprinter, 907143, 907145, 907243, 907245, 907141), (Sprinter, 907143, 907145, 907243, 907141, 907241), (Sprinter, 907855, 907857), (Sprinter, 910143, 910145, 910243, 910245), (Sprinter, 910133, 910135, 910233, 910235), (Sprinter, 910143, 910145, 910243, 910141, 910241), (Sprinter, 907133, 907135, 907233), (Sprinter, 910133, 910135, 910233), (Sprinter, 907641, 907643), (Sprinter, 907643, 907645), (Sprinter, 910641, 910643), (Sprinter, 910643, 910645), (Sprinter, 907131, 907133), (Sprinter, 910131, 910133), (Sprinter, 907631, 907633), (Sprinter, 907633, 907635, 907631, 907637), (Sprinter, 910633, 910635, 910631, 910637), (Sprinter, 907121, 907123), (Sprinter, 907123, 907221, 907223), (Sprinter, 910221, 910223), (Sprinter, 910643, 910645, 910647), (Sprinter, 910633, 910635, 910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (Sprinter, 907643, 907641), (B-Klasse, 247010))

Resetting long-term adaptation values of diesel exhaust fluid dosing module ((Sprinter, 906131, 906133, 906135, 906231, 906233, 906235, 906631, 906633, 906635, 906637, 906731, 906733, 906735), (Sprinter, 906731, 906733, 906735), (Sprinter, 906153, 906155, 906253, 906255), (Sprinter, 906131, 906133, 906135, 906231, 906233, 906235), (Sprinter, 906711, 906713), (Sprinter, 906611, 906613), (Sprinter, 906653, 906655, 906657), (Sprinter, 906631, 906633, 906635, 906637), (Sprinter, 906111, 906113, 906211, 906213), (Sprinter, 906),



Diagnostic devices

Resetting the counter for headlight operating hours ((E-Klasse, 213068), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (E-Klasse, 213268), (E-Klasse, 238483), (V-Klasse, 447701,447703,447705), (V-Klasse, 447603,447605), (V-Klasse, 447703), (V-Klasse, 447703,447705), (E-Klasse, 213053,213050), (E-Klasse, 213216), (E-Klasse, 213253), (V-Klasse, 447601,447603,447605))

Resetting learned values of NOx sensor ((Sprinter,
906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,906733,906735), (Sprinter, 906731,906733,906735), (Sprinter, 906153,906155,906253,906255),
(Sprinter, 906131,906133,906135,906231,906233,906235), (Sprinter, 906711,906713),
(Sprinter, 906611,906613), (Sprinter, 906653,906655,906657), (Sprinter,
906631,906633,906635,906637), (Sprinter, 906111,906113,906211,906213), (Sprinter, 906),
(Sprinter, 906735,906737), (Sprinter,
906153,906155,906253,906255,906653,906655,906657), (Sprinter, 910621,910623),
(Sprinter, 910121,910123), (Sprinter, 910631,910633), (Sprinter,
910141,910143,910145,910241,910243), (Sprinter, 910643,910641), (Sprinter,
910131,910133,910135,910231,910233), (Sprinter, 907621,907623), (Sprinter,
907141,907143,907145,907241,907243), (Sprinter, 907153,907155,907253,907255),
(Sprinter, 907653,907655,907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter,



Diagnostic devices

907731,907733,907735), (Sprinter, 910141,910143), (Sprinter, 907141,907143,907241,907243,907145,907245), (Sprinter, 907743,90745,907747), (Sprinter, 907), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 907633,907635,907637), (Sprinter, 907133,907135,907233,907235), (Sprinter, 907643,907645,907647), (Sprinter, 907143,907145,907243,907245), (Sprinter, 907733,907735), (Sprinter, 910631,910633,910621,910623), (Sprinter, 907631,907633,907635,907637), (Sprinter, 910040,910141,910143,910143,910641,910643), (Sprinter, 910153,910155,910253,910255), (Sprinter, 910631,910633,910635,910637), (V-Klasse, 639811,639813,639815), (V-Klasse, 639711,639713,639811,639813), (V-Klasse, 639701,639703,639705), (V-Klasse, 639601,639603,639605), (V-Klasse, 447601,447603,447605), (V-Klasse, 447701,447703,447705), (V-Klasse, 447811,447813,447815,447801,447803), (V-Klasse, 447705,447701,447703), (V-Klasse, 447811,447813,447815,447801,447803), (V-Klasse, 447815,447813,447811), (V-Klasse, 447811,447813,447801,447803), (V-Klasse, 447701,447702,447703,447704,447705), (V-Klasse, 447811,447812,447813,447814,447815), (V-Klasse, 447703,477813), (V-Klasse, 447701,447703), (V-Klasse, 447), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse, 207403,207404), (E-Klasse, 207326), (V-Klasse, 447701,447703,447705,), (V-Klasse, 447811,447813), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721,907723), (Sprinter, 907843), (Sprinter, 907141,907143), (Sprinter, 907143,907145,907243,907245,907141), (Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter, 910143,910145,910243,910245), (Sprinter, 910133,910135,910233,910235), (Sprinter, 910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter, 910133,910135,910233), (Sprinter, 907641,907643), (Sprinter, 907643,907645), (Sprinter, 910641,910643), (Sprinter, 910643,910645), (Sprinter, 907131,907133), (Sprinter, 910131,910133), (Sprinter, 907631,907633), (Sprinter, 907633,907635,907631,907637), (Sprinter, 910633,910635,910631,910637), (Sprinter, 907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223), (Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647), (Sprinter, 910633,910635,910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (Sprinter, 907643,907641), (B-Klasse, 247010))

Resetting learned values of camshaft sensor ((Sprinter, 906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,906733,906735), (Sprinter, 906731,906733,906735), (Sprinter, 906153,906155,906253,906255), (Sprinter, 906131,906133,906135,906231,906233,906235), (Sprinter, 906711,906713), (Sprinter, 906611,906613), (Sprinter, 906653,906655,906657), (Sprinter, 906631,906633,906635,906637), (Sprinter, 906111,906113,906211,906213), (Sprinter, 906), (Sprinter, 906735,906737), (Sprinter, 906153,906155,906253,906255,906653,906655,906657), (Sprinter, 910621,910623), (Sprinter, 910121,910123), (Sprinter, 910631,910633), (Sprinter, 910141,910143,910145,910241,910243), (Sprinter, 910643,910641), (Sprinter, 910131,910133,910135,910231,910233), (Sprinter, 907621,907623), (Sprinter, 907141,907143,907145,907241,907243), (Sprinter, 907153,907155,907253,907255), (Sprinter, 907653,907655,907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731,907733,907735), (Sprinter, 910141,910143), (Sprinter, 907141,907143,907241,907243,907145,907245), (Sprinter, 907743,90745,907747), (Sprinter, 907), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 907633,907635,907637), (Sprinter, 907133,907135,907233,907235), (Sprinter, 907643,907645,907647), (Sprinter, 907143,907145,907243,907245), (Sprinter, 907733,907735), (Sprinter, 910631,910633,910621,910623), (Sprinter, 907631,907633,907635,907637), (Sprinter, 910040,910141,910143,910143,910641,910643), (Sprinter, 910153,910155,910253,910255), (Sprinter, 910631,910633,910635,910637), (V-Klasse, 639811,639813,639815), (V-Klasse, 639711,639713,639811,639813), (V-Klasse, 639701,639703,639705), (V-Klasse, 639601,639603,639605), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse, 207403,207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721,907723), (Sprinter,



Diagnostic devices

907843), (Sprinter, 907141,907143), (Sprinter, 907143,907145,907243,907245,907141), (Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter, 910143,910145,910243,910245), (Sprinter, 910133,910135,910233,910235), (Sprinter, 910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter, 910133,910135,910233), (V-Klasse, 447701,447703,447705), (Sprinter, 907641,907643), (Sprinter, 907643,907645), (Sprinter, 910641,910643), (Sprinter, 910643,910645), (Sprinter, 907131,907133), (Sprinter, 910131,910133), (Sprinter, 907631,907633), (Sprinter, 907633,907635,907631,907637), (Sprinter, 910633,910635,910631,910637), (Sprinter, 907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223), (Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647), (Sprinter, 910633,910635,910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter, 907643,907641), (V-Klasse, 447601,447603,447605), (B-Klasse, 247010))

Adapting the temperature sensor before SCR catalyst ((Sprinter, 906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,906733,906735), (Sprinter, 906731,906733,906735), (Sprinter, 906153,906155,906253,906255), (Sprinter, 906131,906133,906135,906231,906233,906235), (Sprinter, 906711,906713), (Sprinter, 906611,906613), (Sprinter, 906653,906655,906657), (Sprinter, 906631,906633,906635,906637), (Sprinter, 906111,906113,906211,906213), (Sprinter, 906), (Sprinter, 906735,906737), (Sprinter, 906153,906155,906253,906255,906653,906655,906657), (Sprinter, 910621,910623), (Sprinter, 910121,910123), (Sprinter, 910631,910633), (Sprinter, 910141,910143,910145,910241,910243), (Sprinter, 910643,910641), (Sprinter, 910131,910133,910135,910231,910233), (Sprinter, 907621,907623), (Sprinter, 907141,907143,907145,907241,907243), (Sprinter, 907153,907155,907253,907255), (Sprinter, 907653,907655,907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731,907733,907735), (Sprinter, 910141,910143), (Sprinter, 907141,907143,907241,907243,907145,907245), (Sprinter, 907743,90745,907747), (Sprinter, 907), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 907633,907635,907637), (Sprinter, 907133,907135,907233,907235), (Sprinter, 907643,907645,907647), (Sprinter, 907143,907145,907243,907245), (Sprinter, 907733,907735), (Sprinter, 910631,910633,910621,910623), (Sprinter, 907631,907633,907635,907637), (Sprinter, 910040,910141,910143,910143,910641,910643), (Sprinter, 910153,910155,910253,910255), (Sprinter, 910631,910633,910635,910637), (V-Klasse, 639811,639813,639815), (V-Klasse, 639711,639713,639811,639813), (V-Klasse, 639701,639703,639705), (V-Klasse, 639601,639603,639605), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse, 207403,207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721,907723), (Sprinter, 907843), (Sprinter, 907141,907143), (Sprinter, 907143,907145,907243,907245,907141), (Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter, 910143,910145,910243,910245), (Sprinter, 910133,910135,910233,910235), (Sprinter, 910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter, 910133,910135,910233), (V-Klasse, 447701,447703,447705), (Sprinter, 907641,907643), (Sprinter, 907643,907645), (Sprinter, 910641,910643), (Sprinter, 910643,910645), (Sprinter, 907131,907133), (Sprinter, 910131,910133), (Sprinter, 907631,907633), (Sprinter, 907633,907635,907631,907637), (Sprinter, 910633,910635,910631,910637), (Sprinter, 907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223), (Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647), (Sprinter, 910633,910635,910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter, 907643,907641), (V-Klasse, 447601,447603,447605), (B-Klasse, 247010))

Resetting learned values of diesel exhaust fluid pump ((Sprinter, 910141,910143), (Sprinter, 910631,910633,910621,910623), (Sprinter, 910153,910155,910253,910255), (V-Klasse, 447701,447703,447705), (V-Klasse, 447815,447811,447813), (V-Klasse, 447711,447713), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse, 207403,207404), (E-Klasse, 207326), (B-Klasse, 247002), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907633,907635,907637), (Sprinter,



Diagnostic devices

907731,907733,907735), (Sprinter, 907733,907735), (Sprinter, 907721,907723), (Sprinter, 907843), (Sprinter, 907643,907645,907647), (Sprinter, 907143,907145,907243,907245), (Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter, 907653,907655,907657), (Sprinter, 907153,907155,907253,907255), (Sprinter, 910143,910145,910243,910245), (Sprinter, 907133,907135,907233,907235), (Sprinter, 910133,910135,910233,910235), (Sprinter, 910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter, 910133,910135,910233), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 910131,910133,910135,910231,910233), (Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647), (Sprinter, 910633,910635,910637), (E-Klasse, 213216), (GLE-Klasse, 166073), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (V-Klasse, 447601,447603,447605), (B-Klasse, 247010))

Reset learned values of injectors. ((Sprinter, 906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,906733,906735), (Sprinter, 906731,906733,906735), (Sprinter, 906153,906155,906253,906255), (Sprinter, 906131,906133,906135,906231,906233,906235), (Sprinter, 906711,906713), (Sprinter, 906611,906613), (Sprinter, 906653,906655,906657), (Sprinter, 906631,906633,906635,906637), (Sprinter, 906111,906113,906211,906213), (Sprinter, 906), (Sprinter, 906735,906737), (Sprinter, 906153,906155,906253,906255,906653,906655,906657), (Sprinter, 910621,910623), (Sprinter, 910121,910123), (Sprinter, 910631,910633), (Sprinter, 910141,910143,910145,910241,910243), (Sprinter, 910643,910641), (Sprinter, 910131,910133,910135,910231,910233), (Sprinter, 907621,907623), (Sprinter, 907141,907143,907145,907241,907243), (Sprinter, 907153,907155,907253,907255), (Sprinter, 907653,907655,907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731,907733,907735), (Sprinter, 910141,910143), (Sprinter, 907141,907143,907241,907243,907145,907245), (Sprinter, 907743,90745,907747), (Sprinter, 907), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 907633,907635,907637), (Sprinter, 907133,907135,907233,907235), (Sprinter, 907643,907645,907647), (Sprinter, 907143,907145,907243,907245), (Sprinter, 907733,907735), (Sprinter, 910631,910633,910621,910623), (Sprinter, 907631,907633,907635,907637), (Sprinter, 910040,910141,910143,910145,910641,910643), (Sprinter, 910153,910155,910253,910255), (Sprinter, 910631,910633,910635,910637), (V-Klasse, 639811,639813,639815), (V-Klasse, 639711,639713,639811,639813), (V-Klasse, 639701,639703,639705), (V-Klasse, 639601,639603,639605), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse, 207403,207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721,907723), (Sprinter, 907843), (Sprinter, 907141,907143), (Sprinter, 907143,907145,907243,907245,907141), (Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter, 910143,910145,910243,910245), (Sprinter, 910133,910135,910233,910235), (Sprinter, 910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter, 910133,910135,910233), (V-Klasse, 447701,447703,447705), (Sprinter, 907641,907643), (Sprinter, 907643,907645), (Sprinter, 910641,910643), (Sprinter, 910643,910645), (Sprinter, 907131,907133), (Sprinter, 910131,910133), (Sprinter, 907631,907633), (Sprinter, 907633,907635,907631,907637), (Sprinter, 910633,910635,910631,910637), (Sprinter, 907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223), (Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647), (Sprinter, 910633,910635,910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter, 907643,907641), (V-Klasse, 447601,447603,447605), (B-Klasse, 247010))

Resetting learned values of steering angle sensor ((GLK-Klasse, 204990))

Adjusting the headlights ((EQB, 243708))

Initializing pre-programmed keys ((SLK/SLC-Klasse, 172466), (SLK/SLC-Klasse, 172435), (GLE-Klasse, 166073))



Diagnostic devices

Initializing the fuel quantity adjuster ((Sprinter, 906131, 906133, 906135, 906231, 906233, 906235, 906631, 906633, 906635, 906637, 906731, 906733, 906735), (Sprinter, 906731, 906733, 906735), (Sprinter, 906153, 906155, 906253, 906255), (Sprinter, 906131, 906133, 906135, 906231, 906233, 906235), (Sprinter, 906711, 906713), (Sprinter, 906611, 906613), (Sprinter, 906653, 906655, 906657), (Sprinter, 906631, 906633, 906635, 906637), (Sprinter, 906111, 906113, 906211, 906213), (Sprinter, 906153, 906155, 906253, 906255, 906653, 906655, 906657), (Sprinter, 906735, 906737), (Sprinter, 906153, 906155, 906253, 906255, 906653, 906655, 906657), (Sprinter, 910621, 910623), (Sprinter, 910121, 910123), (Sprinter, 910631, 910633), (Sprinter, 910141, 910143, 910145, 910241, 910243), (Sprinter, 910643, 910641), (Sprinter, 910131, 910133, 910135, 910231, 910233), (Sprinter, 907621, 907623), (Sprinter, 907141, 907143, 907145, 907241, 907243), (Sprinter, 907153, 907155, 907253, 907255), (Sprinter, 907653, 907655, 907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731, 907733, 907735), (Sprinter, 910141, 910143), (Sprinter, 907141, 907143, 907241, 907243, 907145, 907245), (Sprinter, 907743, 90745, 907747), (Sprinter, 907), (Sprinter, 907131, 907133, 907135, 907231, 907233), (Sprinter, 907633, 907635, 907637), (Sprinter, 907133, 907135, 907233, 907235), (Sprinter, 907643, 907645, 907647), (Sprinter, 907143, 907145, 907243, 907245), (Sprinter, 907733, 907735), (Sprinter, 910631, 910633, 910621, 910623), (Sprinter, 907631, 907633, 907635, 907637), (Sprinter, 910040, 910141, 910143, 910143, 910641, 910643), (Sprinter, 910153, 910155, 910253, 910255), (Sprinter, 910631, 910633, 910635, 910637), (V-Klasse, 639811, 639813, 639815), (V-Klasse, 639711, 639713, 639811, 639813), (V-Klasse, 639701, 639703, 639705), (V-Klasse, 639601, 639603, 639605), (E-Klasse, 207426), (E-Klasse, 207401, 207402), (E-Klasse, 207403, 207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721, 907723), (Sprinter, 907843), (Sprinter, 907141, 907143), (Sprinter, 907143, 907145, 907243, 907245, 907141), (Sprinter, 907143, 907145, 907243, 907141, 907241), (Sprinter, 907855, 907857), (Sprinter, 910143, 910145, 910243, 910245), (Sprinter, 910133, 910135, 910233, 910235), (Sprinter, 910143, 910145, 910243, 910241), (Sprinter, 907133, 907135, 907233), (Sprinter, 910133, 910135, 910233), (V-Klasse, 447701, 447703, 447705), (Sprinter, 907641, 907643), (Sprinter, 907643, 907645), (Sprinter, 907131, 907133), (Sprinter, 910131, 910133), (Sprinter, 907631, 907633), (Sprinter, 907633, 907635, 907631, 907637), (Sprinter, 910633, 910635, 910631, 910637), (Sprinter, 907121, 907123), (Sprinter, 907123, 907221, 907223), (Sprinter, 910123, 910221, 910223), (Sprinter, 907221, 907223), (Sprinter, 910221, 910223), (Sprinter, 910643, 910645, 910647), (Sprinter, 910633, 910635, 910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter, 907643, 907641), (V-Klasse, 447601, 447603, 447605), (B-Klasse, 247010))

Initializing the adaptive cruise control ((Sprinter, 910141, 910143), (Sprinter, 910631, 910633, 910621, 910623), (Sprinter, 910153, 910155, 910253, 910255), (Sprinter, 907633, 907635, 907637), (Sprinter, 907731, 907733, 907735), (Sprinter, 907733, 907735), (Sprinter, 907721, 907723), (Sprinter, 907843), (Sprinter, 907643, 907645, 907647), (Sprinter, 907143, 907145, 907243, 907245), (Sprinter, 907143, 907145, 907243, 907141, 907241), (Sprinter, 907855, 907857), (Sprinter, 907653, 907655, 907657), (Sprinter, 907153, 907155, 907253, 907255), (Sprinter, 910143, 910145, 910243, 910245), (Sprinter, 907133, 907135, 907233, 907235), (Sprinter, 910133, 910135, 910233, 910235), (Sprinter, 910143, 910145, 910243, 910241), (Sprinter, 907133, 907135, 907233), (Sprinter, 910133, 910135, 910233), (Sprinter, 907131, 907133, 907135, 907231, 907233), (Sprinter, 910131, 910133, 910135, 910231, 910233), (Sprinter, 907221, 907223), (Sprinter, 910221, 910223), (Sprinter, 910643, 910645, 910647), (Sprinter, 910633, 910635, 910637), (Sprinter, 907643))

HFM drift compensation ((Sprinter, 906131, 906133, 906135, 906231, 906233, 906235, 906631, 906633, 906635, 906637, 906731, 906733, 906735), (Sprinter, 906731, 906733, 906735), (Sprinter, 906153, 906155, 906253, 906255), (Sprinter, 906131, 906133, 906135, 906231, 906233, 906235), (Sprinter, 906711, 906713), (Sprinter, 906611, 906613), (Sprinter, 906653, 906655, 906657), (Sprinter,



Diagnostic devices

906631,906633,906635,906637), (Sprinter, 906111,906113,906211,906213), (Sprinter, 906),
(Sprinter, 906735,906737), (Sprinter,
906153,906155,906253,906255,906653,906655,906657), (Sprinter, 910621,910623),
(Sprinter, 910121,910123), (Sprinter, 910631,910633), (Sprinter,
910141,910143,910145,910241,910243), (Sprinter, 910643,910641), (Sprinter,
910131,910133,910135,910231,910233), (Sprinter, 907621,907623), (Sprinter,
907141,907143,907145,907241,907243), (Sprinter, 907153,907155,907253,907255),
(Sprinter, 907653,907655,907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter,
907731,907733,907735), (Sprinter, 910141,910143), (Sprinter,
907141,907143,907241,907243,907145,907245), (Sprinter, 907743,90745,907747), (Sprinter,
907), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 907633,907635,907637),
(Sprinter, 907133,907135,907233,907235), (Sprinter, 907643,907645,907647), (Sprinter,
907143,907145,907243,907245), (Sprinter, 907733,907735), (Sprinter,
910631,910633,910621,910623), (Sprinter, 907631,907633,907635,907637), (Sprinter,
910040,910141,910143,910143,910641,910643), (Sprinter, 910153,910155,910253,910255),
(Sprinter, 910631,910633,910635,910637), (V-Klasse, 639811,639813,639815), (V-Klasse,
639711,639713,639811,639813), (V-Klasse, 639701,639703,639705), (V-Klasse,
639601,639603,639605), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse,
207403,207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse,
213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721,907723), (Sprinter,
907843), (Sprinter, 907141,907143), (Sprinter, 907143,907145,907243,907245,907141),
(Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter,
910143,910145,910243,910245), (Sprinter, 910133,910135,910233,910235), (Sprinter,
910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter,
910133,910135,910233), (V-Klasse, 447701,447703,447705), (Sprinter, 907641,907643),
(Sprinter, 907643,907645), (Sprinter, 910641,910643), (Sprinter, 910643,910645), (Sprinter,
907131,907133), (Sprinter, 910131,910133), (Sprinter, 907631,907633), (Sprinter,
907633,907635,907631,907637), (Sprinter, 910633,910635,910631,910637), (Sprinter,
907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223),
(Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647),
(Sprinter, 910633,910635,910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter,
907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter,
907643,907641), (V-Klasse, 447601,447603,447605), (B-Klasse, 247010))

Activating the fuel pump ((Sprinter,
906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,9067
33,906735), (Sprinter, 906731,906733,906735), (Sprinter, 906153,906155,906253,906255),
(Sprinter, 906131,906133,906135,906231,906233,906235), (Sprinter, 906711,906713),
(Sprinter, 906611,906613), (Sprinter, 906653,906655,906657), (Sprinter,
906631,906633,906635,906637), (Sprinter, 906111,906113,906211,906213), (Sprinter, 906),
(Sprinter, 906735,906737), (Sprinter,
906153,906155,906253,906255,906653,906655,906657), (Sprinter, 910621,910623),
(Sprinter, 910121,910123), (Sprinter, 910631,910633), (Sprinter,
910141,910143,910145,910241,910243), (Sprinter, 910643,910641), (Sprinter,
910131,910133,910135,910231,910233), (Sprinter, 907621,907623), (Sprinter,
907141,907143,907145,907241,907243), (Sprinter, 907153,907155,907253,907255),
(Sprinter, 907653,907655,907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter,
907731,907733,907735), (Sprinter, 910141,910143), (Sprinter,
907141,907143,907241,907243,907145,907245), (Sprinter, 907743,90745,907747), (Sprinter,
907), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 907633,907635,907637),
(Sprinter, 907133,907135,907233,907235), (Sprinter, 907643,907645,907647), (Sprinter,
907143,907145,907243,907245), (Sprinter, 907733,907735), (Sprinter,
910631,910633,910621,910623), (Sprinter, 907631,907633,907635,907637), (Sprinter,
910040,910141,910143,910143,910641,910643), (Sprinter, 910153,910155,910253,910255),
(Sprinter, 910631,910633,910635,910637), (V-Klasse, 639811,639813,639815), (V-Klasse,
639711,639713,639811,639813), (V-Klasse, 639701,639703,639705), (V-Klasse,
639601,639603,639605), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse,
207403,207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse,



Diagnostic devices

213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721,907723), (Sprinter, 907843), (Sprinter, 907141,907143), (Sprinter, 907143,907145,907243,907245,907141), (Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter, 910143,910145,910243,910245), (Sprinter, 910133,910135,910233,910235), (Sprinter, 910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter, 910133,910135,910233), (V-Klasse, 447701,447703,447705), (Sprinter, 907641,907643), (Sprinter, 907643,907645), (Sprinter, 910641,910643), (Sprinter, 910643,910645), (Sprinter, 907131,907133), (Sprinter, 910131,910133), (Sprinter, 907631,907633), (Sprinter, 907633,907635,907631,907637), (Sprinter, 910633,910635,910631,910637), (Sprinter, 907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223), (Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647), (Sprinter, 910633,910635,910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter, 907643,907641), (V-Klasse, 447601,447603,447605), (B-Klasse, 247010))

Initializing the oxidation catalyst ((Sprinter, 906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,906733,906735), (Sprinter, 906731,906733,906735), (Sprinter, 906153,906155,906253,906255), (Sprinter, 906131,906133,906135,906231,906233,906235), (Sprinter, 906711,906713), (Sprinter, 906611,906613), (Sprinter, 906653,906655,906657), (Sprinter, 906631,906633,906635,906637), (Sprinter, 906111,906113,906211,906213), (Sprinter, 906), (Sprinter, 906735,906737), (Sprinter, 906153,906155,906253,906255,906653,906655,906657), (Sprinter, 910621,910623), (Sprinter, 910121,910123), (Sprinter, 910631,910633), (Sprinter, 910141,910143,910145,910241,910243), (Sprinter, 910643,910641), (Sprinter, 910131,910133,910135,910231,910233), (Sprinter, 907621,907623), (Sprinter, 907141,907143,907145,907241,907243), (Sprinter, 907153,907155,907253,907255), (Sprinter, 907653,907655,907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731,907733,907735), (Sprinter, 910141,910143), (Sprinter, 907141,907143,907241,907243,907145,907245), (Sprinter, 907743,90745,907747), (Sprinter, 907), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 907633,907635,907637), (Sprinter, 907133,907135,907233,907235), (Sprinter, 907643,907645,907647), (Sprinter, 907143,907145,907243,907245), (Sprinter, 907733,907735), (Sprinter, 910631,910633,910621,910623), (Sprinter, 907631,907633,907635,907637), (Sprinter, 910040,910141,910143,910143,910641,910643), (Sprinter, 910153,910155,910253,910255), (Sprinter, 910631,910633,910635,910637), (V-Klasse, 639811,639813,639815), (V-Klasse, 639711,639713,639811,639813), (V-Klasse, 639701,639703,639705), (V-Klasse, 639601,639603,639605), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse, 207403,207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721,907723), (Sprinter, 907843), (Sprinter, 907141,907143), (Sprinter, 907143,907145,907243,907245,907141), (Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter, 910143,910145,910243,910245), (Sprinter, 910133,910135,910233,910235), (Sprinter, 910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter, 910133,910135,910233), (V-Klasse, 447701,447703,447705), (Sprinter, 907641,907643), (Sprinter, 907643,907645), (Sprinter, 910641,910643), (Sprinter, 910643,910645), (Sprinter, 907131,907133), (Sprinter, 910131,910133), (Sprinter, 907631,907633), (Sprinter, 907633,907635,907631,907637), (Sprinter, 910633,910635,910631,910637), (Sprinter, 907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223), (Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647), (Sprinter, 910633,910635,910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter, 907643,907641), (V-Klasse, 447601,447603,447605), (B-Klasse, 247010))

Learning the lambda sensor ((Sprinter, 906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,906733,906735), (Sprinter, 906731,906733,906735), (Sprinter, 906153,906155,906253,906255), (Sprinter, 906131,906133,906135,906231,906233,906235), (Sprinter, 906711,906713), (Sprinter, 906611,906613), (Sprinter, 906653,906655,906657), (Sprinter,



Diagnostic devices

906631,906633,906635,906637), (Sprinter, 906111,906113,906211,906213), (Sprinter, 906),
(Sprinter, 906735,906737), (Sprinter,
906153,906155,906253,906255,906653,906655,906657), (Sprinter, 910621,910623),
(Sprinter, 910121,910123), (Sprinter, 910631,910633), (Sprinter,
910141,910143,910145,910241,910243), (Sprinter, 910643,910641), (Sprinter,
910131,910133,910135,910231,910233), (Sprinter, 907621,907623), (Sprinter,
907141,907143,907145,907241,907243), (Sprinter, 907153,907155,907253,907255),
(Sprinter, 907653,907655,907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter,
907731,907733,907735), (Sprinter, 910141,910143), (Sprinter,
907141,907143,907241,907243,907145,907245), (Sprinter, 907743,90745,907747), (Sprinter,
907), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 907633,907635,907637),
(Sprinter, 907133,907135,907233,907235), (Sprinter, 907643,907645,907647), (Sprinter,
907143,907145,907243,907245), (Sprinter, 907733,907735), (Sprinter,
910631,910633,910621,910623), (Sprinter, 907631,907633,907635,907637), (Sprinter,
910040,910141,910143,910143,910641,910643), (Sprinter, 910153,910155,910253,910255),
(Sprinter, 910631,910633,910635,910637), (V-Klasse, 639811,639813,639815), (V-Klasse,
639711,639713,639811,639813), (V-Klasse, 639701,639703,639705), (V-Klasse,
639601,639603,639605), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse,
207403,207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse,
213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721,907723), (Sprinter,
907843), (Sprinter, 907141,907143), (Sprinter, 907143,907145,907243,907245,907141),
(Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter,
910143,910145,910243,910245), (Sprinter, 910133,910135,910233,910235), (Sprinter,
910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter,
910133,910135,910233), (V-Klasse, 447701,447703,447705), (Sprinter, 907641,907643),
(Sprinter, 907643,907645), (Sprinter, 910641,910643), (Sprinter, 910643,910645), (Sprinter,
907131,907133), (Sprinter, 910131,910133), (Sprinter, 907631,907633), (Sprinter,
907633,907635,907631,907637), (Sprinter, 910633,910635,910631,910637), (Sprinter,
907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223),
(Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647),
(Sprinter, 910633,910635,910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter,
907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter,
907643,907641), (V-Klasse, 447601,447603,447605), (B-Klasse, 247010))

Bleeding the fuel system ((Sprinter,
906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,9067
33,906735), (Sprinter, 906731,906733,906735), (Sprinter, 906153,906155,906253,906255),
(Sprinter, 906131,906133,906135,906231,906233,906235), (Sprinter, 906711,906713),
(Sprinter, 906611,906613), (Sprinter, 906653,906655,906657), (Sprinter,
906631,906633,906635,906637), (Sprinter, 906111,906113,906211,906213), (Sprinter, 906),
(Sprinter, 906735,906737), (Sprinter,
906153,906155,906253,906255,906653,906655,906657), (Sprinter, 910621,910623),
(Sprinter, 910121,910123), (Sprinter, 910631,910633), (Sprinter,
910141,910143,910145,910241,910243), (Sprinter, 910643,910641), (Sprinter,
910131,910133,910135,910231,910233), (Sprinter, 907621,907623), (Sprinter,
907141,907143,907145,907241,907243), (Sprinter, 907153,907155,907253,907255),
(Sprinter, 907653,907655,907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter,
907731,907733,907735), (Sprinter, 910141,910143), (Sprinter,
907141,907143,907241,907243,907145,907245), (Sprinter, 907743,90745,907747), (Sprinter,
907), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 907633,907635,907637),
(Sprinter, 907133,907135,907233,907235), (Sprinter, 907643,907645,907647), (Sprinter,
907143,907145,907243,907245), (Sprinter, 907733,907735), (Sprinter,
910631,910633,910621,910623), (Sprinter, 907631,907633,907635,907637), (Sprinter,
910040,910141,910143,910143,910641,910643), (Sprinter, 910153,910155,910253,910255),
(Sprinter, 910631,910633,910635,910637), (V-Klasse, 639811,639813,639815), (V-Klasse,
639711,639713,639811,639813), (V-Klasse, 639701,639703,639705), (V-Klasse,
639601,639603,639605), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse,
207403,207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse,



Diagnostic devices

213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721,907723), (Sprinter, 907843), (Sprinter, 907141,907143), (Sprinter, 907143,907145,907243,907245,907141), (Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter, 910143,910145,910243,910245), (Sprinter, 910133,910135,910233,910235), (Sprinter, 910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter, 910133,910135,910233), (V-Klasse, 447701,447703,447705), (Sprinter, 907641,907643), (Sprinter, 907643,907645), (Sprinter, 910641,910643), (Sprinter, 910643,910645), (Sprinter, 907131,907133), (Sprinter, 910131,910133), (Sprinter, 907631,907633), (Sprinter, 907633,907635,907631,907637), (Sprinter, 910633,910635,910631,910637), (Sprinter, 907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223), (Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647), (Sprinter, 910633,910635,910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter, 907643,907641), (V-Klasse, 447601,447603,447605), (B-Klasse, 247010))

Initializing the soot particulate filter upon engine ECU replacement ((Sprinter, 906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,906733,906735), (Sprinter, 906731,906733,906735), (Sprinter, 906153,906155,906253,906255), (Sprinter, 906131,906133,906135,906231,906233,906235), (Sprinter, 906711,906713), (Sprinter, 906611,906613), (Sprinter, 906653,906655,906657), (Sprinter, 906631,906633,906635,906637), (Sprinter, 906111,906113,906211,906213), (Sprinter, 906), (Sprinter, 906735,906737), (Sprinter, 906153,906155,906253,906255,906257,906259), (Sprinter, 906121,910123), (Sprinter, 910631,910633), (Sprinter, 910141,910143,910145,910241,910243), (Sprinter, 910643,910641), (Sprinter, 910131,910133,910135,910231,910233), (Sprinter, 907621,907623), (Sprinter, 907141,907143,907145,907241,907243), (Sprinter, 907153,907155,907253,907255), (Sprinter, 907653,907655,907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731,907733,907735), (Sprinter, 910141,910143), (Sprinter, 907141,907143,907241,907243,907145,907245), (Sprinter, 907743,90745,907747), (Sprinter, 907), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 907633,907635,907637), (Sprinter, 907133,907135,907233,907235), (Sprinter, 907643,907645,907647), (Sprinter, 907143,907145,907243,907245), (Sprinter, 907733,907735), (Sprinter, 910631,910633,910621,910623), (Sprinter, 907631,907633,907635,907637), (Sprinter, 910040,910141,910143,910143,910641,910643), (Sprinter, 910153,910155,910253,910255), (Sprinter, 910631,910633,910635,910637), (V-Klasse, 639811,639813,639815), (V-Klasse, 639711,639713,639811,639813), (V-Klasse, 639701,639703,639705), (V-Klasse, 639601,639603,639605), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse, 207403,207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721,907723), (Sprinter, 907843), (Sprinter, 907141,907143), (Sprinter, 907143,907145,907243,907245,907141), (Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter, 910143,910145,910243,910245), (Sprinter, 910133,910135,910233,910235), (Sprinter, 910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter, 910133,910135,910233), (V-Klasse, 447701,447703,447705), (Sprinter, 907641,907643), (Sprinter, 907643,907645), (Sprinter, 910641,910643), (Sprinter, 910643,910645), (Sprinter, 907131,907133), (Sprinter, 910131,910133), (Sprinter, 907631,907633), (Sprinter, 907633,907635,907631,907637), (Sprinter, 910633,910635,910631,910637), (Sprinter, 907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223), (Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647), (Sprinter, 910633,910635,910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter, 907643,907641), (V-Klasse, 447601,447603,447605), (B-Klasse, 247010))

Initializing the high-pressure fuel pump and the fuel rail ((Sprinter, 906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,906733,906735), (Sprinter, 906731,906733,906735), (Sprinter, 906153,906155,906253,906255), (Sprinter, 906131,906133,906135,906231,906233,906235), (Sprinter, 906711,906713), (Sprinter, 906611,906613), (Sprinter, 906653,906655,906657), (Sprinter,



Diagnostic devices

906631,906633,906635,906637), (Sprinter, 906111,906113,906211,906213), (Sprinter, 906),
(Sprinter, 906735,906737), (Sprinter,
906153,906155,906253,906255,906653,906655,906657))

Initializing the boost pressure regulator ((Sprinter,
906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,9067
33,906735), (Sprinter, 906731,906733,906735), (Sprinter, 906153,906155,906253,906255),
(Sprinter, 906131,906133,906135,906231,906233,906235), (Sprinter, 906711,906713),
(Sprinter, 906611,906613), (Sprinter, 906653,906655,906657), (Sprinter,
906631,906633,906635,906637), (Sprinter, 906111,906113,906211,906213), (Sprinter, 906),
(Sprinter, 906735,906737), (Sprinter,
906153,906155,906253,906255,906653,906655,906657), (Sprinter, 910621,910623),
(Sprinter, 910121,910123), (Sprinter, 910631,910633), (Sprinter,
910141,910143,910145,910241,910243), (Sprinter, 910643,910641), (Sprinter,
910131,910133,910135,910231,910233), (Sprinter, 907621,907623), (Sprinter,
907141,907143,907145,907241,907243), (Sprinter, 907153,907155,907253,907255),
(Sprinter, 907653,907655,907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter,
907731,907733,907735), (Sprinter, 910141,910143), (Sprinter,
907141,907143,907241,907243,907145,907245), (Sprinter, 907743,90745,907747), (Sprinter,
907), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 907633,907635,907637),
(Sprinter, 907133,907135,907233,907235), (Sprinter, 907643,907645,907647), (Sprinter,
907143,907145,907243,907245), (Sprinter, 907733,907735), (Sprinter,
910631,910633,910621,910623), (Sprinter, 907631,907633,907635,907637), (Sprinter,
910040,910141,910143,910143,910641,910643), (Sprinter, 910153,910155,910253,910255),
(Sprinter, 910631,910633,910635,910637), (V-Klasse, 639811,639813,639815), (V-Klasse,
639711,639713,639811,639813), (V-Klasse, 639701,639703,639705), (V-Klasse,
639601,639603,639605), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse,
207403,207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse,
213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721,907723), (Sprinter,
907843), (Sprinter, 907141,907143), (Sprinter, 907143,907145,907243,907245,907141),
(Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter,
910143,910145,910243,910245), (Sprinter, 910133,910135,910233,910235), (Sprinter,
910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter,
910133,910135,910233), (V-Klasse, 447701,447703,447705), (Sprinter, 907641,907643),
(Sprinter, 907643,907645), (Sprinter, 910641,910643), (Sprinter, 910643,910645), (Sprinter,
907131,907133), (Sprinter, 910131,910133), (Sprinter, 907631,907633), (Sprinter,
907633,907635,907631,907637), (Sprinter, 910633,910635,910631,910637), (Sprinter,
907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223),
(Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647),
(Sprinter, 910633,910635,910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter,
907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter,
907643,907641), (V-Klasse, 447601,447603,447605), (B-Klasse, 247010))

Calibrating the steering-angle sensor ((GLE-Klasse, 166073))

Learning the steering-angle sensor ((GLK-Klasse, 204990))

Resetting air filter learned values ((Sprinter,
906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,9067
33,906735), (Sprinter, 906731,906733,906735), (Sprinter, 906153,906155,906253,906255),
(Sprinter, 906131,906133,906135,906231,906233,906235), (Sprinter, 906711,906713),
(Sprinter, 906611,906613), (Sprinter, 906653,906655,906657), (Sprinter,
906631,906633,906635,906637), (Sprinter, 906111,906113,906211,906213), (Sprinter, 906),
(Sprinter, 906735,906737), (Sprinter,
906153,906155,906253,906255,906653,906655,906657), (Sprinter, 910621,910623),
(Sprinter, 910121,910123), (Sprinter, 910631,910633), (Sprinter,
910141,910143,910145,910241,910243), (Sprinter, 910643,910641), (Sprinter,
910131,910133,910135,910231,910233), (Sprinter, 907621,907623), (Sprinter,
907141,907143,907145,907241,907243), (Sprinter, 907153,907155,907253,907255),
(Sprinter, 907653,907655,907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter,



Diagnostic devices

907731,907733,907735), (Sprinter, 910141,910143), (Sprinter, 907141,907143,907241,907243,907145,907245), (Sprinter, 907743,90745,907747), (Sprinter, 907), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 907633,907635,907637), (Sprinter, 907133,907135,907233,907235), (Sprinter, 907643,907645,907647), (Sprinter, 907143,907145,907243,907245), (Sprinter, 907733,907735), (Sprinter, 910631,910633,910621,910623), (Sprinter, 907631,907633,907635,907637), (Sprinter, 910040,910141,910143,910143,910641,910643), (Sprinter, 910153,910155,910253,910255), (Sprinter, 910631,910633,910635,910637), (V-Klasse, 639811,639813,639815), (V-Klasse, 639711,639713,639811,639813), (V-Klasse, 639701,639703,639705), (V-Klasse, 639601,639603,639605), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse, 207403,207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721,907723), (Sprinter, 907843), (Sprinter, 907141,907143), (Sprinter, 907143,907145,907243,907245,907141), (Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter, 910143,910145,910243,910245), (Sprinter, 910133,910135,910233,910235), (Sprinter, 910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter, 910133,910135,910233), (V-Klasse, 447701,447703,447705), (Sprinter, 907641,907643), (Sprinter, 907643,907645), (Sprinter, 907131,907133), (Sprinter, 910131,910133), (Sprinter, 907631,907633), (Sprinter, 907633,907635,907631,907637), (Sprinter, 910633,910635,910635,910631,910637), (Sprinter, 907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223), (Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647), (Sprinter, 910633,910635,910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter, 907643,907641), (V-Klasse, 447601,447603,447605), (B-Klasse, 247010))

Learning throttle valve stop ((Sprinter, 906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,906733,906735), (Sprinter, 906731,906733,906735), (Sprinter, 906153,906155,906253,906255), (Sprinter, 906131,906133,906135,906231,906233,906235), (Sprinter, 906711,906713), (Sprinter, 906611,906613), (Sprinter, 906653,906655,906657), (Sprinter, 906631,906633,906635,906637), (Sprinter, 906111,906113,906211,906213), (Sprinter, 906), (Sprinter, 906735,906737), (Sprinter, 906153,906155,906253,906255,906653,906655,906657), (Sprinter, 910621,910623), (Sprinter, 910121,910123), (Sprinter, 910631,910633), (Sprinter, 910141,910143,910145,910241,910243), (Sprinter, 910643,910641), (Sprinter, 910131,910133,910135,910231,910233), (Sprinter, 907621,907623), (Sprinter, 907141,907143,907145,907241,907243), (Sprinter, 907153,907155,907253,907255), (Sprinter, 907653,907655,907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731,907733,907735), (Sprinter, 910141,910143), (Sprinter, 907141,907143,907241,907243,907145,907245), (Sprinter, 907743,90745,907747), (Sprinter, 907), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 907633,907635,907637), (Sprinter, 907133,907135,907233,907235), (Sprinter, 907643,907645,907647), (Sprinter, 907143,907145,907243,907245), (Sprinter, 907733,907735), (Sprinter, 910631,910633,910621,910623), (Sprinter, 907631,907633,907635,907637), (Sprinter, 910040,910141,910143,910143,910641,910643), (Sprinter, 910153,910155,910253,910255), (Sprinter, 910631,910633,910635,910637), (V-Klasse, 639811,639813,639815), (V-Klasse, 639711,639713,639811,639813), (V-Klasse, 639701,639703,639705), (V-Klasse, 639601,639603,639605), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse, 207403,207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (GLK-Klasse, 204990), (Sprinter, 907721,907723), (Sprinter, 907843), (Sprinter, 907141,907143), (Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter, 910143,910145,910243,910245), (Sprinter, 910133,910135,910233,910235), (Sprinter, 910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter, 910133,910135,910233), (V-Klasse, 447701,447703,447705), (Sprinter, 907641,907643), (Sprinter, 907643,907645), (Sprinter, 910641,910643), (Sprinter, 910643,910645), (Sprinter, 907131,907133), (Sprinter,



Diagnostic devices

910131,910133), (Sprinter, 907631,907633), (Sprinter, 907633,907635,907631,907637), (Sprinter, 910633,910635,910631,910637), (Sprinter, 907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223), (Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647), (Sprinter, 910633,910635,910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter, 907643,907641), (V-Klasse, 447601,447603,447605), (B-Klasse, 247010))

Adapting the exhaust gas flap actuator ((Sprinter, 906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,906733,906735), (Sprinter, 906731,906733,906735), (Sprinter, 906153,906155,906253,906255), (Sprinter, 906131,906133,906135,906231,906233,906235), (Sprinter, 906711,906713), (Sprinter, 906611,906613), (Sprinter, 906653,906655,906657), (Sprinter, 906631,906633,906635,906637), (Sprinter, 906111,906113,906211,906213), (Sprinter, 906, (Sprinter, 906735,906737), (Sprinter, 906153,906155,906253,906255,906653,906655,906657), (Sprinter, 910621,910623), (Sprinter, 910121,910123), (Sprinter, 910631,910633), (Sprinter, 910141,910143,910145,910241,910243), (Sprinter, 910643,910641), (Sprinter, 910131,910133,910135,910231,910233), (Sprinter, 907621,907623), (Sprinter, 907141,907143,907145,907241,907243), (Sprinter, 907153,907155,907253,907255), (Sprinter, 907653,907655,907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731,907733,907735), (Sprinter, 910141,910143), (Sprinter, 907141,907143,907241,907243,907145,907245), (Sprinter, 907743,90745,907747), (Sprinter, 907), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 907633,907635,907637), (Sprinter, 907133,907135,907233,907235), (Sprinter, 907643,907645,907647), (Sprinter, 907143,907145,907243,907245), (Sprinter, 907733,907735), (Sprinter, 910631,910633,910621,910623), (Sprinter, 907631,907633,907635,907637), (Sprinter, 910040,910141,910143,910143,910641,910643), (Sprinter, 910153,910155,910253,910255), (Sprinter, 910631,910633,910635,910637), (V-Klasse, 639811,639813,639815), (V-Klasse, 639711,639713,639811,639813), (V-Klasse, 639701,639703,639705), (V-Klasse, 639601,639603,639605), (V-Klasse, 447601,447603,447605), (V-Klasse, 447701,447703,447705), (V-Klasse, 447811,447813,447815,447815), (V-Klasse, 447703,447813), (V-Klasse, 447811,447813,447815,447803), (V-Klasse, 447705,447701,447703), (V-Klasse, 447811,447813,447801,447803), (V-Klasse, 447815,447813,447811), (V-Klasse, 447811,447813,447801,447803), (V-Klasse, 447701,447702,447703,447704,447705), (V-Klasse, 447811,447812,447813,447814,447815), (V-Klasse, 447703,477813), (V-Klasse, 447701,447703), (V-Klasse, 447), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse, 207403,207404), (E-Klasse, 207326), (V-Klasse, 447701,447703,447705,), (V-Klasse, 447811,447813), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721,907723), (Sprinter, 907843), (Sprinter, 907141,907143), (Sprinter, 907143,907145,907243,907245,907141), (Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter, 910143,910145,910243,910245), (Sprinter, 910133,910135,910233,910235), (Sprinter, 910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter, 910133,910135,910233), (Sprinter, 907641,907643), (Sprinter, 907643,907645), (Sprinter, 910641,910643), (Sprinter, 910643,910645), (Sprinter, 907131,907133), (Sprinter, 910131,910133), (Sprinter, 907631,907633), (Sprinter, 907633,907635,907631,907637), (Sprinter, 910633,910635,910631,910637), (Sprinter, 907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223), (Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647), (Sprinter, 910633,910635,910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (Sprinter, 907643,907641), (B-Klasse, 247010))

Initializing diesel exhaust fluid fluid level sensor ((Sprinter, 910141,910143), (Sprinter, 910631,910633,910621,910623), (Sprinter, 910153,910155,910253,910255), (V-Klasse, 447701,447703,447705), (V-Klasse, 447815,447811,447813), (V-Klasse, 447711,447713), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse, 207403,207404), (E-Klasse, 207326), (B-Klasse, 247002), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223),



Diagnostic devices

(E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907633,907635,907637), (Sprinter, 907731,907733,907735), (Sprinter, 907733,907735), (Sprinter, 907721,907723), (Sprinter, 907843), (Sprinter, 907643,907645,907647), (Sprinter, 907143,907145,907243,907245), (Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter, 907653,907655,907657), (Sprinter, 907153,907155,907253,907255), (Sprinter, 910143,910145,910243,910245), (Sprinter, 907133,907135,907233,907235), (Sprinter, 910133,910135,910233,910235), (Sprinter, 910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter, 910133,910135,910233), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 910131,910133,910135,910231,910233), (Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647), (Sprinter, 910633,910635,910637), (E-Klasse, 213216), (GLE-Klasse, 166073), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (V-Klasse, 447601,447603,447605), (B-Klasse, 247010))

Initializing the A/C flap actuators ((SLK/SLC-Klasse, 172466), (SLK/SLC-Klasse, 172435))

Initializing the exhaust temperature sensor ((Sprinter, 906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,906733,906735), (Sprinter, 906731,906733,906735), (Sprinter, 906153,906155,906253,906255), (Sprinter, 906131,906133,906135,906231,906233,906235), (Sprinter, 906711,906713), (Sprinter, 906611,906613), (Sprinter, 906653,906655,906657), (Sprinter, 906631,906633,906635,906637), (Sprinter, 906111,906113,906211,906213), (Sprinter, 906, (Sprinter, 906735,906737), (Sprinter, 906153,906155,906253,906255,906653,906655,906657), (Sprinter, 910621,910623), (Sprinter, 910121,910123), (Sprinter, 910631,910633), (Sprinter, 910141,910143,910145,910241,910243), (Sprinter, 910643,910641), (Sprinter, 910131,910133,910135,910231,910233), (Sprinter, 907621,907623), (Sprinter, 907141,907143,907145,907241,907243), (Sprinter, 907153,907155,907253,907255), (Sprinter, 907653,907655,907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731,907733,907735), (Sprinter, 910141,910143), (Sprinter, 907141,907143,907241,907243,907145,907245), (Sprinter, 907743,90745,907747), (Sprinter, 907), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 907633,907635,907637), (Sprinter, 907133,907135,907233,907235), (Sprinter, 907643,907645,907647), (Sprinter, 907143,907145,907243,907245), (Sprinter, 907733,907735), (Sprinter, 910631,910633,910621,910623), (Sprinter, 907631,907633,907635,907637), (Sprinter, 910040,910141,910143,910143,910641,910643), (Sprinter, 910153,910155,910253,910255), (Sprinter, 910631,910633,910635,910637), (V-Klasse, 639811,639813,639815), (V-Klasse, 639711,639713,639811,639813), (V-Klasse, 639701,639703,639705), (V-Klasse, 639601,639603,639605), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse, 207403,207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721,907723), (Sprinter, 907843), (Sprinter, 907141,907143), (Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter, 910143,910145,910243,910245), (Sprinter, 910133,910135,910233,910235), (Sprinter, 910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter, 910133,910135,910233), (V-Klasse, 447701,447703,447705), (Sprinter, 907641,907643), (Sprinter, 907643,907645), (Sprinter, 910643,910645), (Sprinter, 907131,907133), (Sprinter, 910131,910133), (Sprinter, 907631,907633), (Sprinter, 907633,907635,907631,907637), (Sprinter, 910633,910635,910631,910637), (Sprinter, 907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223), (Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647), (Sprinter, 910633,910635,910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter, 907643,907641), (V-Klasse, 447601,447603,447605), (B-Klasse, 247010))

Calibrating the front camera ((CLS-Klasse, 257348), (CLS-Klasse, 257358))

Resetting high-pressure fuel pump adaptation values ((Sprinter, 906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,906733,906735), (Sprinter, 906731,906733,906735), (Sprinter, 906153,906155,906253,906255),



Diagnostic devices

(Sprinter, 906131,906133,906135,906231,906233,906235), (Sprinter, 906711,906713),
(Sprinter, 906611,906613), (Sprinter, 906653,906655,906657), (Sprinter,
906631,906633,906635,906637), (Sprinter, 906111,906113,906211,906213), (Sprinter, 906),
(Sprinter, 906735,906737), (Sprinter,
906153,906155,906253,906255,906653,906655,906657), (Sprinter, 910621,910623),
(Sprinter, 910121,910123), (Sprinter, 910631,910633), (Sprinter,
910141,910143,910145,910241,910243), (Sprinter, 910643,910641), (Sprinter,
910131,910133,910135,910231,910233), (Sprinter, 907621,907623), (Sprinter,
907141,907143,907145,907241,907243), (Sprinter, 907153,907155,907253,907255),
(Sprinter, 907653,907655,907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter,
907731,907733,907735), (Sprinter, 910141,910143), (Sprinter,
907141,907143,907241,907243,907145,907245), (Sprinter, 907743,90745,907747), (Sprinter,
907), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 907633,907635,907637),
(Sprinter, 907133,907135,907233,907235), (Sprinter, 907643,907645,907647), (Sprinter,
907143,907145,907243,907245), (Sprinter, 907733,907735), (Sprinter,
910631,910633,910621,910623), (Sprinter, 907631,907633,907635,907637), (Sprinter,
910040,910141,910143,910143,910641,910643), (Sprinter, 910153,910155,910253,910255),
(Sprinter, 910631,910633,910635,910637), (V-Klasse, 639811,639813,639815), (V-Klasse,
639711,639713,639811,639813), (V-Klasse, 639701,639703,639705), (V-Klasse,
639601,639603,639605), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse,
207403,207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse,
213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721,907723), (Sprinter,
907843), (Sprinter, 907141,907143), (Sprinter, 907143,907145,907243,907245,907141),
(Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter,
910143,910145,910243,910245), (Sprinter, 910133,910135,910233,910235), (Sprinter,
910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter,
910133,910135,910233), (V-Klasse, 447701,447703,447705), (Sprinter, 907641,907643),
(Sprinter, 907643,907645), (Sprinter, 910641,910643), (Sprinter, 910643,910645), (Sprinter,
907131,907133), (Sprinter, 910131,910133), (Sprinter, 907631,907633), (Sprinter,
907633,907635,907631,907637), (Sprinter, 910633,910635,910631,910637), (Sprinter,
907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223),
(Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647),
(Sprinter, 910633,910635,910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter,
907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter,
907643,907641), (V-Klasse, 447601,447603,447605), (B-Klasse, 247010))

Calibrating the camera ((E-Klasse, 213068), (E-Klasse, 213022), (E-Klasse, 213020), (E-
Klasse, 213223), (E-Klasse, 213227), (E-Klasse, 213268), (CLS-Klasse, 257348), (CLS-
Klasse, 257358), (E-Klasse, 238483), (GLK-Klasse, 204990), (E-Klasse, 213053,213050), (E-
Klasse, 213216), (E-Klasse, 213253))

Resetting the quantity mean value adaptation ((Sprinter,
906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,9067
33,906735), (Sprinter, 906731,906733,906735), (Sprinter, 906153,906155,906253,906255),
(Sprinter, 906131,906133,906135,906231,906233,906235), (Sprinter, 906711,906713),
(Sprinter, 906611,906613), (Sprinter, 906653,906655,906657), (Sprinter,
906631,906633,906635,906637), (Sprinter, 906111,906113,906211,906213), (Sprinter, 906),
(Sprinter, 906735,906737), (Sprinter,
906153,906155,906253,906255,906653,906655,906657), (Sprinter, 910621,910623),
(Sprinter, 910121,910123), (Sprinter, 910631,910633), (Sprinter,
910141,910143,910145,910241,910243), (Sprinter, 910643,910641), (Sprinter,
910131,910133,910135,910231,910233), (Sprinter, 907621,907623), (Sprinter,
907141,907143,907145,907241,907243), (Sprinter, 907153,907155,907253,907255),
(Sprinter, 907653,907655,907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter,
907731,907733,907735), (Sprinter, 910141,910143), (Sprinter,
907141,907143,907241,907243,907145,907245), (Sprinter, 907743,90745,907747), (Sprinter,
907), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 907633,907635,907637),
(Sprinter, 907133,907135,907233,907235), (Sprinter, 907643,907645,907647), (Sprinter,
907143,907145,907243,907245), (Sprinter, 907733,907735), (Sprinter,



Diagnostic devices

910631,910633,910621,910623), (Sprinter, 907631,907633,907635,907637), (Sprinter, 910040,910141,910143,910143,910641,910643), (Sprinter, 910153,910155,910253,910255), (Sprinter, 910631,910633,910635,910637), (V-Klasse, 639811,639813,639815), (V-Klasse, 639711,639713,639811,639813), (V-Klasse, 639701,639703,639705), (V-Klasse, 639601,639603,639605), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse, 207403,207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721,907723), (Sprinter, 907843), (Sprinter, 907141,907143), (Sprinter, 907143,907145,907243,907245,907141), (Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter, 910143,910145,910243,910245), (Sprinter, 910133,910135,910233,910235), (Sprinter, 910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter, 910133,910135,910233), (V-Klasse, 447701,447703,447705), (Sprinter, 907641,907643), (Sprinter, 907643,907645), (Sprinter, 907131,907133), (Sprinter, 910131,910133), (Sprinter, 907631,907633), (Sprinter, 907633,907635,907631,907637), (Sprinter, 910633,910635,910631,910637), (Sprinter, 907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223), (Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647), (Sprinter, 910633,910635,910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter, 907643,907641), (V-Klasse, 447601,447603,447605), (B-Klasse, 247010))

Actuating the installation/removal position of the parking brake ((E-Klasse, 213068), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (E-Klasse, 213268), (SLK/SLC-Klasse, 172466), (SLK/SLC-Klasse, 172435), (V-Klasse, 447701,447703,447705), (V-Klasse, 447603,447605), (V-Klasse, 447703), (V-Klasse, 447703,447705), (E-Klasse, 213053,213050), (E-Klasse, 213216), (GLE-Klasse, 166073), (E-Klasse, 213253), (V-Klasse, 447601,447603,447605))

Initializing the mass airflow sensor ((Sprinter, 910621,910623), (Sprinter, 910121,910123), (Sprinter, 910631,910633), (Sprinter, 910141,910143,910145,910241,910243), (Sprinter, 910643,910641), (Sprinter, 910131,910133,910135,910231,910233), (Sprinter, 907621,907623), (Sprinter, 907141,907143,907145,907241,907243), (Sprinter, 907153,907155,907253,907255), (Sprinter, 907653,907655,907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731,907733,907735), (Sprinter, 910141,910143), (Sprinter, 907141,907143,907241,907243,907145,907245), (Sprinter, 907743,90745,907747), (Sprinter, 907), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 907633,907635,907637), (Sprinter, 907133,907135,907233,907235), (Sprinter, 907643,907645,907647), (Sprinter, 907143,907145,907243,907245), (Sprinter, 907733,907735), (Sprinter, 910631,910633,910621,910623), (Sprinter, 907631,907633,907635,907637), (Sprinter, 910040,910141,910143,910143,910641,910643), (Sprinter, 910153,910155,910253,910255), (Sprinter, 910631,910633,910635,910637), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse, 207403,207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (Sprinter, 907721,907723), (Sprinter, 907843), (Sprinter, 907141,907143), (Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter, 910143,910145,910243,910245), (Sprinter, 910133,910135,910233,910235), (Sprinter, 910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter, 910133,910135,910233), (V-Klasse, 447701,447703,447705), (Sprinter, 907641,907643), (Sprinter, 907643,907645), (Sprinter, 910641,910643), (Sprinter, 910643,910645), (Sprinter, 907131,907133), (Sprinter, 910131,910133), (Sprinter, 907631,907633), (Sprinter, 907633,907635,907631,907637), (Sprinter, 910633,910635,910631,910637), (Sprinter, 907121,907123), (Sprinter, 907123,907221,907223), (Sprinter, 910123,910221,910223), (Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647), (Sprinter, 910633,910635,910637), (E-Klasse, 213216), (Sprinter, 910143), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (Sprinter, 907643,907641), (V-Klasse, 447601,447603,447605), (B-Klasse, 247010))



Diagnostic devices

Learning the actuators ((SLK/SLC-Klasse, 172466), (GLK-Klasse, 204990), (SLK/SLC-Klasse, 172435))

Calibrating the parking brake ((V-Klasse, 447701,447703,447705), (V-Klasse, 447603,447605), (V-Klasse, 447703), (V-Klasse, 447703,447705), (V-Klasse, 447601,447603,447605))

Codings

Coding the rain/light sensor of windshield ((E-Klasse, 213068), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse, 207403,207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (E-Klasse, 213268), (E-Klasse, 238483), (GLK-Klasse, 204990), (E-Klasse, 213053,213050), (E-Klasse, 213216), (E-Klasse, 213253))

Coding the rain/light sensor ((Sprinter, 910141,910143), (Sprinter, 910631,910633,910621,910623), (Sprinter, 910153,910155,910253,910255), (EQB, 243708), (B-Klasse, 247044), (B-Klasse, 247002), (GLA-Klasse, 247784), (GLA-Klasse, 247751), (SLK/SLC-Klasse, 172466), (CLS-Klasse, 257348), (CLS-Klasse, 257358), (GLE-Klasse, 167323), (SLK/SLC-Klasse, 172435), (Sprinter, 907633,907635,907637), (Sprinter, 907731,907733,907735), (Sprinter, 907733,907735), (Sprinter, 907721,907723), (Sprinter, 907843), (Sprinter, 907643,907645,907647), (Sprinter, 907143,907145,907243,907245), (Sprinter, 907143,907145,907243,907141,907241), (Sprinter, 907855,907857), (Sprinter, 907653,907655,907657), (Sprinter, 907153,907155,907253,907255), (Sprinter, 910143,910145,910243,910245), (Sprinter, 907133,907135,907233,907235), (Sprinter, 910133,910135,910233,910235), (Sprinter, 910143,910145,910243,910141,910241), (Sprinter, 907133,907135,907233), (Sprinter, 910133,910135,910233), (V-Klasse, 447701,447703,447705), (V-Klasse, 447603,447605), (V-Klasse, 447703), (V-Klasse, 447703,447705), (B-Klasse, 247087), (Sprinter, 907131,907133,907135,907231,907233), (Sprinter, 910131,910133,910135,910231,910233), (Sprinter, 907221,907223), (Sprinter, 910221,910223), (Sprinter, 910643,910645,910647), (Sprinter, 910633,910635,910637), (SL-Klasse, 231474), (Sprinter, 907643), (A-Klasse, 177010), (A-Klasse, 177110), (B-Klasse, 247088), (B-Klasse, 247086), (GLA-Klasse, 247788), (GLA-Klasse, 247786), (V-Klasse, 447601,447603,447605), (B-Klasse, 247010))

Registering the battery ((E-Klasse, 213068), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (E-Klasse, 213268), (E-Klasse, 238483), (E-Klasse, 213053,213050), (E-Klasse, 213216), (E-Klasse, 213253))

Coding injectors ((Sprinter, 906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,906733,906735), (Sprinter, 906731,906733,906735), (Sprinter, 906153,906155,906253,906255), (Sprinter, 906131,906133,906135,906231,906233,906235), (Sprinter, 906711,906713), (Sprinter, 906611,906613), (Sprinter, 906653,906655,906657), (Sprinter, 906631,906633,906635,906637), (Sprinter, 906111,906113,906211,906213), (Sprinter, 906), (Sprinter, 906735,906737), (Sprinter, 906153,906155,906253,906255,906653,906655,906657), (V-Klasse, 639811,639813,639815), (V-Klasse, 639711,639713,639811,639813), (V-Klasse, 639701,639703,639705), (V-Klasse, 639601,639603,639605), (E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse, 207403,207404), (E-Klasse, 207326), (E-Klasse, 213022), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLE-Klasse, 167323), (V-Klasse, 447701,447703,447705), (E-Klasse, 213216), (A-Klasse, 177010), (A-Klasse, 177110), (V-Klasse, 447703), (V-Klasse, 447601,447603,447605), (B-Klasse, 247010))

Coding the trailer detection ((E-Klasse, 207426), (E-Klasse, 207401,207402), (E-Klasse, 207403,207404), (E-Klasse, 207326), (SLK/SLC-Klasse, 172466), (GLK-Klasse, 204990), (SLK/SLC-Klasse, 172435))

Coding the parking assist ((GLK-Klasse, 204990))

Coding the rain sensor ((GLE-Klasse, 166073))

Coding the fuel quantity ((GLK-Klasse, 204990))



Diagnostic devices

Coding injectors ((Sprinter, 910621, 910623), (Sprinter, 910121, 910123), (Sprinter, 910631, 910633), (Sprinter, 910141, 910143, 910145, 910241, 910243), (Sprinter, 910643, 910641), (Sprinter, 910131, 910133, 910135, 910231, 910233), (Sprinter, 907621, 907623), (Sprinter, 907141, 907143, 907145, 907241, 907243), (Sprinter, 907153, 907155, 907253, 907255), (Sprinter, 907653, 907655, 907657), (Sprinter, 910), (Sprinter, 907733), (Sprinter, 907731, 907733, 907735), (Sprinter, 910141, 910143), (Sprinter, 907141, 907143, 907241, 907243, 907145, 907245), (Sprinter, 907743, 90745, 907747), (Sprinter, 907), (Sprinter, 907131, 907133, 907135, 907231, 907233), (Sprinter, 907633, 907635, 907637), (Sprinter, 907133, 907135, 907233, 907235), (Sprinter, 907643, 907645, 907647), (Sprinter, 907143, 907145, 907243, 907245), (Sprinter, 907733, 907735), (Sprinter, 910631, 910633, 910621, 910623), (Sprinter, 907631, 907633, 907635, 907637), (Sprinter, 910040, 910141, 910143, 910143, 910641, 910643), (Sprinter, 910153, 910155, 910253, 910255), (Sprinter, 910631, 910633, 910635, 910637), (Sprinter, 907721, 907723), (Sprinter, 907843), (Sprinter, 907141, 907143), (Sprinter, 907143, 907145, 907243, 907245, 907141), (Sprinter, 907143, 907145, 907243, 907141, 907241), (Sprinter, 907855, 907857), (Sprinter, 910143, 910145, 910243, 910245), (Sprinter, 910133, 910135, 910233, 910235), (Sprinter, 910143, 910145, 910243, 910141, 910241), (Sprinter, 907133, 907135, 907233), (Sprinter, 910133, 910135, 910233), (Sprinter, 907641, 907643), (Sprinter, 907643, 907645), (Sprinter, 910641, 910643), (Sprinter, 910643, 910645), (Sprinter, 907131, 907133), (Sprinter, 910131, 910133), (Sprinter, 907631, 907633), (Sprinter, 907633, 907635, 907631, 907637), (Sprinter, 910633, 910635, 910631, 910637), (Sprinter, 907121, 907123), (Sprinter, 907123, 907221, 907223), (Sprinter, 910123, 910221, 910223), (Sprinter, 907221, 907223), (Sprinter, 910221, 910223), (Sprinter, 910643, 910645, 910647), (Sprinter, 910633, 910635, 910637), (Sprinter, 910143), (Sprinter, 907643), (Sprinter, 907643, 907641))

Service resets

(Citan, 415601), (CLS-Klasse, 257348), (E-Klasse, 207426), (E-Klasse, 213227), (E-Klasse, 213022), (GLE-Klasse, 166073), (GLK-Klasse, 204990), (SLK/SLC-Klasse, 172466), (V-Klasse, 447701, 447703, 447705)

Mini

Trouble codes

(F54 Clubman, FMK), (F55 One/Cooper, F55), (F56 One/Cooper, F56), (F57 Cabrio, F57), (F60 Countryman, F60)

Parameters

(F54 Clubman, FMK), (F55 One/Cooper, F55), (F56 One/Cooper, F56), (F57 Cabrio, F57), (F60 Countryman, F60)

Actuators

(F54 Clubman, FMK), (F55 One/Cooper, F55), (F56 One/Cooper, F56), (F57 Cabrio, F57), (F60 Countryman, F60)

Basic settings

Initializing the overhead control panel ((F56 One/Cooper, F56), (F55 One/Cooper, F55))

Resetting fuel system adaptation values ((F54 Clubman, FMK), (F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F60 Countryman, F60), (F55 One/Cooper, F55))

Adjusting the starting torque ((F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56))

Activating the fuel pump ((F54 Clubman, FMK), (F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F60 Countryman, F60))

Initializing the exhaust gas flap ((F54 Clubman, FMK), (F54 Clubman, F54), (F60 Countryman, F60), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F55 One/Cooper, F55))

Resetting engine adaptation values ((F54 Clubman, FMK), (F54 Clubman, F54), (F60 Countryman, F60))



Diagnostic devices

Resetting the ECU ((F54 Clubman, FMK), (F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F60 Countryman, F60), (F55 One/Cooper, F55))

Bleeding the transfer case ((F54 Clubman, FMK), (F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F60 Countryman, F60), (F55 One/Cooper, F55))

Adapting the headlight motor ((F54 Clubman, FMK), (F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F60 Countryman, F60), (F55 One/Cooper, F55))

Learning the power windows ((F54 Clubman, FMK), (F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F60 Countryman, F60), (F55 One/Cooper, F55))

Reset exhaust-gas aftertreatment learning values ((F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56))

Initializing the valve stroke adaptation ((F54 Clubman, FMK), (F54 Clubman, F54), (F60 Countryman, F60), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F55 One/Cooper, F55))

Resetting the pulse-generator ring adaptation ((F54 Clubman, FMK), (F54 Clubman, F54), (F60 Countryman, F60), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F55 One/Cooper, F55))

Bleeding the ABS/ESC system ((F57 Cabrio, F57), (F56 One/Cooper, F56), (F55 One/Cooper, F55))

Resetting mass airflow sensor adaptation values ((F54 Clubman, F54))

Resetting the pulse-generator ring adaptation ((F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56))

Calibrating the front camera ((F57 Cabrio, F57), (F56 One/Cooper, F56), (F55 One/Cooper, F55))

Resetting the mixture adjustment ((F54 Clubman, FMK), (F54 Clubman, F54), (F60 Countryman, F60), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F55 One/Cooper, F55))

Initializing the air distribution flaps ((F57 Cabrio, F57), (F56 One/Cooper, F56), (F55 One/Cooper, F55))

Resetting the rain/light sensor ((F54 Clubman, FMK), (F54 Clubman, F54), (F57 Cabrio, F57), (F60 Countryman, F60))

Resetting learned values of throttle valve actuator ((F60 Countryman, F60))

Initializing the air distribution flap actuator ((F57 Cabrio, F57), (F56 One/Cooper, F56), (F55 One/Cooper, F55))

Filling/bleeding the SCR passive system ((F54 Clubman, FMK), (F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F60 Countryman, F60), (F55 One/Cooper, F55))

Reset equipment variant ((F54 Clubman, FMK), (F54 Clubman, F54), (F60 Countryman, F60))

Resetting transfer case adaptation values ((F54 Clubman, FMK), (F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F60 Countryman, F60), (F55 One/Cooper, F55))

Resetting learned values of the DEF injection system ((F54 Clubman, FMK), (F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F60 Countryman, F60), (F55 One/Cooper, F55))

Resetting gearbox learning values ((F54 Clubman, FMK), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F54 Clubman, F54), (F60 Countryman, F60), (F55 One/Cooper, F55))

Resetting gearbox learning values ((F54 Clubman, F54), (F54 Clubman, FMK))

Activating the assembly position of the exhaust gas flap actuator ((F54 Clubman, FMK), (F54 Clubman, F54), (F60 Countryman, F60), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F55 One/Cooper, F55))



Diagnostic devices

Initializing the angular offset between the crankshaft and camshaft ((F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56))

Resetting the valve stroke adaptation initialization values ((F54 Clubman, FMK), (F54 Clubman, F54), (F60 Countryman, F60), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F55 One/Cooper, F55))

Initializing the rain/light sensor ((F56 One/Cooper, F56), (F55 One/Cooper, F55))

Learning low injection quantity ((F54 Clubman, FMK), (F54 Clubman, F54), (F60 Countryman, F60))

Initializing the ride height sensor ((F54 Clubman, F54), (F54 Clubman, FMK))

Adapt shifting speed regulation ((F54 Clubman, FMK), (F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F60 Countryman, F60))

Initialize acceleration sensor ((F54 Clubman, FMK), (F54 Clubman, F54), (F60 Countryman, F60), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F55 One/Cooper, F55))

Resetting mass airflow sensor adaptation values ((F57 Cabrio, F57), (F56 One/Cooper, F56))

Initializing the ride height sensor ((F54 Clubman, FMK), (F57 Cabrio, F57), (F54 Clubman, F54), (F60 Countryman, F60))

Initializing the A/C flap actuators ((F54 Clubman, F54), (F60 Countryman, F60), (F54 Clubman, FMK))

Initializing the gear sensor ((F54 Clubman, FMK), (F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F60 Countryman, F60), (F55 One/Cooper, F55))

Bleeding the brake system ((F54 Clubman, FMK), (F54 Clubman, F54), (F60 Countryman, F60))

Initializing the glow plugs ((F56 One/Cooper, F56))

Unlocking aux. heater/independent car heater ((F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F55 One/Cooper, F55), (F54 Clubman, FMK))

Standardizing the liftgate ((F60 Countryman, F60))

Calibrating the front camera ((F54 Clubman, FMK), (F54 Clubman, F54), (F60 Countryman, F60))

Actuating the assembly position of the EGR valve ((F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56))

Initializing the variable valve lift ((F54 Clubman, FMK), (F54 Clubman, F54), (F60 Countryman, F60))

Learning the steering-angle sensor ((F56 One/Cooper, F56), (F55 One/Cooper, F55))

Unlocking aux. heater/independent car heater ((F60 Countryman, F60))

De/activating the parking brake service mode ((F54 Clubman, FMK), (F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F60 Countryman, F60), (F55 One/Cooper, F55))

Bleeding the fuel system ((F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56))

Replacing the particle filter ((F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56))

Bleeding the cooling system ((F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F60 Countryman, F60), (F55 One/Cooper, F55))

Regenerating the soot particulate filter ((F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56))

Adapting the variable camshaft timing ((F54 Clubman, FMK), (F54 Clubman, F54), (F60 Countryman, F60))



Diagnostic devices

Interchanged brake pipe check ((F54 Clubman, FMK), (F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F60 Countryman, F60), (F55 One/Cooper, F55))

Initializing the sunroof actuator ((F54 Clubman, FMK), (F54 Clubman, F54), (F57 Cabrio, F57), (F60 Countryman, F60))

Initializing the EGR valve ((F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56))

Adjusting the boost control rod ((F54 Clubman, FMK), (F54 Clubman, F54), (F60 Countryman, F60), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F55 One/Cooper, F55))

Resetting starter learning values ((F54 Clubman, FMK), (F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F60 Countryman, F60), (F55 One/Cooper, F55))

Adapt automatic start/stop (MSA) ((F54 Clubman, FMK), (F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56))

Adapting the A/C compressor ((F57 Cabrio, F57), (F56 One/Cooper, F56), (F55 One/Cooper, F55))

Performing the initial run-in of the air conditioning compressor ((F54 Clubman, F54), (F60 Countryman, F60), (F54 Clubman, FMK))

Initializing the neutral position sensor ((F54 Clubman, FMK), (F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F60 Countryman, F60), (F55 One/Cooper, F55))

Resetting differential pressure sensor learning values ((F56 One/Cooper, F56), (F55 One/Cooper, F55), (F54 Clubman, F54), (F57 Cabrio, F57), (F60 Countryman, F60), (F54 Clubman, FMK))

Codings

Registering the battery ((F54 Clubman, FMK), (F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F60 Countryman, F60), (F55 One/Cooper, F55))

Coding injectors ((F54 Clubman, FMK), (F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F60 Countryman, F60), (F55 One/Cooper, F55))

Coding the idle rpm ((F54 Clubman, FMK), (F54 Clubman, F54), (F57 Cabrio, F57), (F56 One/Cooper, F56), (F60 Countryman, F60), (F55 One/Cooper, F55))

Service resets

(F54 Clubman, FMK), (F55 One/Cooper, F55), (F56 One/Cooper, F56), (F57 Cabrio, F57), (F60 Countryman, F60)

Nissan

Trouble codes

(Altima, L33), (Maxima, A36), (Patrol, Y62)

Parameters

Actuators

Basic settings

Learning throttle valve stop ((Patrol, Y62), (Altima, L34), (Altima, L33), (Maxima, A36))

Learning the steering-angle sensor ((Patrol, Y62), (Altima, L33), (Maxima, A36))

Codings

Service resets



Diagnostic devices

Opel/Vauxhall

Trouble codes	(Astra-G, T98), (Astra-K, B16), (Crossland X, P17), (Vivaro-A, X83), (Zafira-C, P12)
Parameters	(Astra-K, B16), (Crossland X, P17), (Vivaro-A, X83), (Zafira-C, P12)
Actuators	(Astra-K, B16), (Crossland X, P17), (Zafira-C, P12)
Basic settings	<ul style="list-style-type: none">Resetting throttle valve adaptation values ((Zafira-C, P12))Initializing the SCR system ((Astra-K, B16), (Astra-K, B-K))Learning the lambda sensor heater ((Zafira-C, P12))Adapting the longitudinal acceleration sensor ((Crossland X, P17))Learning the flywheel ((Zafira-C, P12), (Crossland X, P17))Resetting the mixture adjustment ((Zafira-C, P12))Adapting the accelerator sensor ((Zafira-C, P12))Resetting the ECU ((Crossland X, P17))Resetting the diesel exhaust fluid level ((Astra-K, B16), (Astra-K, B-K))Learning the lambda sensor ((Zafira-C, P12))Reset learned values of intake-air flap. ((Zafira-C, P12))MTA EasyTronic transmission ((Corsa-D, S07))Initializing the fuel pressure sensor or the fuel rail ((Zafira-C, P12))Resetting the exhaust temperature values ((Zafira-C, P12))Resetting boost pressure controller learned values ((Crossland X, P17))Resetting learned values of steering angle sensor ((Zafira-C, P12))Replace cylinder head ((Crossland X, P17))Initializing the air distribution flaps ((Astra-K, B16), (Zafira-C, P12), (Astra-K, B-K), (Astra-K,))Initializing the mass airflow sensor ((Zafira-C, P12))Learning the turbocharger ((Zafira-C, P12), (Crossland X, P17))De/activating the parking brake service mode ((Astra-K, B16), (Astra-K, B-K))Learning the steering-angle sensor ((Zafira-C, P12))Resetting the particulate filter learning values ((Zafira-C, P12))Resetting learned values of the oxidation catalyst ((Astra-K, B16), (Astra-K, B-K))Regenerating the soot particulate filter ((Astra-K, B16), (Zafira-C, P12), (Astra-K, B-K))Initializing the brake-pressure sensor ((Zafira-C, P12))Resetting the accelerator sensor learning values ((Crossland X, P17))Learning the clutch position ((Zafira-C, P12), (Crossland X, P17))Adapting the SCR catalyst upon replacement ((Astra-K, B16), (Astra-K, B-K))Initializing the crankshaft position sensor ((Zafira-C, P12))Learning the clutch position ((Corsa-E, X15), (Adam, M13), (Astra-K, B16), (Astra-K, B-K))



Diagnostic devices

Initializing the yaw rate sensor ((Zafira-C, P12))
Adjusting the headlights ((Crossland X, P17))
Reset learned values for diesel exhaust fluid tank system ((Astra-K, B16), (Astra-K, B-K))
Initializing the crankshaft position ((Zafira-C, P12))
Retracting parking brake ((Astra-K, B16), (Astra-K, B-K), (Crossland X, P17), (Astra-K,))
Initializing the alternator ((Crossland X, P17))
Initializing the adaptive cruise control ((Zafira-C, P12))
Teach-in battery sensor module ((Zafira-C, P12))
Resetting differential pressure sensor learning values ((Zafira-C, P12))
Learning the throttle valve ((Crossland X, P17))
Bleeding the clutch ((Corsa-E, X15), (Adam, M13), (Astra-K, B16), (Astra-K, B-K))
Calibrating the front camera ((Astra-K, B16), (Zafira-C, P12), (Astra-K, B-K), (Crossland X, P17), (Astra-K,))
Reset learned values of glow plugs. ((Zafira-C, P12))
Resetting learned values of idle speed stabilizer ((Zafira-C, P12))
Learning the idle ((Zafira-C, P12))
Reducing system pressure in transmission ((Corsa-E, X15), (Adam, M13), (Astra-K, B16), (Astra-K, B-K))
Leaving the ECO mode ((Crossland X, P17))
Learning the steering-angle sensor ((Crossland X, P17))
Resetting battery discharging current values ((Crossland X, P17))
Initializing the EGR valve ((Zafira-C, P12))
Resetting starter learning values ((Crossland X, P17))
Extending parking brake ((Astra-K, B16), (Astra-K, B-K), (Astra-K,))
Bleeding the brake system ((Astra-K, B16), (Astra-K, B-K))
Calibrating the tire pressure monitoring system ((Astra-K, B16), (Zafira-C, P12), (Astra-K, B-K), (Astra-K,))
Initializing the neutral position sensor ((Zafira-C, P12))
Calibrating the parking brake ((Zafira-C, P12), (Astra-K, B16), (Astra-K, B-K))

Codings

Coding the trailer hitch ((Crossland X, P17))

Service resets

(Astra-K, B16), (Crossland X, P17), (Zafira-C, P12)

Peugeot

Trouble codes

(2008, U), (208, U), (308, L), (5008, 0A), (508,), (508, 8), (508, F), (Boxer-III, Y), (Partner-III, 7), (Rifter, E)

Parameters

(2008, U), (208, U), (308, L), (5008, 0A), (508,), (508, 8), (508, F), (Boxer-III, Y), (Partner-III, 7), (Rifter, E)



Diagnostic devices

Actuators	(2008, U), (208, U), (308, L), (5008, 0A), (508,), (508, 8), (508, F), (Boxer-III, Y), (Partner-III, 7), (Rifter, E)
Basic settings	<p>Adapting the accelerator sensor ((5008, 0A))</p> <p>Reactivating the emergency brake assistant ((5008, 0A), (208, U), (2008, U), (308, L), (508, F), (Rifter, E), (508,))</p> <p>Replacing/filling the regeneration additive container ((508, 8))</p> <p>De-calibrating the longitudinal/lateral acceleration sensor ((Boxer-III, Y))</p> <p>Resetting learned values of steering angle sensor ((Partner-III, 7), (508, 8))</p> <p>Uninstalling/installing the rear brake linings ((508, 8))</p> <p>Calibrating the night vision assist ((508, F), (508,))</p> <p>Adapting the longitudinal acceleration sensor ((308, L))</p> <p>Initializing the rain/light sensor ((5008, 0A), (508, 8), (208, U), (2008, U), (308, L), (508, F), (Rifter, E), (508,))</p> <p>Initializing the DeNOx system ((208, U), (508, F), (Boxer-III, Y))</p> <p>Removing/installing the gear selector lever ((5008, 0A), (508, F), (508,))</p> <p>ECU of high-voltage safety shutdown ((Rifter, E), (508, F))</p> <p>Resetting the diesel exhaust fluid level ((208, U), (508, F))</p> <p>Init. of flow control valve ((508, 8))</p> <p>Bleeding the ABS/ESC system ((5008, 0A), (208, U), (2008, U), (508, F), (Rifter, E), (508,))</p> <p>Adapting the variable camshaft timing ((208, U), (2008, U))</p> <p>Calibrating the camera ECU ((108, P), (508, F), (5008, 0A), (208, U), (2008, U), (308, L), (Boxer-III, Y), (Rifter, E), (508,))</p> <p>Bleeding the fuel system ((208, U))</p> <p>Activating the start/stop function ((308, L), (508, F), (3008, M), (5008, 0A), (208, U), (2008, U), (Boxer-III, Y), (508,))</p> <p>Regenerating the soot particulate filter during driving ((508, 8))</p> <p>Resetting headlight leveling adaptation values ((208, U), (2008, U))</p> <p>Adapting the emergency brake assistant ((Partner-III, 7))</p> <p>Adapting the turbocharger controller ((208, U), (308, L))</p> <p>Bleeding the oil pump ((208, U), (2008, U))</p> <p>Resetting the knock counter ((5008, 0A))</p> <p>Cleaning/replacing the soot particulate filter ((308, L), (508, F), (3008, M), (208, U), (2008, U), (508,))</p> <p>Initializing the differential pressure sensor ((308, L), (508, F), (3008, M), (508, 8), (208, U), (2008, U), (508,))</p> <p>Replacing the exhaust manifold ((5008, 0A))</p> <p>Reconnecting the battery ((208, U), (2008, U))</p> <p>Adapting the turbine wheel shut-off valve ((5008, 0A))</p> <p>Bleeding the fuel presupply system ((208, U))</p>



Diagnostic devices

Reset learned values of injectors. ((208, U), (2008, U))
Initializing the soot particulate filter ((308, L))
Fill the DEF tank ((Boxer-III, Y))
Adapting the clutch assembly ((308, L), (508,))
Resetting the misfire counter ((5008, 0A))
Replace brake parts ((Partner-III, 7), (5008, 0A), (208, U), (2008, U), (308, L))
Unlocking the airbag ECU ((Partner-III, 7), (5008, 0A), (508, 8), (208, U), (2008, U), (308, L), (508, F), (Rifter, E), (508,))
Replacing engine parts ((508, 8), (3008, M), (5008, M), (308, L), (508, F), (5008, 0A), (Boxer-III, Y), (508,))
Initializing the rotation rate/acceleration sensor ((Partner-III, 7), (508, 8))
Initialising adaptive functions ((5008, 0A), (508, F))
Initializing the A/C flap actuators ((5008, 0A), (508, 8), (208, U), (2008, U), (308, L), (508, F), (Rifter, E), (508,))
Replacing brake parts of rear axle ((508, F), (Rifter, E), (508,))
Calibrating the steering-angle sensor ((5008, 0A))
Initializing the alternator ((5008, 0A), (208, U), (2008, U), (308, L), (508,))
Adapting the radiator shutter ((308, L), (508, F), (3008, M), (208, U), (2008, U), (508,))
Adjusting the headlights ((5008, 0A), (508, 8), (308, L))
Calibrating the cornering light ((508, F), (508,))
Leaving the ECO mode ((5008, 0A), (508, 8), (208, U), (2008, U), (308, L), (508, F), (Rifter, E), (508,))
Bleeding the cooling system ((208, U), (Rifter, E), (508, F))
Emptying/filling the diesel exhaust fluid tank ((308, L), (508, F), (Boxer-III, Y))
Initializing the EGR valve ((508, 8), (208, U), (508, F), (Boxer-III, Y))
Filling the cooling system ((Rifter, E))
Regenerating the soot particulate filter at standstill ((308, L), (508, F), (3008, M), (5008, 0A), (508, 8), (208, U), (2008, U), (508,))
Initializing the transmission selector actuator ((5008, 0A), (508, F), (508,))
Adapting the clutch biting point ((5008, 0A), (508, 8), (208, U), (2008, U), (308, L))
Replacing the regeneration additive container ((508, 8))
Learning the throttle valve ((5008, 0A), (208, U), (2008, U), (308, L), (508,))
Resetting the counter of fragrance cartridge block ((208, U), (2008, U))
Performing transmission adaptations ((508, 8), (308, L))
Replacing transmission components ((5008, 0A), (508, F), (508,))
Initializing the longitudinal/lateral acceleration sensor ((Boxer-III, Y))
Learning the turbocharger ((308, L), (508, F), (3008, M), (5008, 0A), (508, 8), (508,))
Replace auxiliary drive belt ((508, 8), (208, U), (308, L))
Resetting gearbox learning values ((508, F))



Diagnostic devices

- Initializing the power window anti-pinch protection ((5008, 0A), (508, 8), (308, L), (Rifter, E))
- Initializing the air metering system ((508, 8), (208, U), (508, F), (Boxer-III, Y))
- Replace the parking brake Bowden cables. ((508, 8))
- Replace the battery. ((5008, 0A), (208, U), (2008, U), (308, L), (508,), (508, F))
- Cleaning the EGR cooler switchover valve ((208, U))
- Replace cylinder head ((5008, 0A))
- Initializing the variable valve lift ((308, L), (508,), (508, F))
- Learning the injection valve ((5008, 0A))
- Learning the N position of gearbox ((508, F))
- Initializing the night vision camera ECU ((508, F), (508,))
- Learning the flywheel ((5008, 0A))
- Filling the regeneration additive container ((508, 8), (308, L), (508, F), (Boxer-III, Y))
- Locking the airbag ECU ((Partner-III, 7), (5008, 0A), (508, 8), (208, U), (2008, U), (308, L), (508, F), (Rifter, E), (508,))
- Learning the lambda sensor ((508, 8))
- Adapting crankshaft sensor ((308, L), (508, F), (3008, M), (208, U), (2008, U), (508,))
- Deactivating the torque limitation ((308, L), (508, F), (3008, M), (5008, 0A), (508,))
- Initialize starter ((5008, 0A))
- Replacing the particle filter ((508, 8))
- Initializing the mass airflow sensor ((508, 8))
- Replace the piston ((208, U), (2008, U))
- Calibrating the steering-angle sensor ((Partner-III, 7), (508, 8), (308, L), (Rifter, E))
- Learning the steering-angle sensor ((508, F), (Boxer-III, Y), (508,))
- Resetting the clutch counter ((308, L), (508, F), (3008, M), (508,))
- Regenerating the soot particulate filter ((208, U), (308, L), (Boxer-III, Y))
- Cleaning EGR valve ((208, U), (308, L))
- Adapting the longitudinal acceleration sensor ((Partner-III, 7), (5008, 0A), (208, U), (2008, U), (508, F), (Rifter, E), (508,))
- Special bleeding ((Partner-III, 7), (508, 8), (308, L))
- Calibrating the radar sensor ((5008, 0A), (208, U), (2008, U), (308, L), (508, F), (508,))
- Reducing fuel high pressure ((208, U), (2008, U))
- Initializing the fuel level ((Partner-III, 7), (5008, 0A), (508, 8), (208, U), (2008, U), (308, L), (508, F), (Rifter, E), (508,))
- De-energizing the hybrid/electric vehicle ((Partner-III, 7))
- Draining the cooling system ((Rifter, E))
- Calibrating the rearview camera/all-round vision camera ((5008, 0A), (508, F), (508,))
- Codings
- Coding the trailer hitch ((5008, 0A), (508, 8), (208, U), (2008, U), (308, L), (508, F), (Rifter, E), (508,))



Diagnostic devices

Coding the keys ((Boxer-I, 230), (Partner-III, 7), (5008, 0A), (508, 8), (208, U), (2008, U), (308, L), (508, F), (Boxer-III, Y), (Rifter, E), (508,))

Registering the battery ((Partner-III, 7), (5008, 0A), (508, 8), (208, U), (2008, U), (308, L), (508, F), (Rifter, E), (508,))

Locking the airbag ECU ((508, F), (Rifter, E), (508,))

Retrofit USB module/CD changer ((Partner-III, 7))

Coding the remote control ((Partner-III, 7), (308, L))

Unlocking the airbag ECU ((508, F), (Rifter, E), (508,))

Coding ECUs ((Boxer-III, Y))

Coding transmission readings ((508, 8), (308, L))

Deactivating/activating the transport mode ((Partner-III, 7), (5008, 0A), (508, 8), (208, U), (2008, U), (308, L), (508, F), (Rifter, E), (508,))

Coding the wheel valves ((Partner-III, 7), (508, 8))

Coding the trailer hitch ((Boxer-III, Y))

Coding the regeneration additive quantity ((508, 8))

Coding the intrusion monitoring ((5008, 0A), (308, L))

Coding the VIN ((Partner-III, 7))

Coding injectors ((Partner-III, 7), (508, 8), (308, L), (508, F), (Boxer-III, Y))

Coding the body control module ((Partner-III, 7))

Coding the alarm sound ((5008, 0A), (308, L), (508, F), (Rifter, E), (508,))

Service resets

(2008, U), (208, U), (308, L), (5008, 0A), (508,), (508, 8), (508, F), (Boxer-III, Y), (Partner-III, 7), (Rifter, E)

Porsche

Trouble codes

(911 (991), 991), (911 (992), 992), (Boxster (981), 981), (Boxster 718 (982), 982), (Cayenne (92A), 92A), (Cayenne (9Yx), 9YA), (Cayenne (9Yx), 9YB), (Cayman (981), 981), (Cayman 718 (982), 982), (Macan (95B), 95B), (Panamera (970), 970), (Panamera (971), 971), (Taycan (Y1A), Y1A)

Parameters

(911 (991), 991), (911 (992), 992), (Boxster (981), 981), (Boxster 718 (982), 982), (Cayenne (92A), 92A), (Cayenne (9Yx), 9YA), (Cayenne (9Yx), 9YB), (Cayman (981), 981), (Cayman 718 (982), 982), (Macan (95B), 95B), (Panamera (970), 970), (Panamera (971), 971), (Taycan (Y1A), Y1A)

Actuators

(911 (991), 991), (911 (992), 992), (Boxster (981), 981), (Boxster 718 (982), 982), (Cayenne (92A), 92A), (Cayenne (9Yx), 9YA), (Cayenne (9Yx), 9YB), (Cayman (981), 981), (Cayman 718 (982), 982), (Macan (95B), 95B), (Panamera (970), 970), (Panamera (971), 971), (Taycan (Y1A), Y1A)

Basic settings

Initializing electric seats ((Panamera (971), 971), (Cayenne (9Yx), 9YA), (Cayenne (9Yx), 9YB), (911 (992), 992), (Taycan (Y1A), Y1A))

Performing the parking brake bedding-in drive ((Boxster 718 (982), 982), (Cayman 718 (982), 982))



Diagnostic devices

Standardizing the liftgate ((Panamera (971), 971), (Cayenne (9Yx), 9YA), (Cayenne (9Yx), 9YB), (Taycan (Y1A), Y1A))

Calibrating the parking brake ((Boxster 718 (982), 982), (Cayman 718 (982), 982))

Initializing the adaptive cruise control sensor ((Cayenne (92A), 92A), (Panamera (970), 970), (911 (991), 991), (Boxster (981), 981), (Cayman (981), 981), (Macan (95B), 95B), (Boxster 718 (982), 982), (Cayman 718 (982), 982), (Taycan (Y1A), Y1A))

Initializing the adaptive cruise control ((Cayenne (9Yx), 9YA), (Cayenne (9Yx), 9YB), (911 (992), 992), (Panamera (971), 971))

Learning the steering-angle sensor ((Panamera (971), 971))

Performing engine adaptations ((Panamera (971), 971))

Initializing the sunroof actuator ((Panamera (971), 971))

Calibrating the camera ECU ((Panamera (971), 971))

Adapting the fuel burning heater remote control ((Panamera (971), 971))

Actuating the installation/removal position of the parking brake ((Boxster 718 (982), 982), (Cayman 718 (982), 982))

Unlocking aux. heater/independent car heater ((Panamera (971), 971))

Burning off aux. heater/independent car heater ((Panamera (971), 971))

Calibrating the front camera ((Boxster 718 (982), 982), (Cayman 718 (982), 982))

Adjust clearance of parking brake ((Boxster 718 (982), 982), (Cayman 718 (982), 982))

Parking brake maintenance work ((Panamera (971), 971))

Codings

Coding the trailer detection ((Panamera (971), 971))

Registering the battery ((Panamera (971), 971), (Boxster 718 (982), 982), (Cayman 718 (982), 982))

Coding the rain/light sensor ((Panamera (971), 971))

Coding the parking brake ECU ((Boxster 718 (982), 982), (Cayman 718 (982), 982))

Deactivating/activating the transport mode ((Panamera (971), 971))

Service resets

(Boxster 718 (982), 982), (Cayman 718 (982), 982), (Panamera (971), 971)

Renault

Trouble codes

(Captur-II, RJB), (Master-III, MA), (Twingo-III, BCM1)

Parameters

(Captur-II, RJB), (Master-III, MA), (Twingo-III, BCM1)

Actuators

(Captur-II, RJB), (Master-III, MA), (Twingo-III, BCMD)

Basic settings

Adapting the camshaft ((Megane-III, DZ1P), (Megane-III, KZ0G), (Megane-III, KZ1P), (Megane-III, BZ1P), (Megane-III, BZ0G), (Megane-III, DZ0G), (Megane-III, EZ1E), (Megane-III, EZ1P), (Scenic-III, JZ1P))

Learning the flywheel ((Megane-III, DZ1P), (Megane-III, KZ0G), (Megane-III, KZ1P), (Megane-III, BZ1P), (Megane-III, BZ0G), (Megane-III, DZ0G), (Megane-III, EZ1E), (Megane-III, EZ1P), (Scenic-III, JZ1P))



Diagnostic devices

Resetting the diesel exhaust fluid level ((Master-III, MA), (Master-III, MB), (Master-III, MD), (Master-III, MC))

Learning the lambda sensor ((Master-III, MA), (Master-III, MB), (Master-III, MD), (Master-III, MC))

|TAG_ERROR|Initializing the coolant pump of high-voltage battery module|TAG_ERROR| ((Twingo-III, BCA1))

Adapting the diesel exhaust fluid tank ((Master-III, MA), (Master-III, MB), (Master-III, MD), (Master-III, MC))

Initializing the fuel pressure sensor or the fuel rail ((Master-III, MA), (Master-III, MB), (Master-III, MD), (Master-III, MC), (Captur-II, RJB))

Initializing the differential pressure sensor ((Master-III, MA), (Master-III, MB), (Master-III, MD), (Master-III, MC))

Resetting catalyst adaptation values ((Master-III, MA), (Master-III, MB), (Master-III, MD), (Master-III, MC))

Resetting boost pressure controller learned values ((Captur-II, RJB))

Learning throttle valve stop ((Megane-III, DZ1P), (Megane-III, KZ0G), (Megane-III, KZ1P), (Megane-III, BZ1P), (Megane-III, BZ0G), (Megane-III, DZ0G), (Megane-III, EZ1E), (Megane-III, EZ1P), (Scenic-III, JZ1P), (Captur-II, RJB))

Initializing the fuel pump ((Master-III, MA), (Master-III, MB), (Master-III, MD), (Master-III, MC))

Initializing the mass airflow sensor ((Master-III, MA), (Master-III, MB), (Master-III, MD), (Master-III, MC))

Learning the steering-angle sensor ((Twingo-III, BCM1), (Twingo-III, BCM8), (Twingo-III, BCMD), (Twingo-III, BCME), (Twingo-III, BCM4), (Twingo-III, BCMJ), (Captur-II, RJB), (Twingo-III, BCA1))

De/activating the parking brake service mode ((Captur-II, RJB))

Resetting learned values of NOx adsorption catalyst ((Master-III, MA), (Master-III, MB), (Master-III, MD), (Master-III, MC))

|TAG_ERROR|Initializing the coolant pump of electric drive motor|TAG_ERROR| ((Twingo-III, BCA1))

Calibrating rear radar sensors ((Captur-II, RJB))

Regenerating the soot particulate filter ((Master-III, MA), (Master-III, MB), (Master-III, MD), (Master-III, MC), (Captur-II, RJB))

Adjusting/calibrating matrix LED headlight left ((Megane-IV, B9N8), (Megane-IV, B9N9), (Megane-IV, B9NB), (Megane-IV, K9N8), (Megane-IV, K9N9), (Megane-IV, K9NC), (Megane-IV, K9NB), (Megane-IV, K9A2), (Megane-IV, K9A6), (Megane-IV, B9NC), (Megane-IV, B9A2), (Megane-IV, B9A6), (Megane-IV, B9), (Megane-IV, B9M8), (Megane-IV, B9A7), (Megane-IV, K9A7), (Megane-IV,))

Resetting knock sensor adaptation values ((Megane-III, DZ1P), (Megane-III, KZ0G), (Megane-III, KZ1P), (Megane-III, BZ1P), (Megane-III, BZ0G), (Megane-III, DZ0G), (Megane-III, EZ1E), (Megane-III, EZ1P), (Scenic-III, JZ1P))

Resetting learned values of camshaft sensor ((Megane-III, DZ1P), (Megane-III, KZ0G), (Megane-III, KZ1P), (Megane-III, BZ1P), (Megane-III, BZ0G), (Megane-III, DZ0G), (Megane-III, EZ1E), (Megane-III, EZ1P), (Scenic-III, JZ1P))



Diagnostic devices

Adjusting/calibrating matrix LED headlight right ((Megane-IV, B9N8), (Megane-IV, B9N9), (Megane-IV, B9NB), (Megane-IV, K9N8), (Megane-IV, K9N9), (Megane-IV, K9NC), (Megane-IV, K9NB), (Megane-IV, K9A2), (Megane-IV, K9A6), (Megane-IV, B9NC), (Megane-IV, B9A2), (Megane-IV, B9A6), (Megane-IV, B9), (Megane-IV, B9M8), (Megane-IV, B9A7), (Megane-IV, K9A7), (Megane-IV,))

Initializing the starter ring gear ((Captur-II, RJB))

Resetting the start inhibitor of DEF injection system ((Master-III, MA), (Master-III, MB), (Master-III, MD), (Master-III, MC))

Calibrate radar dynamically ((Captur-II, RJB))

Initializing the intake cam phaser ((Captur-II, RJB))

Initializing the intake-air flap ((Master-III, MA), (Master-III, MB), (Master-III, MD), (Master-III, MC))

Resetting the mixture adjustment ((Megane-III, DZ1P), (Megane-III, KZ0G), (Megane-III, KZ1P), (Megane-III, BZ1P), (Megane-III, BZ0G), (Megane-III, DZ0G), (Megane-III, EZ1E), (Megane-III, EZ1P), (Scenic-III, JZ1P))

Resetting high-pressure fuel pump adaptation values ((Master-III, MA), (Master-III, MB), (Master-III, MD), (Master-III, MC))

Initializing the diesel exhaust fluid pump module ((Master-III, MA), (Master-III, MB), (Master-III, MD), (Master-III, MC))

Initializing the soot particulate filter upon replacement ((Master-III, MA), (Master-III, MB), (Master-III, MD), (Master-III, MC), (Captur-II, RJB))

Resetting the ignition coil adaptation ((Megane-III, DZ1P), (Megane-III, KZ0G), (Megane-III, KZ1P), (Megane-III, BZ1P), (Megane-III, BZ0G), (Megane-III, DZ0G), (Megane-III, EZ1E), (Megane-III, EZ1P), (Scenic-III, JZ1P))

Initializing the electric coolant pump ((Zoe, BFMA), (Zoe, BFMF), (Zoe, FFMA), (Zoe, FFMB), (Zoe, BFMC, BFMD))

Calibrating the camera ECU ((Twingo-III, BCMD), (Twingo-III, BCME), (Captur-II, RJB), (Twingo-III, BCA1))

Initializing the EGR valve ((Master-III, MA), (Master-III, MB), (Master-III, MD), (Master-III, MC))

Bleeding the ABS hydraulic unit ((Twingo-III, BCMD), (Twingo-III, BCME), (Captur-II, RJB), (Twingo-III, BCA1))

Initializing the diesel exhaust fluid injector ((Master-III, MA), (Master-III, MB), (Master-III, MD), (Master-III, MC))

Resetting starter learning values ((Twingo-III, BCM1), (Twingo-III, BCM8), (Twingo-III, BCM4), (Twingo-III, BCMJ), (Captur-II, RJB))

Codings Coding the language version ((Twingo-III, BCMD), (Twingo-III, BCME), (Captur-II, RJB), (Twingo-III, BCA1))

Coding injectors ((Master-III, MA), (Master-III, MB), (Master-III, MD), (Master-III, MC))

Coding the tire size ((Twingo-III, BCMD), (Twingo-III, BCME), (Captur-II, RJB), (Twingo-III, BCA1))

Switching on/off the automatic parking brake application ((Captur-II, RJB))

Airbag ECU locking/unlocking ((Twingo-III, BCMD), (Twingo-III, BCME), (Twingo-III, BCA1))

Coding the wheel valves ((Twingo-III, BCMD), (Twingo-III, BCME), (Twingo-III, BCA1))



Diagnostic devices

Adapting the trailer hitch to advanced driver assistance systems ((Captur-II, RJB))

Coding instrument cluster units ((Twingo-III, BCMD), (Twingo-III, BCME), (Captur-II, RJB), (Twingo-III, BCA1))

- | **Service resets** (Twingo-III, BCMD)

Seat

- | **Trouble codes** (Leon, KL), (Toledo, KG)

- | **Parameters** (Toledo, KG)

Actuators

- | **Basic settings** Standardizing the liftgate ((Ateca, KH), (Tarraco, KN), (Leon, KL))

Initializing the fuel pump ((Leon, 1P))

Retracting parking brake ((Leon, KL))

Resetting engine adaptation values ((Altea, 5P), (Ibiza, 6J), (Leon, 1P), (Toledo, 5P), (Alhambra, 71), (Toledo, KG))

Initializing the ESC sensors ((Leon, KL))

Calibrating the camera ECU ((Leon, KL))

Initializing the brake-pressure sensor ((Leon, KL))

Extending parking brake ((Leon, KL))

Resetting learned values of DEF injection system ((Leon, 5F), (Ateca, KH), (Ibiza, KJ), (Arona, KJ), (Tarraco, KN))

Activating the roller test stand mode ((Leon, KL))

Resetting the impact mode ((Leon, KL))

Calibrating the parking brake ((Leon, KL))

- | **Codings** De/activating the trailer hitch ((Leon, KL))

Registering the battery ((Leon, KL))

Deactivating/activating the transport mode ((Leon, KL))

- | **Service resets**

Skoda

- | **Trouble codes** (Karoq, NU), (Octavia, NX), (Rapid, NH)

- | **Parameters** (Karoq, NU), (Octavia, NX), (Rapid, NH)

- | **Actuators** (Karoq, NU), (Octavia, NX)



Diagnostic devices

Basic settings

- Initializing electric seats ((Karoq, NU), (Octavia, NX))
- Initializing the adaptive cruise control ((Karoq, NU))
- Filling fuel lines of parking heater/auxiliary heater ((Karoq, NU), (Octavia, NX))
- Learning the steering-angle sensor ((Octavia, NX))
- Regenerating the soot particulate filter ((Karoq, NU), (Octavia, NX))
- Resetting engine adaptation values ((Octavia, 1Z), (Superb, 3T), (Yeti, 5L), (Fabia, 54), (Rapid, NH))
- Resetting the diesel exhaust fluid level ((Karoq, NU), (Octavia, NX))
- Adapting the electronic damper control ((Karoq, NU), (Octavia, NX))
- Bleeding the fuel system ((Karoq, NU), (Octavia, NX))
- Burning off aux. heater/independent car heater ((Karoq, NU), (Octavia, NX))
- Performing transmission adaptations ((Karoq, NU), (Octavia, NX))
- Initializing the seat belt tensioner ECU ((Karoq, NU))
- Initializing the tilt/slide sunroof ((Karoq, NU), (Octavia, NX))
- Standardizing the liftgate ((Kodiaq, NS), (Superb, 3V), (Karoq, NU), (Scala, NW), (Kamiq, NW), (Enyaq, 5A), (Octavia, NX))
- Initializing the fuel pump ((Octavia, 1Z))
- Adapting the soot particulate filter ((Karoq, NU), (Octavia, NX))
- Resetting the start inhibitor of DEF injection system ((Karoq, NU), (Octavia, NX))
- Learning the steering-angle sensor ((Karoq, NU))
- Performing engine adaptations ((Karoq, NU), (Octavia, NX))
- Initializing the brake-pressure sensor ((Karoq, NU), (Octavia, NX))
- Resetting learned values of DEF injection system ((Octavia, 5E), (Superb, 3V), (Yeti, 5L), (Kodiaq, NS), (Karoq, NU))
- Initializing the adaptive cruise control ((Octavia, NX))
- Performing the initial run-in of the air conditioning compressor ((Karoq, NU), (Octavia, NX))
- Retracting parking brake ((Enyaq, 5A), (Karoq, NU), (Octavia, NX))
- Initializing the A/C flap actuators ((Karoq, NU), (Octavia, NX))
- Initializing the alternator ((Karoq, NU))
- Activating the retrofitted parking heater ((Karoq, NU), (Octavia, NX))
- Initializing the oxidation catalyst ((Karoq, NU), (Octavia, NX))
- Initialize 4WD clutch oil pump ((Karoq, NU))
- Resetting the impact mode ((Karoq, NU), (Octavia, NX))
- Initializing the clutch pedal position ((Karoq, NU))
- Calibrating the parking brake ((Octavia, NX))
- Adjusting the headlights ((Kodiaq, NS), (Octavia, 5E), (Karoq, NU), (Octavia, NX))
- Bleeding the cooling system ((Karoq, NU), (Octavia, NX))
- Calibrating the camera ECU ((Enyaq, 5A), (Karoq, NU), (Octavia, NX))



Diagnostic devices

Adapting the fuel burning heater remote control ((Karoq, NU), (Octavia, NX))

Extending parking brake ((Enyaq, 5A), (Karoq, NU), (Octavia, NX))

Unlocking aux. heater/independent car heater ((Karoq, NU), (Octavia, NX))

Initializing the ESC sensors ((Karoq, NU), (Octavia, NX))

Activating the roller test stand mode ((Octavia, NX))

Calibrating the parking brake ((Karoq, NU))

Codings

Adjust parking assistance volume ((Karoq, NU), (Octavia, NX))

General ECU replacement ((Karoq, NU))

Coding the language version ((Karoq, NU))

Registering the battery ((Karoq, NU), (Octavia, NX))

Expert mode ECU coding ((Karoq, NU))

Coding the rain/light sensor ((Karoq, NU), (Octavia, NX))

Deactivating/activating the transport mode ((Karoq, NU), (Octavia, NX))

Coding the trailer detection ((Karoq, NU), (Octavia, NX))

Coding the steering-column module ((Karoq, NU))

Adapting the trailer hitch to advanced driver assistance systems ((Karoq, NU))

Coding injectors ((Karoq, NU), (Octavia, NX))

De/activating the trailer hitch ((Karoq, NU), (Octavia, NX))

Coding the gateway installation list ((Karoq, NU))

Service resets

(Enyaq, 5A), (Fabia, PJ), (Karoq, NU), (Octavia, NX), (Superb, 3T)

Smart/MCC

Trouble codes

(Smart Fortwo,)

Parameters

(Smart Fortwo,)

Actuators

(Smart Fortwo,)

Basic settings

Special bleeding ((Smart Fortwo,))

Activating the roller test stand mode ((Smart Fortwo,))

Initializing the steering angle sensor manually ((Smart Fortwo,))

Calibrating the tire pressure monitoring system manually ((Smart Fortwo,))

Calibrating the steering-angle sensor ((Smart Fortwo,))

Performing transmission adaptations ((Smart Fortwo,))

Codings

Service resets

(Smart Fortwo,)



Diagnostic devices

Subaru

- | **Trouble codes**
- | **Parameters**
- | **Actuators** (Legacy/Outback, BS)
- | **Basic settings**
- | **Codings**
- | **Service resets**

Suzuki

- | **Trouble codes** (Across, A5Z)
- | **Parameters** (Across, A5Z)
- | **Actuators**
- | **Basic settings**
- | **Codings**
- | **Service resets**

Tesla

- | **Trouble codes** (Model S, 002), (Model X, 002)
- | **Parameters** (Model S, 002), (Model X, 002)
- | **Actuators**
- | **Basic settings**
 - Performing the parking brake bedding-in drive ((Model S, 002), (Model X, 002))
 - Draining/filling the refrigerant circuit ((Model S, 002), (Model X, 002))
 - De/activating the parking brake service mode ((Model S, 002), (Model X, 002))
 - Resetting learned values of steering angle sensor ((Model S, 002), (Model X, 002))
 - Bleeding the cooling system ((Model S, 002), (Model X, 002))
 - Draining/filling the cooling system ((Model S, 002), (Model X, 002))
 - Initializing the locking actuator of high-voltage charging cable plug ((Model S, 002), (Model X, 002))
 - Unlocking the airbag ECU ((Model S, 002))



Diagnostic devices

Initializing the charging socket cover flap ((Model S, 002), (Model X, 002))

Special bleeding ((Model S, 002), (Model X, 002))

Codings

Service resets

Toyota

- Trouble codes** (Aygo, PAB40), (Camry, AXVH70), (Camry, AXVH71), (Camry, GSV70), (Prius, ZVW50), (RAV 4, ASA44), (RAV 4, ASA44R), (RAV 4, AVA44), (Yaris, GXPA16)
- Parameters** (Aygo, PAB40), (Camry, AXVH70), (Camry, AXVH71), (Camry, GSV70), (Prius, ZVW50), (RAV 4, ASA44), (RAV 4, ASA44R), (RAV 4, AVA44), (Yaris, GXPA16)
- Actuators** (Camry, AXVH71), (Camry, GSV70), (Yaris, GXPA16)
- Basic settings**
 - Calibrating the radar sensor ((Camry, GSV70), (Camry, AXVH71))
 - Registering the parking assist ((Camry, GSV70), (Camry, AXVH71), (Yaris, GXPA16))
 - Initializing the yaw rate sensor ((Camry, AXVH71))
 - De/activating the parking brake service mode ((Camry, AXVH71))
 - Calibrating front radar sensors ((Camry, GSV70), (Camry, AXVH71), (Yaris, GXPA16))
 - Learning the steering-angle sensor ((Camry, GSV70), (Camry, AXVH71))
 - Deactivating the electronic stability control ((Camry, AXVH71))
 - Resetting the particulate filter learning values ((Yaris, NLP10), (Yaris, NLP90), (Urban Cruiser, NLP110), (Urban Cruiser, NLP115), (Auris, NDE150), (Auris, NDE180L), (Verso, NLP121), (Corolla, NDE170), (Yaris, NLP130), (Corolla, MZEH12L), (Corolla, MZEH12), (RAV 4, MXAA54), (RAV 4, MXAA52), (Yaris, MXHP10), (Yaris, MXPA11), (C-HR, MAXH10), (Yaris, MXPB10), (Yaris, MXPJ10), (Yaris, MXPJ15))
 - Calibrating the camera ECU ((Aygo, KGB40), (Aygo, PAB40), (Camry, GSV70), (Camry, AXVH71), (Yaris, GXPA16))
 - Regenerating the soot particulate filter ((Yaris, NLP20), (Yaris, NLP10), (Yaris, NLP20, NLP22), (Urban Cruiser, NLP110), (Urban Cruiser, NLP115), (Auris, NDE180L), (Verso, NLP121), (Auris, NDE180), (Corolla, MZEH12L), (Corolla, MZEH12), (RAV 4, MXAA54), (RAV 4, MXAA52), (Yaris, MXHP10), (Yaris, MXPA11), (C-HR, MAXH10), (Yaris, MXPB10), (Yaris, MXPJ10), (Yaris, MXPJ15))
 - Bleeding the brake system ((Camry, AXVH71))
 - Resetting adaptation values of ABS ECU ((Corolla, NRE210L), (RAV 4, MXAA54), (RAV 4, MXAA52), (Yaris, MXHP10), (Corolla, ZRE210), (Yaris, MXPA11), (Hiace, GDH320), (Hiace, GRH320), (Highlander, GSU70), (Highlander, GSU75), (Highlander, AXUH78), (RAV 4, AXAP54), (Camry, AXVH71), (Corolla, NRE214H), (Corolla, ZEW211), (Yaris, MXPB10), (Yaris, MXPJ10), (Yaris, MXPJ15))
 - Initializing ride height sensors ((Camry, GSV70), (Camry, AXVH71))



Diagnostic devices

Adapting the brake system ((Corolla, NRE210L), (RAV 4, MXAA54), (RAV 4, MXAA52), (Yaris, MXHP10), (Corolla, ZRE210), (Yaris, MXPA11), (Hiace, GDH320), (Hiace, GRH320), (Highlander, GSU70), (Highlander, GSU75), (Highlander, AXUH78), (RAV 4, AXAP54), (Corolla, NRE214H), (Corolla, ZEW211), (Yaris, MXPB10), (Yaris, MXPJ10), (Yaris, MXPJ15))

Codings

Configuring the key warning ((Camry, GSV70), (Camry, AXVH71))

Coding the wheel valves ((RAV 4, MXAA54), (Prius, ZVW50), (Prius, ZVW52), (Camry, GSV70), (Camry, AXVH71))

Service resets

Volkswagen

Trouble codes

(Arteon, 3H), (Crafter, 2E), (Crafter, 2F), (Golf7, 5G), (Golf7, AM), (Golf7, AN), (Golf7, BA), (Golf7, BE), (Golf7, BQ), (Golf7, BV), (Golf8, CD), (Jetta, 16), (Passat, 3G), (Passat, CB), (Polo, AE), (T-Roc, A1), (T-Roc, AC), (Taigo, CS), (Tiguan, BJ), (Transporter, 7E), (Transporter, SG), (Transporter, ST)

Parameters

(Arteon, 3H), (Golf7, 5G), (Golf7, AM), (Golf7, AN), (Golf7, BA), (Golf7, BE), (Golf7, BQ), (Golf7, BV), (Golf8, CD), (Jetta, 16), (Passat, 3G), (Passat, CB), (Polo, AE), (T-Roc, A1), (T-Roc, AC), (Taigo, CS), (Tiguan, BJ), (Touran, 5T), (Transporter, 7E), (Transporter, SG), (Transporter, ST)

Actuators

(Arteon, 3H), (Golf7, 5G), (Golf7, AM), (Golf7, AN), (Golf7, BA), (Golf7, BE), (Golf7, BQ), (Golf7, BV), (Golf8, CD), (Jetta, 16), (Passat, 3G), (Passat, CB), (Polo, AE), (T-Roc, A1), (T-Roc, AC), (Taigo, CS), (Tiguan, BJ), (Touran, 5T), (Transporter, 7E), (Transporter, SG), (Transporter, ST)

Basic settings

Initializing electric seats ((Transporter, ST), (Polo, AE), (Tiguan, BJ), (Taigo, CS))

Initializing the adaptive cruise control ((Passat, CB), (Transporter, ST), (Polo, AE), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1), (Transporter, SG))

Initializing the lateral acceleration sensor ((Transporter, 7E))

Adapting the exhaust gas pressure sensor ((Transporter, 7E), (Transporter, SG))

Resetting fuel system adaptation values ((Transporter, 7E), (Transporter, SG))

Filling fuel lines of parking heater/auxiliary heater ((Transporter, ST), (Polo, AE), (Tiguan, BJ), (T-Roc, A1))

Resetting the start inhibitor of DEF injection system ((Transporter, ST), (Tiguan, BJ))

Regenerating the soot particulate filter ((Sharan, 7N), (Transporter, ST), (Polo, AE), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1))

Initializing the sliding door ((Transporter, 7E), (Transporter, SG))

Resetting engine adaptation values ((Golf6, AJ), (Tiguan, 5N), (Jetta, 16), (CC, 35), (Passat, 36), (Golf6, 51), (Eos, 1F), (Jetta, 1K), (Passat, 3C), (Scirocco, 13), (Touran, 1T), (Golf6, 52), (Golf6, 5K), (Golf5, 5M), (Golf5, 1K), (Sharan, 7N), (Polo, 6R), (New Beetle, 5C), (CC, 35), (Transporter, ST), (Polo, AE), (Tiguan, BJ), (T-Roc, A1), (Transporter, SG))

Initializing the ESC sensors ((Golf8, CD), (Caddy, SB), (Transporter, ST), (Polo, AE), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1), (Transporter, SG))

Reset learned values of injectors. ((Transporter, ST), (Tiguan, BJ), (Taigo, CS), (Polo, AE))

Adapting the normal position of ride-height levelling ((Touareg, CR))



Diagnostic devices

Adapting the electronic damper control ((Transporter, ST), (Polo, AE), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1), (Transporter, SG))

Bleeding the fuel system ((Crafter, SY), (Crafter, SZ), (Sharan, 7N), (Transporter, SH), (Transporter, SJ), (Transporter, ST), (Tiguan, BJ), (Taigo, CS), (Transporter, 7E), (Transporter, SG), (Polo, AE))

Burning off aux. heater/independent car heater ((Transporter, ST), (Polo, AE), (Tiguan, BJ), (T-Roc, A1), (Transporter, 7E), (Transporter, SG))

Checking the ash buildup of soot particulate filter ((Transporter, 7E), (Transporter, SG))

Regenerating the soot particulate filter ((Transporter, 7E), (Transporter, SG))

Resetting oxygen sensor adaptation values ((Transporter, 7E), (Transporter, SG))

Performing transmission adaptations ((Transporter, ST), (Polo, AE), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1))

Initializing the seat belt tensioner ECU ((Polo, AE), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1))

Initializing the tilt/slide sunroof ((Polo, AE), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1))

Standardizing the liftgate ((Passat, 3G), (Touran, 5T), (Tiguan, AD), (Arteon, 3H), (Tiguan, BW), (T-Roc, A1), (Touareg, CR), (Passat, CB), (Transporter, SH), (Transporter, SJ), (Golf8, CD), (T-Roc, AC), (ID.4, E2), (Tiguan, AX), (Transporter, ST), (Tiguan, BJ), (Transporter, SG))

Initializing the fuel pump ((Jetta, 1K), (Golf5, 1K), (Eos, 1F))

Initialize actuator of coolant temperature control ((Transporter, ST), (Tiguan, BJ), (T-Roc, A1))

Adapting the soot particulate filter ((Transporter, ST), (Polo, AE), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1), (Transporter, 7E), (Transporter, SG))

Learning the steering-angle sensor ((Transporter, ST), (Polo, AE), (Taigo, CS))

Learning the throttle valve ((Transporter, ST), (Polo, AE), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1), (Transporter, 7E), (Transporter, SG))

Learning the steering-angle sensor ((Tiguan, BJ), (T-Roc, A1), (Transporter, 7E), (Transporter, SG))

Performing engine adaptations ((Sharan, 7N), (Transporter, ST), (Tiguan, BJ))

Resetting air filter learned values ((Transporter, 7E), (Transporter, SG))

Initializing the brake-pressure sensor ((Golf8, CD), (Caddy, SB), (Transporter, ST), (Tiguan, BJ), (T-Roc, A1), (Transporter, 7E), (Transporter, SG))

Initializing the boost pressure regulator ((Transporter, ST), (Polo, AE), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1))

Resetting learned values of DEF injection system ((Touareg, 7P), (Golf7, 5G), (Golf7, BA), (Golf7, AM), (Jetta, 16), (Golf6, 51), (Touran, 5T), (Tiguan, AD), (Golf7, AN), (Passat, 3G), (New Beetle, 5C), (Tiguan, 5N), (Caddy, SA), (Golf7, BQ), (Golf7, BV), (Arteon, 3H), (Tiguan, BW), (Polo, AW), (T-Roc, A1), (Passat, CB))

Adjusting the xenon headlight ((Transporter, 7E))

Performing the initial run-in of the air conditioning compressor ((Transporter, ST), (Polo, AE), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1), (Transporter, 7E), (Transporter, SG))

Calibrating the tire pressure monitoring system ((Transporter, 7E))

Learning the turbocharger ((Transporter, SG))

Retracting parking brake ((Golf8, CD), (ID.3, E1), (ID.4, E2), (Caddy, SB), (Transporter, ST), (Tiguan, BJ), (T-Roc, A1))



Diagnostic devices

- Initializing the transmission ECU ((Transporter, 7E), (Transporter, SG))
- Initializing the clutch pedal position ((Tiguan, BJ), (T-Roc, A1))
- Reducing fuel high pressure ((Transporter, ST), (Polo, AE), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1))
- Initializing the A/C flap actuators ((Transporter, ST), (Polo, AE), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1))
- Initializing the alternator ((Polo, AE), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1))
- Activating the retrofitted parking heater ((Transporter, ST), (Tiguan, BJ), (T-Roc, A1))
- Initializing the EGR valve ((Transporter, 7E), (Transporter, SG))
- Initializing the oxidation catalyst ((Transporter, ST), (Tiguan, BJ))
- Adapting the electronic climate control ((Transporter, 7E), (Transporter, SG))
- Initialize 4WD clutch oil pump ((Tiguan, BJ), (T-Roc, A1), (Transporter, SG))
- Configuring the lane change assist ((Transporter, 7E), (Transporter, SG))
- Adjust headlight with/without dynamic light control (DLA) ((T-Roc, A1))
- Resetting timing chain adaptation values ((Transporter, ST), (Polo, AE), (Tiguan, BJ), (T-Roc, A1))
- Resetting the impact mode ((Touareg, CR), (Golf8, CD), (Polo, AE), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1))
- Initializing the neutral position sensor ((Transporter, ST), (Polo, AE), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1))
- Resetting the diesel exhaust fluid level ((Transporter, ST), (Tiguan, BJ))
- Adapting the radiator shutter ((Sharan, 7N), (Transporter, ST), (Tiguan, BJ), (Taigo, CS))
- Calibrating the parking brake ((Golf8, CD), (Caddy, SB), (Transporter, ST))
- Adjusting the headlights ((Transporter, ST), (Polo, AE), (Tiguan, BJ), (Taigo, CS), (Transporter, SG))
- Adapting oil pressure for engine run-in ((Sharan, 7N), (Touareg, CR), (Polo, AE))
- Adapt the intake manifold flap ((Golf5, 1K))
- Bleeding the cooling system ((Transporter, ST), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1), (Transporter, SG), (Polo, AE))
- Resetting gen. ECU learning values ((Transporter, 7E))
- Activating the roller test stand mode ((Transporter, 7E))
- Calibrating the camera ECU ((Polo, AW), (Arteon, 3H), (T-Cross, C1), (Passat, CB), (Transporter, SH), (Transporter, SJ), (Golf8, CD), (ID.3, E1), (ID.4, E2), (Tiguan, AX), (Caddy, SB), (Transporter, ST), (Polo, AE), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1), (Transporter, 7E))
- Adapting the fuel burning heater remote control ((Transporter, ST), (Polo, AE), (Tiguan, BJ), (T-Roc, A1), (Transporter, 7E), (Transporter, SG))
- Filling/bleeding the pneumatic suspension system ((Touareg, CR))
- Extending parking brake ((Golf8, CD), (ID.3, E1), (ID.4, E2), (Caddy, SB), (Transporter, ST), (Tiguan, BJ), (T-Roc, A1))
- Adapting the DEF injection system ((Transporter, SG))
- Unlocking aux. heater/independent car heater ((Transporter, ST), (Polo, AE), (Tiguan, BJ), (T-Roc, A1), (Transporter, 7E), (Transporter, SG))



Diagnostic devices

Calibrating the parking brake ((Tiguan, BJ), (T-Roc, A1))

Activating the roller test stand mode ((Golf8, CD), (Caddy, SB), (Transporter, ST))

Codings

Coding the language version ((Polo, AE), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1))

Variable service interval coding ((Transporter, 7E))

Coding injectors ((Transporter, ST), (Tiguan, BJ), (Transporter, 7E), (Transporter, SG))

General ECU replacement ((Polo, AE), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1), (Transporter, 7E), (Transporter, SG))

Expert mode ECU coding ((Polo, AE), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1), (Transporter, 7E), (Transporter, SG))

Coding the rain/light sensor ((Transporter, ST), (Polo, AE), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1), (Transporter, 7E))

Deactivating/activating the transport mode ((Golf8, CD), (Caddy, SB), (Transporter, ST), (Polo, AE), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1), (Transporter, 7E), (Transporter, SG))

Coding the language version of instrument cluster ((Transporter, 7E), (Transporter, SG))

Coding the fuel burning heater ((Caddy, 2C), (Touran, 1T), (Transporter, 7E))

Adjust parking assistance volume ((Transporter, ST), (Polo, AE), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1), (Transporter, 7E), (Transporter, SG))

Coding the remote control ((Transporter, 7E))

Coding the steering-column module ((Tiguan, BJ), (T-Roc, A1))

De-/activating the cruise control ((Transporter, 7E))

Adapting the trailer hitch to advanced driver assistance systems ((Polo, AE), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1), (Transporter, 7E), (Transporter, SG))

Registering the battery ((Golf8, CD), (Caddy, SB), (Transporter, ST), (Polo, AE), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1), (Transporter, 7E), (Transporter, SG))

Coding the parking assist ((Transporter, 7E), (Transporter, SG))

Coding the radio remote control ((New Beetle, 5C))

Coding the trailer detection ((Tiguan, AX), (Tiguan, BW), (Transporter, ST), (Polo, AE), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1), (Transporter, 7E), (Transporter, SG))

Coding the rear camera system ((Transporter, 7E))

De/activating the trailer hitch ((Golf8, CD), (Caddy, SB), (Transporter, ST), (Polo, AE), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1), (Transporter, 7E), (Transporter, SG))

Coding the gateway installation list ((Polo, AE), (Tiguan, BJ), (Taigo, CS), (T-Roc, A1), (Transporter, 7E), (Transporter, SG))

Coding the instrument cluster ((Transporter, 70), (Sharan, 7M), (Passat, 3B), (Transporter, 7D), (Polo, 9N), (Transporter, 7E))

Service resets

((Golf7, 5G), (Golf7, AM), (Golf7, AN), (Golf7, BA), (Golf7, BQ), (Golf7, BV), (ID.3, E1), (ID.4, E2), (Polo, AE), (T-Roc, A1), (Taigo, CS), (Tiguan, AD), (Tiguan, BJ), (Tiguan, BW), (Transporter, 7E), (Transporter, SG), (Transporter, ST))



Diagnostic devices

Volvo

- | Trouble codes
- | Parameters (XC60-II, UZ)
- | Actuators
- | Basic settings
- | Codings
- | Service resets

*capable for diagnostics only with mega macs X