## Oil coolers for hydrodynamic retarders | HELLA

## General

Hydrodynamic retarders (working with liquids) are used in commercial vehicles in order to support the actual brake system as an almost wear-free hydrokinetic brake. The kinetic energy is turned into heat through the deceleration caused by the flow speed of the oil, and this must be transferred back to the cooling system via a heat exchanger (Fig.1). The use of the retarder is either activated by the driver or works automatically. The braking power reaches several hundred KW.



0

Figure 1



Besides the service brake of a commercial vehicle, which usually is a friction brake subject to wear, vehicle manufacturers increasingly use additional, wear-free deceleration systems.



All variants have several common goals:



Figure 2





• Minimise wear of the service brake

NAME AND POST OFFICE ADDRESS OF TAXABLE PARTY OF TAXABLE PARTY.
The second
The WAR PRODUCED IN THE OWNER OF THE PARTY O
ANTIAN PROPERTY AND A CONTRACT OF A CONTRACT
A WAR PROPERTY AND A REAL PROPERTY A REAL
NAME AND ADDRESS OF THE OWNER
Restriction of the second second of the second seco
Restances in a sub-
Advised in the owner of the owner of the owner of the owner of the
indemandent of the second
The second se

Figure 4



Figure 5

The oil cooler, which is made of solid aluminium or steel, is flange-mounted to the retarder and returns the heat it absorbs to the vehicle coolant circuit. In order to avoid exceeding the preset temperature limit, a temperature sensor for monitoring the coolant temperature is installed near the oil cooler. The sensor ensures that the retarder is reduced or switched off when the temperature limit is exceeded.

## Important safety notice

The following technical information and tips for practical use have been set up by HELLA in order to offer professional support to automotive workshops in their daily work. The information available here on this website is only to be used by appropriately trained specialist staff.

The reprinting, distribution, reproduction, exploitation in any form and disclosure of the contents of this document, even in part, is prohibited without our express written approval and indication of the source. The schematic illustrations, figures and descriptions are for explanation and presentation of the document text and cannot be used as a basis for installation or design. All rights reserved.