



BMW 1 Series - buzzing noise when the air conditioning is switched off


| | |
|---------------------|-----------------------------------|
| Data sheet | |
| Manufacturer | BMW |
| Vehicle model | 1 Series (F40) |
| Engine | All models without keyless system |
| Year of manufacture | 2019 - |
| Symptoms | Buzzing noise |

Important safety note

Buzzing when air conditioning is switched off

If the engine is idling, there may be buzzing noises in the engine compartment when the air conditioning is switched off. These can be caused by the air conditioning compressor.

Before replacing the compressor, check the battery voltage, the compressor power supply and the correct refrigerant quantity or system pressures.



Reprinting, distribution, reproduction, exploitation in any form or disclosure of the contents of this document, even in part, is prohibited without our express, written approval; indication of the document source is also required. The schematic illustrations, pictures and descriptions serve only for the purposes of explanation and representation of the instructions and cannot be used as a basis for installation or assembly work. All rights reserved.