



## **Audi A6** **Model year from 08.2001 to 03.2005** **with 2.0 L engine and engine code ALT**

### **Engine will not start**

If there are complaints about the above-mentioned fault, the cause could be a defective engine-control relay. In addition, it may be that after a successful engine start, the engine cuts out when driving. The following fault codes may be stored in the fault memory:

- P0685 Supply relay for engine control unit/drive control unit – open circuit.
- P0688 Engine control unit – Short-circuit on battery plus.
- P1517 Engine control relay – Circuit malfunction.

In this case, the engine control relay (See picture, slot 3) must be replaced. This is located in the fuse box, on the front left in the engine bay. After this, delete the fault memory.

