## **Bulletin**



© Hella KGaA Hueck & Co., Lippstadt

22. September 2005

4.4

## Audi All models from model year 2002 with alarm system

## When the driver door is opened using the key, only the driver is opened and the alarm is triggered.

If there are complaints with these vehicles that after the driver door has been opened using the key only the driver door opens and the alarm is triggered, this is not a fault. Since model year 2002 all Audi vehicles equipped with an alarm system have had this additional function. If the ignition is not switched on within 15 seconds of the driver door being opened using the key, the acoustic alarm sounds. This additional function is not active when the remote control is used.



