



BMW E34 / E36

Control light of the Airbag system illuminated after working on the instruments panel.

If the instrument panel on this vehicles is removed, the ignition should not be switched on. When the ignition is switched on, during the time the instrument panel is disconnected, a trouble code is saved in the ECU. This trouble code "Open circuit Airbag control light" shows itself after, through the control light being illuminated one minute when the ignition is switched on. To eliminate the trouble code, the fault memory must be read out and deleted with a suitable tester.

