



## ***Opel Vevtra-B up to build year 1996 All engines***

### **Illumination of the coolant level warning light in the check display**

If the coolant level warning light illuminates although the coolant level is okay, a possible cause could be a faulty coolant level sensor. To rectify the problem consider the following steps:

Check the sensor in the coolant expansion tank for continuity using a multimeter. Reading: 0 Ohm. Also check the wiring and the connector for damage and continuity. If the sensor has no continuity it must be renewed. When the sensor and the coolant expansion tank are one unit, the complete coolant expansion tank must be renewed.

**Bulletin**