



VW Polo Type: 6N2 Loose Ground / Earth connections.

Engine starts and then stops/
Engine doesn't start

If the above-mentioned vehicles, after starting, immediately stop or don't start in damp weather, the cause can be loose ground/earth connections. We recommend you to proceed as follows:

- Carry out self diagnosis
- Should an error code be stored and the code can not be erased or the ECU doesn't register, all ground connections should be checked, if necessary cleaned and tightened with a torque of 9 Nm. In particular pay attention on the connections in the area of the tunnel (see picture).
- Try to erase the error code once more and/or establish a connection with the ECU.

