



AUDI

All models with 2.6 l engine

Engine code: ACZ,ABC

Engine control device with self maintenance

Idle current measurements on the vehicle when

the battery is discharging

When an idle current measurement is taken on the vehicles listed here because of constant battery discharge, observe the following:

The motor control device installed in these vehicles has what is called self maintenance, also called an after-running function.

This function can be active up to 2.30 hours after the motor is turned off. During this time, the idle current reception can be up to 250 mA.

If repairs are being done at the same time, or if plug connectors are pulled out of the engine cable tree, a fault entry may appear in the engine control device. In this case the failure memory should be read out and then deleted.

