



BMW E 34 With Check Control

Message “Stop light” or “Brake electrics” appears sporadically in the Check Control display.

If there are complaints with these vehicles that the message “Stop light” or “Brake electrics” appears sporadically even though everything on the vehicle is OK, one possible cause is a relay.

The relay in question is the load release relay K3 which switches late.

To rectify the fault, the relief relay K3 in the fuse box (engine compartment) must be replaced.