



VW Golf, Bora, Passat model year 1999 with alarm system and interior monitoring

Interior lights are glowing.

If with these vehicles the boot is opened within a short time of the vehicle having been locked up (approx. 30 seconds), the interior lights can begin to glow. This fault is caused by return currents. The interior lights switch off again after about 70 minutes. To eliminate the fault an adapter lead has to be installed in the front interior light with a diode which prevents the return current. To do this proceed as follows:

- Remove front interior light.
- Pull the plug off the interior light and insert the adapter lead between interior light and plug.
- Reinstall the interior light and check its function.