



VW Lupo

Main beam cannot be switched off

If there are complaints with these vehicles that the main beam cannot be switched off, one possible cause is the indicator switch. If too much actuation force is used, the main beam contacts in the indicator switch become damaged. These bend and the main beam can no longer be switched off.

In this case the indicator switch must be replaced.

Modified indicator switches have been installed in vehicles since model year September 1999.