



Fiat 500 X - squeaking noises when braking

Data sheet

Manufacturer

Fiat

Vehicle model

500 X

Models

All models, up to chassis no: 0P318018

Year of manufacture

From 2014 -

Symptoms

Squeaking noises when braking

Important safety note

Fiat 500 X - squeaking noises

In the above-mentioned vehicles, squeaking noises may occur when braking, originating from the front of the vehicle. The noise occurs mainly when braking at low speed and until the vehicle comes to a standstill.

The cause may be the use of excess thread locking compound. The locking compound, applied between the steering knuckle and the support of the brake calliper on the front axle, prevents the components from fully being in contact with each other.

Take the following steps to rectify the problem:

- Remove and discard the fastening screws of the front axle brake calliper carrier
- Clean the contact surfaces of the steering knuckles and the brake calliper carrier
- Insert new fastening screws with locking compound and tighten to the torque specified by the vehicle manufacturer

Reprinting, distribution, reproduction, exploitation in any form or disclosure of the contents of this document, even in part, is prohibited without our express, written approval; indication of the document source is also required. The schematic illustrations, pictures and descriptions serve only for the purposes of explanation and representation of the instructions and cannot be used as a basis for installation or assembly work. All rights reserved.