



Jeep Compass - engine cuts out again after having started it at low outside temperatures

Data sheet	
Manufacturer	Jeep
Vehicle model	Compass
Year of manufacture	2017
Engine code	All models
Symptoms	Engine stops again after having started it at low outside temperatures

Important safety note

Shortly after having started the engine in the Jeep Compass, the engine may stop again in low outside temperatures

In the above-mentioned vehicles, the engine may cut out again shortly after starting at low outside temperatures (-10 °C). This is often the case when the vehicle has been parked overnight.

Particularly when it is operated for short distances, condensation accumulates in the exhaust system, which freezes at low outside temperatures and blocks the exhaust gas flow. This causes the engine to stop after starting.

To remedy this, drill a hole with a maximum depth of 25 mm and a diameter of 3 mm at the lower end of the rear silencer (see figure). <shy /> This ensures that the condensation water is drained.



Reprinting, distribution, reproduction, exploitation in any form or disclosure of the contents of this document, even in part, is prohibited without our express, written approval; indication of the document source is also required. The schematic illustrations, pictures and descriptions serve only for the purposes of explanation and representation of the instructions and cannot be used as a basis for installation or assembly work. All rights reserved.